


MOUNTING AND OPERATING INSTRUCTIONS



EB 8384-5 EN

Translation of original instructions



Series 3730

Type 3730-5 Electropneumatic Positioner

With FOUNDATION™ fieldbus communication · FF Device Rev. 3

Firmware version 1.65



Edition January 2022

Note on these mounting and operating instructions

These mounting and operating instructions assist you in mounting and operating the device safely. The instructions are binding for handling SAMSON devices. The images shown in these instructions are for illustration purposes only. The actual product may vary.

- For the safe and proper use of these instructions, read them carefully and keep them for later reference.
- If you have any questions about these instructions, contact SAMSON's After-sales Service (aftersaleservice@samsongroup.com).



Documents relating to the device, such as the mounting and operating instructions, are available on our website at www.samsongroup.com > **Downloads > Documentation.**

Definition of signal words

DANGER

Hazardous situations which, if not avoided, will result in death or serious injury

WARNING

Hazardous situations which, if not avoided, could result in death or serious injury

NOTICE

Property damage message or malfunction

Note

Additional information

Tip

Recommended action

| | | |
|----------|--|-----------|
| 1 | Safety instructions and measures | 7 |
| 1.1 | Notes on possible severe personal injury | 10 |
| 1.2 | Notes on possible personal injury | 11 |
| 1.3 | Notes on possible property damage | 11 |
| 2 | Markings on the device | 13 |
| 2.1 | Nameplate | 13 |
| 2.2 | Article code | 14 |
| 2.3 | Firmware versions | 15 |
| 3 | Design and principle of operation | 19 |
| 3.1 | Mounting versions | 20 |
| 3.2 | Additional equipment | 20 |
| 3.3 | Communication | 21 |
| 3.4 | Configuration using the TROVIS-VIEW software | 21 |
| 3.5 | Device overview and operating controls | 22 |
| 3.6 | Accessories | 23 |
| 3.6.1 | Travel tables | 28 |
| 3.7 | Technical data | 29 |
| 3.8 | Dimensions in mm | 35 |
| 3.8.1 | Fixing levels according to VDI/VDE 3845 (September 2010) | 39 |
| 4 | Measures for preparation | 41 |
| 4.1 | Unpacking | 41 |
| 4.2 | Transporting | 41 |
| 4.3 | Storage | 41 |
| 5 | Mounting and start-up | 43 |
| 5.1 | Mounting position | 43 |
| 5.2 | Lever and pin position | 43 |
| 5.3 | Exchanging the lever | 44 |
| 5.4 | Direct attachment | 48 |
| 5.4.1 | Type 3277-5 Actuator | 48 |
| 5.4.2 | Type 3277 Actuator | 50 |
| 5.5 | Attachment according to IEC 60534-6 | 52 |

Contents

| | | |
|----------|---|-----------|
| 5.6 | Attachment according to VDI/VDE 3847-1 | 54 |
| 5.7 | Attachment according to VDI/VDE 3847-2 | 58 |
| 5.7.1 | Version for single-acting actuator | 60 |
| 5.7.2 | Version for double-acting actuator | 62 |
| 5.8 | Attachment to Type 3510 Micro-flow Valve | 66 |
| 5.9 | Attachment to rotary actuators | 66 |
| 5.9.1 | Heavy-duty version | 68 |
| 5.10 | Reversing amplifier for double-acting actuators | 72 |
| 5.10.1 | Reversing amplifier (1079-1118 or 1079-1119) | 72 |
| 5.11 | Attachment of external position sensor | 74 |
| 5.11.1 | Mounting the position sensor with direct attachment | 75 |
| 5.11.2 | Mounting the position sensor with attachment according to IEC 60534-6 | 77 |
| 5.11.3 | Mounting the position sensor to Type 3510 Micro-flow Valve | 78 |
| 5.11.4 | Mounting on rotary actuators | 79 |
| 5.12 | Mounting the leakage sensor | 80 |
| 5.13 | Retrofitting an inductive limit switch | 81 |
| 5.14 | Attaching positioners with stainless steel housings | 82 |
| 5.15 | Air purging function for single-acting actuators | 82 |
| 5.15 | Pneumatic connections | 85 |
| 5.15.1 | Connecting the supply air | 85 |
| 5.15.2 | Signal pressure gauges | 86 |
| 5.15.3 | Supply pressure | 86 |
| 5.15.4 | Signal pressure (output) | 87 |
| 5.16 | Electrical connections | 87 |
| 5.16.1 | Establishing communication | 89 |
| 6 | Operation | 93 |
| 7 | Operating the positioner | 97 |
| 7.1 | Determining the fail-safe position | 98 |
| 7.2 | Adjusting the volume restriction Q | 98 |
| 7.3 | Adapting the display direction | 99 |
| 7.4 | Limiting the signal pressure | 99 |
| 7.5 | Checking the operating range of the positioner | 100 |
| 7.6 | Initializing the positioner | 101 |

| | | |
|-----------|--|------------|
| 7.6.1 | MAX – Initialization based on maximum range | 104 |
| 7.6.2 | NOM – Initialization based on nominal range | 105 |
| 7.6.3 | MAN – Initialization based on a manually selected range | 107 |
| 7.6.4 | SU _b – Substitute calibration | 108 |
| 7.7 | Zero calibration | 113 |
| 7.8 | Adjusting the inductive limit switch | 114 |
| 7.9 | Reset to default settings | 116 |
| 7.10 | Enabling and selecting parameters | 116 |
| 7.11 | Operating modes | 118 |
| 7.11.1 | Automatic and manual modes | 118 |
| 7.11.2 | Fail-safe position (SAFE) | 119 |
| 8 | Servicing..... | 121 |
| 8.1 | Firmware update..... | 121 |
| 8.2 | Preparation for return shipment | 122 |
| 9 | Malfunctions | 123 |
| 9.1 | Confirming error messages | 124 |
| 9.2 | Emergency action | 124 |
| 10 | Decommissioning and removal | 125 |
| 10.1 | Decommissioning | 125 |
| 10.2 | Removing the positioner | 125 |
| 10.3 | Disposal | 125 |
| 11 | Appendix..... | 127 |
| 11.1 | After-sales service | 127 |
| 11.2 | Certificates | 127 |
| 11.3 | Code list..... | 128 |
| 11.4 | Error codes..... | 135 |
| 11.5 | Decimal values of the modes in the FOUNDATION™ fieldbus blocks (Code 48) | 141 |
| 11.6 | Decimal values of the states in the FOUNDATION™ fieldbus blocks (Code 48) | 141 |
| 11.8 | Selecting the characteristic..... | 143 |

i Note

- Configuration and operation over FOUNDATION™ fieldbus are described in the Configuration Manual ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.
 - The functions of the **EXPERTplus** Valve Diagnostics are described in the Operating Instructions ► EB 8389. EB 8389 is included on the enclosed CD-ROM and is available on our website.
-

1 Safety instructions and measures

Intended use

SAMSON's Type 3730-5 Positioner is mounted on pneumatic control valves and is used to assign the valve position to the control signal. The device is designed to operate under exactly defined conditions (e.g. operating pressure, temperature). Therefore, operators must ensure that the positioner is only used in applications where the operating conditions correspond to the technical data. In case operators intend to use the positioner in other applications or conditions than specified, contact SAMSON.

SAMSON does not assume any liability for damage resulting from the failure to use the device for its intended purpose or for damage caused by external forces or any other external factors.

➔ Refer to the technical data for limits and fields of application as well as possible uses.

Reasonably foreseeable misuse

The Type 3730-5 Positioner is **not** suitable for the following applications:

- Use outside the limits defined during sizing and by the technical data

Furthermore, the following activities do not comply with the intended use:

- Use of non-original spare parts
- Performing maintenance activities not specified by SAMSON

Qualifications of operating personnel

The positioner is to be mounted, started up or operated only by trained and experienced personnel familiar with the product. According to these mounting and operating instructions, trained personnel refers to individuals who are able to judge the work they are assigned to and recognize possible hazards due to their specialized training, their knowledge and experience as well as their knowledge of the applicable standards.

Explosion-protected versions of this device must be operated only by personnel who has undergone special training or instructions or who is authorized to work on explosion-protected devices in hazardous areas.

Safety instructions and measures

Personal protective equipment

No personal protective equipment is required for the direct handling of the positioner. Work on the control valve may be necessary when mounting or removing the device.

- Observe the requirements for personal protective equipment specified in the valve documentation.
- Check with the plant operator for details on further protective equipment.

Revisions and other modifications

Revisions, conversions or other modifications of the product are not authorized by SAMSON. They are performed at the user's own risk and may lead to safety hazards, for example. Furthermore, the product may no longer meet the requirements for its intended use.

Safety features

Upon failure of the air supply or electric signal, the positioner vents the actuator, causing the valve to move to the fail-safe position determined by the actuator.

Warning against residual hazards

The positioner has direct influence on the control valve. Any hazards that could be caused in the valve by the process medium, the signal pressure or by moving parts are to be prevented by taking appropriate precautions. They must observe all hazard statements, warning and caution notes in these mounting and operating instructions, especially for installation, start-up and service work.

If inadmissible motions or forces are produced in the pneumatic actuator as a result of the supply pressure, it must be restricted using a suitable supply pressure reducing station.

Explosion protection

– Explosive dust atmospheres of zone 21 or zone 22

The following applies to type of protection Ex i in combustible dust atmospheres:

If intrinsic safety is impaired by the influence of dust, an enclosure complying with Clause 6.1.3 of EN 60079-11 with at least in degree of protection IP 5X must be used.

The requirements according to Clause 6.1.3 apply to the cable glands accordingly. The degree of ingress protection is verified by a test according to IEC 60529 and EN 60079-0 (e.g. performed by VDE).

For use in the presence of combustible dust in compliance with type of protection Ex tb IIC (protection by enclosure), observe Clause 5.6.3 of EN 60079-14.

– Servicing explosion-protected devices

If a part of the device on which the explosion protection is based needs to be serviced, the device must not be put back into operation until a qualified inspector has assessed it according to explosion protection requirements, has issued an inspection certificate, or given the device a mark of conformity. Inspection by a qualified inspector is not required if the manufacturer performed a routine test on the device before putting it back into operation. Document the passing of the routine test by attaching a mark of conformity to the device.

Replace explosion-protected components only with original, routine-tested components by the manufacturer.

Devices that have already been used outside hazardous areas and are intended for future use inside hazardous areas must comply with the safety requirements placed on serviced devices. Before being operated inside hazardous areas, test the devices according to the specifications for servicing explosion-protected devices.

EN 60079-17 applies to servicing explosion-protected devices.

– Maintenance, calibration and work on equipment

Observe the maximum permissible values specified in the certificates for intrinsically safe circuits to ensure that components relevant to explosion protection are not damaged.

Responsibilities of the operator

The operator is responsible for proper operation and compliance with the safety regulations. Operators are obliged to provide these mounting and operating instructions to the operating personnel and to instruct them in proper operation. Furthermore, the operator must ensure that operating personnel or third persons are not exposed to any danger.

Responsibilities of operating personnel

Operating personnel must read and understand these mounting and operating instructions as well as the specified hazard statements, warning and caution notes. Furthermore, the operating personnel must be familiar with the applicable health, safety and accident prevention regulations and comply with them.

Safety instructions and measures

Referenced standards, directives and regulations

Devices with a CE marking fulfill the following requirements of the Directives:

- Type 3730-5: 2011/65/EU, 2014/30/EU
- Type 3730-51, -55, -58: 2011/65/EU, 2014/30/EU, 2014/34/EU

See Appendix for declarations of conformity.

Referenced documentation

The following documents apply in addition to these mounting and operating instructions:

- Operating instructions for valve diagnostics: ► EB 8389
- The mounting and operating instructions of the components on which the positioner is mounted (valve, actuator, valve accessories etc.).

1.1 Notes on possible severe personal injury

DANGER

Risk of fatal injury due to the formation of an explosive atmosphere.

Incorrect installation, operation or maintenance of the positioner in potentially explosive atmospheres may lead to ignition of the atmosphere and cause death.

- ➔ The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1).
- ➔ Installation, operation or maintenance of the positioner must only be performed by personnel who has undergone special training or instructions or who is authorized to work on explosion-protected devices in hazardous areas.

1.2 Notes on possible personal injury

⚠ WARNING

Risk of personal injury due to moving parts on the valve.

During initialization of the positioner and during operation, the actuator stem moves through its entire travel range. Injury to hands or fingers is possible if they are inserted into the valve.

- During initialization, do not insert hands or fingers into the valve yoke and do not touch any moving valve parts.

1.3 Notes on possible property damage

ⓘ NOTICE

Risk of damage to the positioner due to incorrect mounting position.

- Do not mount the positioner with the back of the device facing upward.
- Do not seal or restrict the vent opening when the device is installed on site.

Incorrect installation of the lever in positioner versions without a sliding clutch will damage the travel sensor.

- Hold the lever in position while removing or mounting it to prevent it from moving to the end stops.

Risk of malfunction due to incorrect sequence during start-up.

The positioner can only work properly if the mounting and start-up are performed in the prescribed sequence.

- Perform mounting and start-up as described in Chapter 5.

An incorrect electric signal will damage the positioner.

The positioner is powered over the bus line.

- Only use a current source and never a voltage source.

Incorrect assignment of the terminals will damage the positioner and will lead to malfunction.

For the positioner to function properly, the prescribed terminal assignment must be observed.

- Connect the electrical wiring to the positioner according to the prescribed terminal assignment.

Malfunction due to initialization not yet completed.

The initialization causes the positioner to be adapted to the mounting situation. After initialization is completed, the positioner is ready to use.

- Initialize the positioner on the first start-up.
- Re-initialize positioner after changing the mounting position.

Risk of positioner damage due to incorrect grounding of the electric welding equipment.

- Do not ground electric welding equipment near to the positioner.

2 Markings on the device

2.1 Nameplate

The nameplates shown were up to date at the time of publication of this document. The nameplates on the device may differ from the ones shown.

Explosion-protected version

SAMSON 3730-5 FOUNDATION™ Fieldbus Positioner

FOUNDATION

Communication Profile Class: 1

Physical Layer Class: 2

Supply max. 3

Fieldbus* 4

5

* See technical data and explosion-protection certificate for permissible ambient temperature and maximum values.

⚠ See technical data for ambient temperature

Diagnostics EXPERTplus

Date 7

Firmware 6

Var.-ID 8 Serial no. 9

Model 10

SAMSON AG D-60314 Frankfurt Made in Germany

- 1 FOUNDATION™ fieldbus: Communication Profile Class
- 2 FOUNDATION™ fieldbus: Physical Layer Class
- 3 Supply pressure
- 4 Type of protection for explosion-protected devices

Version without explosion protection

SAMSON 3730-5 FOUNDATION™ Fieldbus Positioner

FOUNDATION

Communication Profile Class: 1

Physical Layer Class: 2

Supply max. 3

Fieldbus 4

5

⚠ See technical data for ambient temperature

Diagnostics EXPERTplus

Date 7

Firmware 6

Var.-ID 8 Serial no. 9

Model 10

Made in Germany SAMSON AG D-60314 Frankfurt

- 5 Features: Yes/ No
 - Binary input 5 to 30 V DC
 - Binary input, floating contact
 - Leakage detection
 - Limit switch, inductive
 - Solenoid valve
- 6 Firmware version (see Chapter 2.3)
- 7 Year of manufacture
- 8 Configuration ID
- 9 Serial number
- 10 Model number
- 11 Conformity
- 12 RoHS marking
- 13 Data Matrix code

2.2 Article code

| Positioner | Type 3730-5 | x | x | 0 | x | x | x | 0 | x | 0 | 0 | x | 0 | x | x | |
|--|---------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| With LCD and autotune, FOUNDATION™ fieldbus | | | | | | | | | | | | | | | | |
| Explosion protection | | | | | | | | | | | | | | | | |
| Without | | 0 | | | | | | | | | | | | 0 | 0 | 0 |
| ATEX II 2G Ex ia IIC T6 Gb; II 2D Ex ia III T80°C Db | | 1 | | | | | | | | | | | | 0 | 0 | 0 |
| ATEX II 2D Ex tb IIIC T80°C Db | | 5 | | | | | | | | | | | | 0 | 0 | 0 |
| ATEX II 3G Ex nA IIC T6 Gc, II 3D Ex tc IIIC T80°C Dc | | 8 | | | | | | | | | | | | 0 | 0 | 0 |
| IECEX Ex ia IIC T6...T4 Gb; Ex ia IIIC T80°C Db | | 1 | | | | | | | | | | | | 0 | 1 | 2 |
| IECEX Ex nA IIC T6...T4 Gc; Ex tc IIIC T80°C Dc | | 8 | | | | | | | | | | | | 0 | 1 | 3 |
| CCC Ex Ex ia IIC T4...T6 Gb; Ex ia IIIC T80 °C Db | | 1 | | | | | | | | | | | | 0 | 0 | 9 |
| CCC Ex Ex ec IIC T6 Gc | | 8 | | | | | | | | | | | | 0 | 1 | 0 |
| CCoE Ex ia IIC T6...T4 Gb | | 1 | | | | | | | | | | | | | | |
| CSA Ex ia IIC T6; Class I,II, Div.1, Groups A–G; Ex nA II T6; Ex nL IIC T6; Class I, II, Div.2, Groups A–G; Class II, Div.1, Groups E–G; Class III | | 3 | | | | | | | | | | | | 0 | 0 | 0 |
| EAC 1 Ex ia IIC T6/T5/T4 Gb X, Ex tb IIIC T80 °C Db X | | 1 | | | | | | | | | | | | 0 | 1 | 4 |
| FM Class I, Zone 0 AEx ia IIC; Class I, II, III, Div.1, Groups A, B, C, D, E, F, G; Class I, Div.2, Groups A, B, C, D; Class II, Div.2, Groups F, G | | | | | | | | | | | | | | | 0 | 0 |
| INMETRO Ex ia IIC T4...T6 Gb; Ex ia IIIC T80 °C Db | | 1 | | | | | | | | | | | | 0 | 3 | 1 |
| Ex ec IIC T4...T6 Gc; Ex tc IIIC T80 °C Dc | | 8 | | | | | | | | | | | | | | |
| KCS Ex ia IIC T6/T5/T4 | | 1 | | | | | | | | | | | | 0 | 2 | 9 |
| TR CMU II 2G Ex ia IIC T6...T4 Gb; II 2D Ex ia IIIC T80 °C Db | | 1 | | | | | | | | | | | | 0 | 4 | 3 |
| II 2D Ex tb IIIC T80 °C Db | | 5 | | | | | | | | | | | | | | |
| II 3G Ex ic nA IIC T6 Gc; II 3D Ex tc IIIC T80 °C Dc IP66 | | 8 | | | | | | | | | | | | | | |
| UKEX II 2G Ex ia IIC T4/T6 Gb; II 2D Ex ia IIIC T80°C Db | | 1 | | | | | | | | | | | | 0 | 5 | 1 |
| II 2D Ex tb IIIC T80°C Db | | 5 | | | | | | | | | | | | | | |
| II 3G Ex ec IIC T* Gc; II 3D Ex tc IIIC T80°C Dc | | 8 | | | | | | | | | | | | | | |
| Additional equipment | | | | | | | | | | | | | | | | |
| Inductive limit switch | Without | 0 | | | | | | | | | | | | | | |
| | SJ2-SN (NC contact) | 1 | | | | | | | | | | | | | | |
| Solenoid valve | Without | 0 | | | | | | | | | | | | | | |
| | With, 24 V DC | 4 | | | | | | | | | | | | | | |
| External position sensor | Without | | | | | 0 | | | | | | | | | | |
| | With | 0 | | 1 | 0 | | 0 | | | | | | | | | |
| Leakage sensor | Without | | | | | | 0 | | | | | | | | | |
| | With | | | | | | 1 | | | | | | | | | |
| Binary input | Without | | | | | | | 0 | | | | | | | | |
| | Floating contact | | | | | | 0 | 1 | | | | | | | | |
| Diagnostics | | | | | | | | | | | | | | | | |
| EXPERTplus | | | | | | | | | | 4 | | | | | | |

| Positioner | Type 3730-5 | | | | | | | | | | | | |
|--|-------------|---|---|---|---|---|---|---|---|---|---|---|-------|
| Housing material | x | x | 0 | x | x | x | 0 | x | 0 | 0 | x | x | x |
| Aluminum (standard) | | | | | | | | | 0 | | | | |
| Stainless steel 1.4408 | | | 0 | | | | | | 1 | | | | |
| Special applications | | | | | | | | | | | | | |
| Without | | | | | | | | | | | | | 0 |
| Device compatible with paint | | | | | | | | | | | | | 1 |
| Exhaust air port with 1/4-18 NPT thread, back of positioner sealed | 0 | 0 | 0 | 0 | | | | | | | | | 2 |
| Attachment according to VDI/VDE 3847 including interface | | | | | | | | | | | | | 6 |
| Attachment according to VDI/VDE 3847 prepared for interface | | | | | | | | | | | | | 7 |
| Special version | | | | | | | | | | | | | |
| Without | | | | | | | | | | | | | 0 0 0 |

2.3 Firmware versions

| Firmware revisions (Control R) |
|--|
| R 1.44 to 1.46 Internal revisions |
| R 1.52 <ul style="list-style-type: none"> • Diagnostics: all EXPERTplus diagnostic functions are available without having to activate them in the positioner (► EB 8389 on EXPERTplus Valve Diagnostics). • Additional function blocks: 2x DO (Discrete Output), 1x IS (Input Selector), 1x MAI (Multiple Analog Input), 1x MAO (Multiple Analog Output). See Configuration Manual ► KH 8384-5 • New functions: new functions are implemented in the DO Function Block (Discrete Output). See Configuration Manual ► KH 8384-5 • Action on fault detection: If the AO Transducer Block is in O/S mode and the condensed state changes to "Maintenance alarm", the following actions can be started: <ul style="list-style-type: none"> – Hold last value – Move valve to fail-safe position – Move to a predefined fault state value Configuration Manual ► KH 8384-5 |
| R 1.54 to 1.56 Code 48 extended: The following subitems have been added to Code 48 (► EB 8389): <ul style="list-style-type: none"> • h0: Activation/deactivation reference test • h1: Reference test completed (YES/No) • h3: Automatic reset of diagnosis after this time • h4: Remaining time until diagnosis reset |
| R 1.54 to 1.56 Internal revisions |
| R 1.57 Data logging: Data logging has been extended to document errors in internal device communication. |

Markings on the device

| Firmware revisions (Control R) |
|--|
| R 1.58 Improved memory function: the test results of newly performed partial stroke tests (PST) are saved in several cycles. |
| R 1.62 The positioner moves more quickly to closed-loop operation due to an improved start-up routine. |
| R 1.64 Improved memory function: the test results of newly performed partial stroke tests (PST) are saved in several cycles. |
| R 1.65 Internal revisions |

| Firmware revisions (Communication K) |
|---|
| Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website. |
| K 1.21 <ul style="list-style-type: none">• "Device not initialized" diagnostic alarm: the diagnostic alarm "Device not initialized" is generated when the positioner is not initialized and the condensed state is set to "Maintenance alarm".• Leakage sensor at binary input 2: The connection of a leakage sensor at binary input 2 (by selecting LEAKAGE SENSOR in CONFIG_BINARY_INPUT2 parameter of the AO Transducer Block) causes:<ul style="list-style-type: none">– Information specified in XD_ERROR_EXT parameter in the AO Transducer Block and the generation of a diagnostic alarm which is logged– The state of the binary input is reported in BINARY_INPUT2 parameter in the AO Transducer BlockThe connection of a leakage sensor at binary input 2 (by selecting LEAKAGE SENSOR in CONFIG_BINARY_INPUT2 parameter of the AO Transducer Block) causes:<ul style="list-style-type: none">– Information specified in XD_ERROR_EXT parameter in the AO Transducer Block and the generation of a diagnostic alarm which is logged– The state of the binary input is reported in BINARY_INPUT2 parameter in the AO Transducer Block• Display of the operating range FINAL_VALUE_RANGE: the correction of the operating range FINAL_VALUE_RANGE over on-site operation of the positioner (Code 8/9) is also transferred over fieldbus in firmware version K 1.21 and higher.• De-energized internal solenoid valve: a masking allows to set whether a de-energized internal solenoid valve generates an AO block error, resulting in a block alarm.• SOLENOID_SELECT parameter: the SOLENOID_SELECT parameter in firmware K 1.21 and higher allows to set whether a "Maintenance now" block error of the AO Transducer Block results in an output error in the AO Block.• TOT_VALVE_TRAV_LIM parameter: new range: 1 000 to 990 000 000 |

| |
|---|
| <p>Firmware revisions (Communication K)</p> <p>Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.</p> |
| <p>K 1.22</p> <ul style="list-style-type: none"> • Operating range FINAL_VALUE_RANGE: the operating range FINAL_VALUE_RANGE of the AO Transducer Block is compared on entering it with TRANSM_PIN_POS. • If the TRANSM_PIN_POS parameter is changed, the positioner checks whether the setting and unit match the current operating range FINAL_VALUE_RANGE. If this is not the case, the FINAL_VALUE_RANGE parameter is set to 0 to 100 %. • VALVE_TYPE parameter: the parameter of the AO Transducer Block is set depending on the selected PIN_POS. The last setting is kept when VALVE_TYPE is set to OFF. • FINAL_VALUE parameter: the output value is scaled with FINAL_VALUE_RANGE in firmware K 1.22 and higher and not as previously with XD_SCALE. • Display of O/S mode in AO Transducer Block: if the AO Transducer Block is set to O/S mode, this is indicated in the positioner display by MAN/AUTO. |
| <p>K 1.23 Internal revisions</p> |
| <p>K 1.24</p> <ul style="list-style-type: none"> • BUS_ADDRESS parameter: the bus address has the default setting of 248. • Device type: in the delivered state, the device is configured as a basic device. |
| <p>K 1.25 Internal revisions</p> |
| <p>K 2.01</p> <ul style="list-style-type: none"> • Additional function blocks: 2x DO (Discrete Output), 1x IS (Input Selector), 1x MAI (Multiple Analog Input), 1x MAO (Multiple Analog Output). • New functions: the following new functions are implemented in the DO Function Block (Discrete Output): <ul style="list-style-type: none"> – Discrete analysis of on/off valves – Start partial stroke test (PST) – Start and reset the data logger – Resetting the diagnosis – Stop diagnosis – Move to the fail-safe position – Lock on-site operation • Action on fault detection: If the AO Transducer Block is in O/S mode and the condensed state changes to "Maintenance alarm", the following actions can be started: <ul style="list-style-type: none"> – Hold last value – Move valve to fail-safe position – Move to a predefined fault state value |
| <p>K 2.02</p> <p>Partial stroke test (PST): configuration of the partial stroke test (PST) over the FF parameters is no longer possible. Configuration over the TROVIS-VIEW software is still possible.</p> |

Markings on the device

Firmware revisions (Communication K)

Further details can be found in ► KH 8384-5. KH 8384-5 is included on the enclosed CD-ROM and is available on our website.

K 2.03

Partial stroke test (PST): configuration of the partial stroke test (PST) over the FF parameters is no longer possible. Configuration over the TROVIS-VIEW software is still possible. The partial stroke test can be started over the binary input BI2.

K 2.04

Internal revisions

K 2.05

Internal revisions

K 2.06

Process control system: new firmware compatible with Honeywell Experion® control system.
Communication: improved communication of valve positions smaller than -0.9% .

K 2.07

Testing device functioning: monitoring of internal device communication has been added to the cyclic testing of the device functions.

K 2.08

Internal communication interface redesigned: the permissible clock frequency of communication calls between the internal device controllers has been optimized.

K 3.01

- Certified according to ITK 6.2.0
- Diagnostics specification according to FF-912
- Function block added: AI (Analog Input)
- Function blocks removed: MAI (Multiple Analog Input), MAO (Multiple Analog Output), IS (Input Selector)

K 3.05

Internal communication interface redesigned: the permissible clock frequency of communication calls between the internal device controllers has been optimized.

K 3.06

Fail-safe position reliably maintained even when the positioner is not connected to the process control system.

3 Design and principle of operation

→ Refer to Fig. 1

The positioner is mounted on pneumatic control valves and is used to assign the valve position (controlled variable x) to the control signal (set point w). The positioner compares the control signal of a control system to the travel or rotational angle of the control valve and issues a signal pressure (output variable y) for the pneumatic actuator.

The positioner mainly consists of an electric travel sensor system, an analog i/p convert-

er with a downstream air capacity booster and the electronics with the microcontroller.

When a system deviation occurs, the actuator is either vented or filled with air. If necessary, the signal pressure change can be slowed down by a volume restriction. The signal pressure supplied to the actuator can be limited by software or on site to 1.4, 2.4 or 3.7 bar.

The fixed flow regulator ensures a constant air flow to the atmosphere, which is used to flush the inside of the positioner housing and to optimize the air capacity booster. The i/p converter is supplied with a constant upstream pressure by the pressure regulator to




Fig. 1: Block diagram

Design and principle of operation

compensate for any fluctuations in the supply pressure.

The positioner communicates and is powered using IEC 61158-2 transmission technology conforming to FOUNDATION™ fieldbus specification.

As a standard feature, the positioner comes with a binary input used to signalize process information over the FOUNDATION™ fieldbus network.

The extended EXPERTplus diagnostics are integrated into the positioner. They provide information on the positioner and generate diagnostic and status messages, which allow faults to be pinpointed quickly.

3.1 Mounting versions

The positioner is suitable for the following types of attachment using the corresponding accessories (see Chapter 3.6):

- **Direct attachment to SAMSON Type 3277 Actuator**
→ See Chapter 5.4.
- **Attachment to actuators according to IEC 60534-6:**
→ See Chapter 5.5.
- **Attachment according to VDI/VDE 3847-1/-2:**
→ See Chapter 5.6 and Chapter 5.7.
- **Attachment to Type 3510 Micro-flow Valve**
→ See Chapter 5.8.

- **Attachment to rotary actuators according to VDI/VDE 3845:**

→ See Chapter 5.9.

3.2 Additional equipment

Solenoid valve

If the operating voltage for the solenoid valve (12) fails, the supply pressure for the i/p converter is vented to the atmosphere.

The positioner can no longer operate and the control valve moves to the fail-safe position determined by the actuator, regardless of the set point.

! NOTICE

The manual set point is also reset to 0 % after the solenoid valve is activated.

A different manual set point must be entered again (Code 1).

Inductive limit switch

In this version, the rotary shaft of the positioner carries an adjustable tag which actuates the built-in proximity switch.

External position sensor

In this version, only the sensor is mounted to the control valve. The positioner is located separately from the valve. The connection of x and y signals to the valve is established by cable and piping for air (only without inductive limit switch).

Leakage sensor

By upgrading the positioner with a leakage sensor, it is possible to detect seat leakage when the valve is in the closed position.

Binary input BI1 (14)

As a standard feature, the positioner comes with a binary input used to signalize process information over the FOUNDATION™ fieldbus network.

Binary input BI2 (15)

This binary input BI2 is optional. It is an active input which is powered by the positioner to connect a floating contact. The switching state of the floating contact can be indicated over the FOUNDATION™ fieldbus network.

i Note

The binary inputs are configured in the DI Function Blocks. Refer to Configuration Manual ► KH 8384-5.

3.3 Communication

The positioner is controlled completely by digital signal transmission according to FOUNDATION™ fieldbus specification.

Data are transmitted over the bus using digital, bit-synchronous Manchester coding at a Baud rate of 31.25 kbit/s over twisted-pair wires according to IEC 61158-2.

i Note

*If complex functions are started in the positioner, which require a long calculation time or lead to a large quantity of data being saved in the volatile memory of the positioner, the alert 'busy' is issued over the DD. This alert is **not an error message** and can be simply confirmed.*

Configuration and operation of the positioner over FOUNDATION™ fieldbus are described in the Configuration Manual

► KH 8384-5.

3.4 Configuration using the TROVIS-VIEW software

The positioner can be configured with SAMSON's TROVIS-VIEW Software.

The positioner has for this purpose a **serial interface** to allow the RS-232 or USB port of a computer to be connected to it using an adapter cable.

The TROVIS-VIEW software enables the user to easily configure the positioner as well as view process parameters online.

i Note

TROVIS-VIEW provides a uniform user interface that allows users to configure and parameterize various SAMSON devices using device-specific database modules. The device module 3730-5 can be downloaded free of charge from our website at

▶ www.samsongroup.com > Downloads > TROVIS-VIEW.

Further information on TROVIS-VIEW (e.g. system requirements) is available on our website and in the Data Sheet ▶ T 6661.

3.5 Device overview and operating controls

→ See Chapter 6.

3.6 Accessories

Table 1: *General accessories*

| Designation | Order no. | |
|--|--|-----------|
| Reversing amplifier for double-acting actuators | Type 3710 | |
| Cable gland M20x1.5 | Black plastic (6 to 12 mm clamping range) | 8808-1011 |
| | Blue plastic (6 to 12 mm clamping range) | 8808-1012 |
| | Nickel-plated brass (6 to 12 mm clamping range) | 1890-4875 |
| | Nickel-plated brass (10 to 14 mm clamping range) | 1922-8395 |
| | Stainless steel 1.4305 (8 to 14.5 mm clamping range) | 8808-0160 |
| Adapter M20x1.5 to ½ NPT | Powder-coated aluminum | 0310-2149 |
| | Stainless steel | 1400-7114 |
| Lever | S | 0510-0522 |
| | M | 0510-0510 |
| | L | 0510-0511 |
| | XL | 0510-0512 |
| | XXL | 0510-0525 |
| Retrofit kit for inductive limit switch 1 x SJ2-SN | 1402-1770 | |
| Isolated USB interface adapter (SSP interface to USB port) including TROVIS-VIEW CD-ROM | 1400-9740 | |
| Serial interface adapter (SAMSON SSP interface to RS-232 port on a computer) | 1400-7700 | |
| TROVIS-VIEW 6661 (download: ► www.samsongroup.com > Downloads > Software & Drivers > TROVIS-VIEW) | | |

Table 2: *Direct attachment to Type 3277-5 (see Chapter 5.4.1)*

| Designation | Order no. | | |
|----------------------------|--|---------------------------------|-----------|
| Mounting parts | Standard version for actuators 120 cm ² or smaller | 1400-7452 | |
| | Version compatible with paint for actuators 120 cm ² or smaller | 1402-0940 | |
| Accessories for actuator | Old switchover plate for Type 3277-5xxxxxx. 00 Actuator (old) | 1400-6819 | |
| | New switchover plate for Type 3277-5xxxxxx. 01 Actuator (new) ¹⁾ | 1400-6822 | |
| | New connecting plate for Type 3277-5xxxxxx. 01 Actuator (new) ¹⁾ , G ¼ and ½ NPT | 1400-6823 | |
| | Old connecting plate for Type 3277-5xxxxxx. 00 Actuator (old): G ¼ | 1400-6820 | |
| | Old connecting plate for Type 3277-5xxxxxx. 00 (old): ½ NPT | 1400-6821 | |
| Accessories for positioner | Connecting plate (6) | G ¼ | 1400-7461 |
| | | ¼ NPT | 1400-7462 |
| | Pressure gauge bracket (7) | G ¼ | 1400-7458 |
| | | ¼ NPT | 1400-7459 |
| | Pressure gauge mounting kit (8) up to max. 6 bar (output/supply) | Stainless steel/brass | 1402-0938 |
| | | Stainless steel/stainless steel | 1402-0939 |

¹⁾ Only new switchover and connecting plates can be used with new actuators (Index 01). Old and new plates are not interchangeable.

Design and principle of operation

Table 3: Direct attachment to Type 3277 (see Chapter 5.4.2)

| Mounting parts/accessories | | Order no. |
|--|---------------------------------|-----------|
| Standard version for actuators 175, 240, 350, 355, 700, 750 cm ² | | 1400-7453 |
| Version compatible with paint for actuators 175, 240, 350, 355, 700, 750 cm ² | | 1402-0941 |
| Connection block with seals and screw | G ¼ | 1400-8819 |
| | ¼ NPT | 1402-0901 |
| Pressure gauge mounting kit up to max. 6 bar (output/supply) | Stainless steel/brass | 1402-0938 |
| | Stainless steel/stainless steel | 1402-0939 |
| Piping with screw fittings ¹⁾ | | Order no. |
| Actuator (175 cm ²), steel | G ¼/G ¾ | 1402-0970 |
| | ¼ NPT/¾ NPT | 1402-0976 |
| Actuator (175 cm ²), stainless steel | G ¼/G ¾ | 1402-0971 |
| | ¼ NPT/¾ NPT | 1402-0978 |
| Actuator (240 cm ²), steel | G ¼/G ¾ | 1400-6444 |
| | ¼ NPT/¾ NPT | 1402-0911 |
| Actuator (240 cm ²), stainless steel | G ¼/G ¾ | 1400-6445 |
| | ¼ NPT/¾ NPT | 1402-0912 |
| Actuator (350 cm ²), steel | G ¼/G ¾ | 1400-6446 |
| | ¼ NPT/¾ NPT | 1402-0913 |
| Actuator (350 cm ²), stainless steel | G ¼/G ¾ | 1400-6447 |
| | ¼ NPT/¾ NPT | 1402-0914 |
| Actuator (355 cm ²), steel | G ¼/G ¾ | 1402-0972 |
| | ¼ NPT/¾ NPT | 1402-0979 |
| Actuator (355 cm ²), stainless steel | G ¼/G ¾ | 1402-0973 |
| | ¼ NPT/¾ NPT | 1402-0980 |
| Actuator (700 cm ²), steel | G ¼/G ¾ | 1400-6448 |
| | ¼ NPT/¾ NPT | 1402-0915 |
| Actuator (700 cm ²), stainless steel | G ¼/G ¾ | 1400-6449 |
| | ¼ NPT/¾ NPT | 1402-0916 |
| Actuator (750 cm ²), steel | G ¼/G ¾ | 1402-0974 |
| | ¼ NPT/¾ NPT | 1402-0981 |
| Actuator (750 cm ²), stainless steel | G ¼/G ¾ | 1402-0975 |
| | ¼ NPT/¾ NPT | 1402-0982 |

¹⁾ For "actuator stem retracts" fail-safe action with air purging of the top diaphragm chamber

Table 4: Attachment to NAMUR rib or attachment to rod-type yokes ¹⁾ according to IEC 60534-6 (Chapter 5.5)

| Travel in mm | Lever | For actuator | Order no. |
|--|-----------------|---|-----------|
| 7.5 | S | Type 3271-5 with 60/120 cm ² on Type 3510 Micro-flow Valve | 1402-0478 |
| 5 to 50 | M ²⁾ | Actuators from other manufacturers and Type 3271 with 120 to 750 cm ² effective areas | 1400-7454 |
| 14 to 100 | L | Actuators from other manufacturers and Type 3271 with 1000 and 1400-60 cm ² | 1400-7455 |
| 30 or 60 | L | Type 3271, 1400-120 and 2800 cm ² versions with 30/60 mm travel ³⁾ | 1400-7466 |
| | | Mounting brackets for Emerson and Masoneilan linear actuators (in addition, a mounting kit according to IEC 60534-6 is required depending on the travel). See rows above. | 1400-6771 |
| | | Valtek Type 25/50 | 1400-9554 |
| 40 to 200 | XL | Actuators from other manufacturers and Type 3271 with 1400-120 and 2800 cm ² and with 120 mm travel | 1400-7456 |
| Accessories | | | Order no. |
| Connecting plate | | G ¼ | 1400-7461 |
| | | ¼ NPT | 1400-7462 |
| Pressure gauge bracket | | G ¼ | 1400-7458 |
| | | ¼ NPT | 1400-7459 |
| Pressure gauge mounting kit up to max. 6 bar (output/supply) | | Stainless steel/brass | 1402-0938 |
| | | Stainless steel/stainless steel | 1402-0939 |

¹⁾ 20 to 35 mm rod diameter

²⁾ M lever is mounted on basic device (included in the scope of delivery)

³⁾ In conjunction with Type 3273 Side-mounted Handwheel with 120 mm rated travel, additionally one bracket (0300-1162) and two countersunk screws (8330-0919) are required.

Table 5: Attachment according to VDI/VDE 3847-1 (see Chapter 5.6)

| Mounting parts | | Order no. | |
|--|-----------------|---------------|-----------|
| VDI/VDE 3847 interface adapter | | 1402-0257 | |
| Connecting plate, including connection for air purging of actuator spring chamber | Aluminum | ISO 228/1-G ¼ | 1402-0268 |
| | | ¼-18 NPT | 1402-0269 |
| | Stainless steel | ISO 228/1-G ¼ | 1402-0270 |
| | | ¼-18 NPT | 1402-0271 |
| Mounting kit for attachment to SAMSON Type 3277 Actuator with 175 to 750 cm ² | | 1402-0868 | |
| Mounting kit for attachment to SAMSON Type 3271 Actuator or third-party actuators | | 1402-0869 | |
| Travel pick-off for valve travel up to 100 mm | | 1402-0177 | |
| Travel pick-off for 100 to 200 mm valve travel (SAMSON Type 3271 Actuator only) | | 1402-0178 | |

Design and principle of operation

Table 6: Attachment according to VDI/VDE 3847-2 (see Chapter 5.7)

| Designation | | Order no. |
|--------------------------|---|-----------|
| Mounting parts | Mounting block for PFEIFFER Type 31a (edition 2020+) Rotary Actuators with dummy plate for solenoid valve interface | 1402-1645 |
| | Dummy plate for solenoid valve interface (sold individually) | 1402-1290 |
| | Adapter bracket for Type 3730 (VDI/VDE 3847) | 1402-0257 |
| | Adapter bracket for Type 3730 and Type 3710 (DAP/PST) | 1402-1590 |
| Accessories for actuator | Shaft adapter AA1 | 1402-1617 |
| | Shaft adapter AA2 | 1402-1616 |
| | Shaft adapter AA4 | 1402-1888 |

Table 7: Attachment to rotary actuators (see Chapter 5.9)

| Mounting parts/accessories | | Order no. | |
|---|--|---------------------------------|-----------|
| Attachment according to VDI/VDE 3845 (September 2010), actuator surface corresponds to fixing level 1 | | | |
| | Size AA1 to AA4, version with CrNiMo steel bracket | 1400-7448 | |
| | Size AA1 to AA4, heavy-duty version | 1400-9244 | |
| | Size AA5, heavy-duty version (e.g. Air Torque 10 000) | 1400-9542 | |
| | Bracket surface corresponds to fixing level 2, heavy-duty version | 1400-9526 | |
| | Attachment for rotary actuators with max. 180° opening angle, fixing level 2 | 1400-8815 and 1400-9837 | |
| Attachment to SAMSON Type 3278 with 160/320 cm ² , CrNiMo steel bracket | | 1400-7614 | |
| Attachment to SAMSON Type 3278 with 160 cm ² and to VETEC Type S160, Type R and Type M, heavy-duty version | | 1400-9245 | |
| Attachment to SAMSON Type 3278 with 320 cm ² and to VETEC Type S320, heavy-duty version | | 1400-5891 and 1400-9526 | |
| Attachment to Camflex II | | 1400-9120 | |
| Accessories | Connecting plate | G ¼ | 1400-7461 |
| | | ¼ NPT | 1400-7462 |
| | Pressure gauge bracket | G ¼ | 1400-7458 |
| | | ¼ NPT | 1400-7459 |
| | Pressure gauge mounting kit up to max. 6 bar (output/supply) | Stainless steel/brass | 1402-0938 |
| | | Stainless steel/stainless steel | 1402-0939 |

Table 8: Attachment of external position sensor (see Chapter 5.11)

| Mounting parts/accessories | | Order no. |
|--|---|-------------------------|
| Template for mounting position sensor on older mounting parts | | 1060-0784 |
| Direct attachment | Mounting parts for actuator with 120 cm ² | 1400-7472 |
| | Connecting plate (9, old) with $G \frac{1}{8}$ | 1400-6820 |
| | Type 3277-5xxxxx.00 Actuator $\frac{1}{8}$ NPT | 1400-6821 |
| | Connecting plate (new) with Type 3277-5xxxxx.01 Actuator (new) ¹⁾ | 1400-6823 |
| Mounting parts for actuators with 175, 240, 350, 355 and 750 cm ² | | 1400-7471 |
| NAMUR attachment | Mounting parts for attachment to NAMUR rib using L or XL lever | 1400-7468 |
| Attachment to Type 3510 Micro-flow Valve | Mounting parts for Type 3271 Actuator with 60 cm ² | 1400-7469 |
| Attachment to rotary actuators | VDI/VDE 3845 (September 2010), see Chapter 3.8.1 for details. | |
| | Actuator surface corresponds to fixing level 1 | |
| | Size AA1 to AA4 with follower clamp and coupling wheel, version with CrNiMo steel bracket | 1400-7473 |
| | Size AA1 to AA4, heavy-duty version | 1400-9384 |
| | Size AA5, heavy-duty version (e.g. Air Torque 10 000) | 1400-9992 |
| | Bracket surface corresponds to fixing level 2, heavy-duty version | 1400-9974 |
| SAMSON Type 3278 with 160 cm ² and VETEC Type S160 and Type R, heavy-duty version | | 1400-9385 |
| SAMSON Type 3278 with 320 cm ² and VETEC Type S320, heavy-duty version | | 1400-5891 and 1400-9974 |
| Accessories for positioner | Connecting plate (6) $G \frac{1}{4}$ | 1400-7461 |
| | $\frac{1}{4}$ NPT | 1400-7462 |
| | Pressure gauge bracket (7) $G \frac{1}{4}$ | 1400-7458 |
| | $\frac{1}{4}$ NPT | 1400-7459 |
| | Pressure gauge mounting kit up to max. 6 bar (output/supply) Stainless steel/brass | 1402-0938 |
| Stainless steel/stainless steel | 1402-0939 | |
| Bracket to mount the positioner on a wall (Note: The other fastening parts are to be provided at the site of installation as wall foundations vary from site to site). | | 0309-0184 |

¹⁾ Only new connecting plates can be used with new actuators (Index 01). Old and new plates are not interchangeable.

3.6.1 Travel tables

i Note

The **M** lever is included in the scope of delivery.

S, L, XL levers for attachment according to IEC 60534-6 (NAMUR) are available as accessories (see Table 4 on page 25). The **XXL** lever is available on request.

Table 9: Direct attachment to Type 3277-5 and Type 3277 Actuator

| Actuator size [cm ²] | Rated travel [mm] | Adjustment range at positioner ¹⁾ Travel [mm] | Required lever | Assigned pin position |
|-------------------------------------|----------------------|---|-------------------|--------------------------|
| 120 | 7.5 | 5.0 to 25.0 | M | 25 |
| 120/175/240/350 | 15 | 7.0 to 35.0 | M | 35 |
| 355/700/750 | 30 | 10.0 to 50.0 | M | 50 |

¹⁾ The min./max. adjustment range is based on the NOM (nominal range) initialization mode

Table 10: Attachment according to IEC 60534-6 (NAMUR)

| SAMSON valves with Type 3271 Actuator | | Adjustment range at positioner Other control valves ¹⁾ | | Required lever | Assigned pin position |
|--|----------------------|--|---------------------|-------------------|--------------------------|
| Actuator size [cm ²] | Rated travel [mm] | Min. travel [mm] | Max. travel [mm] | | |
| 60 and 120 with Type 3510 Valve | 7.5 | 3.6 | 18.0 | S | 17 |
| 120 | 7.5 | 5.0 | 25.0 | M | 25 |
| 120/175/240/350 | 15 | 7.0 | 35.0 | M | 35 |
| 355/700/750 | 7.5 | 7.0 | 35.0 | M | 35 |
| 355/700/750 | 15 and 30 | 10.0 | 50.0 | M | 50 |
| 1000/1400/2800 | 30 | 14.0 | 70.0 | L | 70 |
| | 60 | 20.0 | 100.0 | L | 100 |
| 1400/2800 | 120 | 40.0 | 200.0 | XL | 200 |
| See manufacturer's specifications | 200 | See manufacturer's specifications | | | 300 |

¹⁾ The min./max. adjustment range is based on the NOM (nominal range) initialization mode

Table 11: Attachment to rotary actuators

| Opening angle | Required lever | Assigned pin position |
|---------------|----------------|-----------------------|
| 24 to 100° | M | 90° |

3.7 Technical data

Table 12: *Type 3730-5 Electropneumatic Positioner*

| Type 3730-5 Positioner: the technical data for the explosion-protected devices may be restricted by the limits specified in the test certificates. | | |
|--|---|--|
| Rated travel, adjustable | Direct attachment to Type 3277 Actuator: 3.6 to 30 mm Attachment according to IEC 60534-6 (NAMUR): 3.6 to 300 mm Attachment according to VDI/VDE 3847: 3.6 to 300 mm Attachment to rotary actuators (VDI/VDE 3845): 24 to 100° opening angle | |
| Travel range, adjustable | Adjustable within the initialized travel/angle of rotation; travel can be restricted to 1/5 at the maximum | |
| Bus connection | Fieldbus interface according to IEC 61158-2, bus-powered Physical Layer Class 113 (without explosion protection) and 111 (explosion-protected version) Field device according to FM 3610 entity, FISCO and FNICO | |
| Communi- cation | Fieldbus | Data transmission conforming to FOUNDATION™ fieldbus specification Communication Profile Class: 31 PS, 32 L Interoperability tested according to Interoperability Test Kit (ITK) 6.2.0 |
| | Execution times | AO FB: 30 ms DI FB: 20 ms PID FB: 40 ms |
| | Local | SAMSON SSP interface and serial interface adapter Software requirements: TROVIS-VIEW with database module 3730-5 |
| Permissible operating voltage | 9 to 32 V DC · Powered by bus line Observe the limits in the test certificate for explosion-protected versions. | |
| Maximum operating current | 15 mA | |
| Additional current in case of error | 0 mA | |
| | 1.4 to 7 bar (20 to 105 psi) | |
| Supply air | Air quality acc. to ISO 8573-1 | Max. particle size and density: Class 4 · Oil content: Class 3 Moisture and water: Class 3 · Pressure dew point: Class 3 or at least 10 K below the lowest ambient temperature to be expected |
| Signal pressure (output) | 0 bar up to the supply pressure · Can be limited to 1.4/2.4/3.7 bar ±0.2 bar by software | |
| Characteristic | Linear/Equal percentage/Reverse equal percentage User-defined (over operating software and communication) Butterfly valve, rotary plug valve or segmented ball valve: Linear/equal percentage Deviation from characteristic ≤ 1 % | |
| Hysteresis | ≤0.3 % | |
| Sensitivity | ≤0.1 % | |
| Direction of action | Reversible | |
| Air consumption | Independent of supply air < 110 l _n /h | |

Design and principle of operation





| | |
|---|---|
| Type 3730-5 Positioner: the technical data for the explosion-protected devices may be restricted by the limits specified in the test certificates. | |
| Air output capacity | Supply At $\Delta p = 6 \text{ bar}$: $8.5 \text{ m}_n^3/\text{h}$ · At $\Delta p = 1.4 \text{ bar}$: $3.0 \text{ m}_n^3/\text{h}$ · $K_{V_{\max}(20^\circ\text{C})} = 0.09$ |
| | Exhaust At $\Delta p = 6 \text{ bar}$: $14.0 \text{ m}_n^3/\text{h}$ · At $\Delta p = 1.4 \text{ bar}$: $4.5 \text{ m}_n^3/\text{h}$ · $K_{V_{\max}(20^\circ\text{C})} = 0.15$ |
| Permissible ambient temperature | <p>-20 to +80 °C All versions -45 to +80 °C With metal cable gland -55 to +80 °C Special version for low temperatures with metal cable gland (Type 3730-5xxxxxxxx0x02x0xx)</p> <p>The temperature limits for the explosion-protected devices may be further restricted by the limits specified in the test certificates.</p> |
| Influences | Temperature ≤ 0.15 %/10 K |
| | Supply air None |
| | Effect of vibration ≤ 0.25 % up to 2000 Hz and 4 g according to IEC 770 |
| EMC | Complying with EN 61000-6-2, EN 61000-6-3, EN 61326-1 and NAMUR Recommendation NE 21 |
| Explosion protection | Refer to Table 14 |
| Electrical connections | One M20x1.5 cable gland for 6 to 12 mm clamping range · Second M20x1.5 threaded connection additionally exists · Screw terminals for 0.2 to 2.5 mm ² wire cross-sections |
| Degree of protection | IP66/NEMA 4X |
| Use in safety-instrumented systems (SIL) | Observing the requirements of IEC 61508, the systematic capability of the pilot valve for emergency venting as a component in safety-instrumented systems is given. |
| Emergency venting at 0 V or over the optional solenoid valve | Use is possible on observing the requirements of IEC 61511 and the required hardware fault tolerance in safety-instrumented systems up to SIL 2 (single device/HFT = 0) and SIL 3 (redundant configuration/HFT = 1). |
| Binary input BI1 | |
| Input | 0 to 30 V DC · Reverse polarity protection · Static destruction limit 40 V Current consumption 3.5 mA at 24 V, galvanic isolation |
| Signal | Signal '1' at $U_e > 5 \text{ V}$ · Signal '0' at $U_e < 3 \text{ V}$ |
| Materials | |
| Housing | Die-cast aluminum EN AC-ALSi12(Fe) (EN AC-44300) acc. to DIN EN 1706 chromated and powder paint coated · Special version: stainless steel 1.4408 |
| External parts | Stainless steel 1.4404/316L |
| Cable gland | M20x1.5, black polyamide |
| Weight | Approx. 1.0 kg · Special version in stainless steel: 2.2 kg |
| Conformity |  |

Table 13: *Optional additional functions*

| | |
|---|---|
| Binary input BI2 for floating contact | |
| Switching input | R < 100 Ω · Contact load 100 mA · Static destruction limit 20 V/5.8 mA Galvanic isolation |
| Solenoid valve · Approval acc. to IEC 61508/SIL | |
| Input | 24 V DC · Reverse polarity protection · Static destruction limit 40 V Current consumption $I = \frac{U - 5.7\text{ V}}{3840\ \Omega}$ (corresponding to 4.8 mA at 24 V/114 mW) |
| Signal '0' (no response) | <12 V (emergency venting at 0 V) |
| Signal '1' (response) | > 19 V |
| Service life | >5 x 10 ⁶ switching cycles |
| K _v coefficient | 0.15 |
| Inductive limit switch by Pepperl+Fuchs | |
| | For connection to switching amplifier acc. to EN 60947-5-6 |
| SJ2-SN proximity switch | Measuring plate not detected: ≥3 mA · Measuring plate detected: ≤1 mA |
| External position sensor | |
| Travel | Same as positioner |
| Cable | 10 m · Flexible and durable · With M12x1 connector · Flame-retardant acc. to VDE 0472 · Resistant to oils, lubricants and coolants as well as other aggressive media |
| Permissible ambient temperature | -60 to +105 °C with a fixed connection between positioner and position sensor · The limits in the test certificate additionally apply for explosion-protected versions. |
| Immunity to vibration | Up to 10 g in the range of 10 to 2000 Hz |
| Degree of protection | IP 67 |
| Leakage sensor · Suitable for operation in hazardous areas | |
| Temperature range | -40 to +130 °C |
| Tightening torque | 20 ±5 Nm |


Design and principle of operation

Table 14: Summary of explosion protection approvals


| | | Certification | | | Type of protection | |
|-------------|--------|---|---------------------------------|-----------------------------|---|--|
| Type 3730 | -51 |  | EU type examination certificate | Number | PTB 04 ATEX 2109 | II 2G Ex ia IIC T6 Gb II 2D Ex ia III T80°C Db II 2D Ex tb IIIC T80°C Db |
| | | | | Date | 2017-05-11 | |
| | -55 |  | EU type examination certificate | Number | PTB 04 ATEX 2109 | II 2G Ex ia IIC T6 Gb II 2D Ex ia III T80°C Db II 2D Ex tb IIIC T80°C Db |
| | | | | Date | 2017-05-11 | |
| | -58 |  | Statement of conformity | Number | PTB 05 ATEX 2010 X | II 3G Ex nA IIC T6 Gc, II 3D Ex tc IIIC T80°C Dc |
| | | | | Date | 2017-06-22 | |
| | -51 | IECEX | | Number | IECEX PTB 06.0054X | Ex ia IIC T6...T4 Gb Ex ia IIIC T80°C Db |
| | | | | Date | 2017-07-17 | |
| | 55 | IECEX | | Number | IECEX PTB 06.0054X | Ex tb IIIC T80°C Db |
| | | | | Date | 2017-07-17 | |
| | -58 | IECEX | | Number | IECEX PTB 06.0054X | Ex nA IIC T6...T4 Gc Ex tc IIIC T80 °C Dc |
| | | | | Date | 2017-07-17 | |
| | -5 | CCoE | | Number | A P HQ MH 104 7593 | Ex ia IIC T6...T4 Gb |
| | | | | Date | 2023-05-25 | |
| | | | | Valid until | 2027-12-31 | |
| | -51 | CCC Ex | | Number | 2020322307002425 | Ex ia IIC T4...T6 Gb Ex ia IIIC T80 °C Db |
| Date | | | | 2024-08-05 | | |
| Valid until | | | | 2025-09-28 | | |
| -58 | CCC Ex | | Number | 2020322307002425 | Ex ec IIC T6 Gc | |
| | | | Date | 2024-08-05 | | |
| | | | Valid until | 2025-09-28 | | |
| -53 | CSA | | Number | 1675804 | Ex ia IIC T6; Class I,II, Div.1, Groups A, B, C, D, E, F, G; Ex nA II T6; Ex nL IIC T6; Class I, II, Div.2, Groups A, B, C, D, E, F, G; Class II, Div.1, Groups E, F, G; Class III Type 4 Enclosure | |
| | | | Date | 2017-05-23 | | |
| -51 | EAC | | Number | RU C-DE. HA65.B.00510/20 | 1Ex ia IIC T6/T5/T4 Gb X Ex tb IIIC T80 °C Db X | |
| | | | Date | 2020-03-18 | | |
| | | | Valid until | 2025-03-18 | | |
| -53 | FM | | Number | 3023605 | Class I, Zone 0 AEx ia IIC; Class I, II, III, Div.1, Groups A–G; Class I, Div.2, Groups A–D; Class II, Div.2, Groups F, G | |
| | | | Date | 2006-03-15 | | |

| | | Certification | | Type of protection | |
|-----------|-----|---------------|-------------|--------------------|---|
| Type 3730 | -51 | INMETRO | Number | IEx 22.0025X | Ex ia IIC T4...T6 Gb Ex ia IIIC T80 °C Db |
| | | | Date | 2022-11-22 | |
| | | | Valid until | 2028-11-21 | |
| | -58 | INMETRO | Number | IEx 22.0025X | Ex ec IIC T4...T6 Gc Ex tc IIIC T80 °C Dc |
| | | | Date | 2022-11-22 | |
| | | | Valid until | 2028-11-21 | |
| | -51 | KCS Korea | Number | 11-KB4BO-0225 | Ex ia IIC T6/T5/T4 |
| | | | Date | 2011-11-10 | |
| | | | Valid until | 2024-11-10 | |
| | -51 | NEPSI | Number | GYJ24.1293X | Ex ia IIC T4...T6 Gb Ex ia IIIC T80 °C Db |
| | | | Date | 2024-11-05 | |
| | | | Valid until | 2029-11-04 | |
| | | | Number | GYJ24.1293X | Ex ec IIC T6 Gc |
| | | | Date | 2024-11-05 | |
| | | | Valid until | 2029-11-04 | |
| | -51 | TR CMU | Number | ZETC/35/2021 | II 2G Ex ia IIC T6...T4 Gb II 2D Ex ia IIIC T80 °C Db |
| | | | Date | 2021-07-26 | |
| | | | Valid until | 2024-07-25 | |
| | -55 | TR CMU | Number | ZETC/35/2021 | II 2D Ex tb IIIC T80 °C Db |
| | | | Date | 2021-07-26 | |
| | | | Valid until | 2024-07-25 | |
| | -58 | TR CMU | Number | ZETC/35/2021 | II 3G Ex ic nA IIC T6 Gc II 3D Ex tc IIIC T80 °C Dc IP66 |
| | | | Date | 2021-07-26 | |
| | | | Valid until | 2024-07-25 | |


3.8 Dimensions in mm




**Attachment according to VDI/
VDE 3847-1 onto Type 3277
Actuator**




**Attachment according to VDI/
VDE 3847-1 to a NAMUR rib**



**Attachment according to VDI/VDE 3847-2
with single-acting actuator**




**Attachment according to VDI/VDE 3847-2
with double-acting actuator**




Attachment to rotary actuators according to VDI/VDE 3845

Heavy-duty version





Light version





- ¹⁾ Reversing amplifiers
- Type 3710 (see drawing of heavy-duty version for dimensions)
 - 1079-1118/1079-1119, no longer available (see drawing of light version for dimensions)

Lever



| Lever | x | y | z |
|-------|--------|--------|--------|
| S | 17 mm | 25 mm | 33 mm |
| M | 25 mm | 50 mm | 66 mm |
| L | 70 mm | 100 mm | 116 mm |
| XL | 100 mm | 200 mm | 216 mm |
| XXL | 200 mm | 300 mm | 316 mm |

3.8.1 Fixing levels according to VDI/VDE 3845 (September 2010)



| Dimensions in mm | | | | | | |
|------------------|-----|----|----|------------|------------------|-----------------|
| Size | A | B | C | Ød | M _{min} | D ¹⁾ |
| AA0 | 50 | 25 | 15 | 5.5 for M5 | 66 | 50 |
| AA1 | 80 | 30 | 20 | 5.5 for M5 | 96 | 50 |
| AA2 | 80 | 30 | 30 | 5.5 for M5 | 96 | 50 |
| AA3 | 130 | 30 | 30 | 5.5 for M5 | 146 | 50 |
| AA4 | 130 | 30 | 50 | 5.5 for M5 | 146 | 50 |
| AA5 | 200 | 50 | 80 | 6.5 for M6 | 220 | 50 |

¹⁾ Flange type F05 acc. to DIN EN ISO 5211

4 Measures for preparation

After receiving the shipment, proceed as follows:

1. Check the scope of delivery. Compare the shipment received with the delivery note.
2. Check the shipment for transportation damage. Report any transportation damage.

4.1 Unpacking

NOTICE

Risk of positioner damage due to foreign particles entering it.

Do not remove the packaging and protective film/protective caps until immediately before mounting and start-up.

1. Remove the packaging from the positioner.
2. Dispose of the packaging in accordance with the valid regulations.

4.2 Transporting

- Protect the positioner against external influences (e.g. impact).
- Protect the positioner against moisture and dirt.
- Observe transport temperature depending on the permissible ambient temperature (see technical data in Chapter 3.7).

4.3 Storage

NOTICE

Risk of positioner damage due to improper storage.

- Observe storage instructions.
- Contact SAMSON in case of different storage conditions or long storage periods.

Storage instructions

- Protect the positioner against external influences (e.g. impact, shocks, vibration).
- Do not damage the corrosion protection (coating).
- Protect the positioner against moisture and dirt. In damp spaces, prevent condensation. If necessary, use a drying agent or heating.
- Observe storage temperature depending on the permissible ambient temperature (see technical data in Chapter 3.7).
- Store positioner with closed cover.
- Seal the pneumatic and electrical connections.

5 Mounting and start-up

NOTICE

Risk of malfunction due to incorrect mounting parts/accessories.

Only use the mounting parts and accessories listed in these mounting and operating instructions to mount and install the positioner. Pay attention to the type of attachment.

NOTICE

Risk of malfunction due to incorrect sequence of mounting, installation and start-up.

Observe the prescribed sequence.

→ Sequence:

1. Remove the protective caps from the pneumatic connections.

2. Mount the positioner on the valve.

→ Chapter 5.4 onward

3. Perform pneumatic installation.

→ Chapter 5.15 onward

4. Perform electrical installation.

→ Chapter 5.16 onward

5. Perform settings.

→ Chapter 7 onward

5.1 Mounting position

NOTICE

Risk of damage to the positioner due to incorrect mounting position.

- Do not mount the positioner with the back of the device facing upward.
- Do not seal or restrict the vent opening when the device is installed on site.

→ Observe mounting position (see Fig. 3).

→ Do not seal or restrict the vent opening (see Fig. 2) when the device is installed on site.

5.2 Lever and pin position

The positioner is adapted to the actuator and to the rated travel by the lever on the back of the positioner and the pin inserted into the lever.

The travel tables on page 28 show the maximum adjustment range at the positioner. The travel that can be implemented at the valve is additionally restricted by the selected fail-safe position and the required compression of the actuator springs.

The positioner is equipped with the M lever (pin position 35) as standard (see Fig. 4).

Note

The **M** lever is included in the scope of delivery.

S, L, XL levers are available as accessories.

The **XXL** lever is available on request.

If a pin position other than position **35** with the standard **M** lever is required or an **L** or **XL** lever size is required, proceed as follows (see Fig. 5):

1. Fasten the follower pin (2) in the assigned lever hole (pin position as speci-

Mounting and start-up

fied in the travel tables on page 28).

Only use the longer follower pin included in the mounting kit.

2. Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1).

5.3 Exchanging the lever

The procedure to exchange the lever depends on whether the standard version of the positioner has been ordered with a sliding clutch or the special version without a sliding clutch.

Special version of the positioner without sliding clutch can be identified by their article code. The article code is printed on the nameplate as "Model". Special versions of the positioner without sliding clutch are:

- Type 3730-5xxxxxxxxxxxxx**002**
- Type 3730-5xxxxxxxxxxxxx**018**
- Type 3730-5xxxxxxxxxxxxx**028**
- Type 3730-5xxxxxxxxxxxxx**036**
- Type 3730-5xxxxxxxxxxxxx**039**
- Type 3730-5xxxxxxxxxxxxx**048**

Lever exchange in standard version with sliding clutch

If a pin position other than position 35 with the standard M lever is required or an L or XL lever size is required, proceed as follows:

1. Unthread the nut (1.1) to unfasten the mounted lever (1).

2. Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel tables on page 28). Only use the longer follower pin included in the mounting kit.
3. Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1).
4. Move the newly mounted lever once all the way as far as it will go in both directions to adapt it to the internal measuring lever.

Lever exchange in standard version without sliding clutch

NOTICE

Incorrect installation of the lever in positioner versions without a sliding clutch will damage the travel sensor.

➔ *Hold the lever in position while removing or mounting it to prevent it from moving to the end stops.*

If a pin position other than position 35 with the standard M lever is required or an L or XL lever size is required, proceed as follows:

1. Unthread the nut (1.1) to unfasten the mounted lever (1). While doing so, hold the lever in the middle to ensure that it does not rest at the end stops.
2. Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel tables on page 28).




Fig. 2: Vent opening
(back of the positioner)




Fig. 3: Permissible mounting
positions





Fig. 4: M lever with pin position 35



- 1 Lever
- 1.1 Nut
- 1.2 Disk spring
- 2 Follower pin

Fig. 5: Mounting the lever
and follower pin

Mounting and start-up

Only use the longer follower pin included in the mounting kit.

3. Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1). While doing so, hold the lever in the middle to ensure that it does not rest at the end stops.

5.4 Direct attachment

5.4.1 Type 3277-5 Actuator

- Required mounting parts and accessories: Table 2 on page 23.
- Observe travel tables on page 28.

Actuator with 120 cm² (see Fig. 6)

Depending on the type of positioner attachment, the signal pressure is routed either left or right of the yoke through a hole to the actuator diaphragm. Depending on the fail-safe action of the actuator "actuator stem extends" or "actuator stem retracts" (valve closes or opens upon supply air failure), the switchover plate (9) must first be attached to the actuator yoke. Align the switchover plate with the corresponding symbol for left or right attachment according to the marking (view looking onto the switchover plate).

1. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly.
2. Remove screw plug (4) on the back of the positioner and seal the signal pressure output (38) on the connecting plate (6) or on the pressure gauge bracket (7) with the stopper (5) included in the accessories.
3. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.
4. Mount cover plate (10) with narrow side of the cut-out (Fig. 6, on the left) pointing

towards the signal pressure connection. Make sure that the gasket (14) points towards the actuator yoke.

5. **15 mm travel:** Keep the follower pin (2) on the M lever (1) on the back of the positioner in the pin position 35 (delivered state).
7.5 mm travel: Remove the follower pin (2) from the pin position 35, reposition it in the hole for pin position 25 and screw tight.
6. Insert molded seal (15) into the groove of the positioner housing and insert the seal (10.1) on the back of the housing.
7. Place positioner on the cover plate (10) in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton. The lever (1) must rest on the follower clamp with spring force. Fasten the positioner on the cover plate (10) using the two fastening screws.

i Note

The following applies to all types of attachment except for direct attachment to Type 3277-5: the signal pressure output at the back must be sealed by the screw plug (4, order no. 0180-1436) and the associated O-ring (order no. 0520-0412) (delivered state, parts included in the scope of delivery).

8. Mount cover (11) on the other side. Make sure that the vent plug is located at




Fig. 6: Direct attachment – Signal pressure connection for Type 3277-5 Actuator with 120 cm²

Mounting and start-up

the bottom when the control valve is installed to allow any condensed water that collects to drain off.


5.4.2 Type 3277 Actuator

- ➔ Required mounting parts and accessories: Table 3 on page 24.
- ➔ Observe travel tables on page 28.

Actuators with 175 to 750 cm² effective areas (see Fig. 7)

Mount the positioner on the yoke. The signal pressure is routed to the actuator over the connection block (12), for actuators with fail-safe action "actuator stem extends" internally through a hole in the valve yoke and for "actuator stem retracts" through an external pipe.

1. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.
2. Mount cover plate (10) with narrow side of the cut-out (Fig. 7, on the left) pointing towards the signal pressure connection. Make sure that the gasket (14) points towards the actuator yoke.
3. For actuators with 355, 700 or 750 cm², remove the follower pin (2) on the **M** lever (1) on the back of the positioner from pin position **35**, reposition it in the hole for pin position **50** and screw tight. For actuators 175, 240 and 350 cm² with 15 mm travel, keep the follower pin (2) in pin position **35**.
4. Insert molded seal (15) into the groove of the positioner housing.
5. Place positioner on the cover plate in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton. The lever (1) must rest on the follower clamp with spring force. Fasten the positioner on the cover plate (10) using the two fastening screws.
6. Make sure that the tip of the gasket (16) projecting from the side of the connection block is positioned to match the actuator symbol for the actuator's fail-safe action "actuator stem extends" or "actuator stem retracts". If this is not the case, unscrew the three fastening screws and lift off the cover. Turn the gasket (16) by 180° and re-insert it. The old connection block version (Fig. 7, bottom) requires the switch plate (13) to be turned to align the actuator symbol with the arrow marking.
7. Place the connection block (12) with the associated seals against the positioner and the actuator yoke and fasten using the screw (12.1). For actuators with fail-safe action "actuator stem retracts", additionally remove the stopper (12.2) and mount the external signal pressure pipe.
8. Mount cover (11) on the other side. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.



5.5 Attachment according to IEC 60534-6

- Required mounting parts and accessories: Table 4 on page 25.
- Observe travel tables on page 28.
- Refer to Fig. 8

The positioner is attached to the control valve using a NAMUR bracket (10).

1. Screw the two bolts (14) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (14.1) for fastening.

Actuator sizes 2800 cm² and 1400 cm² with 120 mm travel:

- For a travel of 60 mm or smaller, screw the longer follower plate (3.1) directly to the stem connector (9).
 - For a travel exceeding 60 mm, mount the bracket (16) first and then the follower plate (3) to the bracket together with the bolts (14) and screws (14.1).
2. Mount NAMUR bracket (10) to the control valve as follows:
 - For **attachment to the NAMUR rib**, use an M8 screw (11) and toothed lock washer directly in the yoke hole.
 - For attachment to **valves with rod-type yokes**, use two U-bolts (15) around the yoke. Align the NAMUR bracket (10) according to the embossed scale so that the follower plate (3) is shifted by half the angle range to the NAMUR bracket (the slot of the follower plate is centrally

aligned with the NAMUR bracket at mid valve travel).

3. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly.
4. Select required lever size (1) M, L or XL and pin position according to the actuator size and valve travel listed in the travel table on page 28.

Should a pin position other than position **35** with the standard **M** lever be required or an **L** or **XL** lever size be required, proceed as follows:

- Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel table). Only use the longer follower pin (2) included in the mounting kit.
 - Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1). Move lever once all the way as far as it will go in both directions.
5. Place positioner on the NAMUR bracket in such a manner that the follower pin (2) rests in the slot of the follower plate (3, 3.1). Adjust the lever (1) correspondingly.
Screw the positioner to the NAMUR bracket using its two fastening screws.




Fig. 8: Attachment according to IEC 60534-6 (NAMUR)

5.6 Attachment according to VDI/VDE 3847-1

The Type 3730-5xxx0xxxx0x0060xx and Type 3730-5xxxxxx0xx0700 Positioners with air purging of the actuator's spring chamber can be attached according to VDI/VDE 3847.

Type 3730-5xxx0xxxx0x0000xx Positioner without air purging of the actuator's spring chamber can be attached according to VDI/VDE 3847.

This type of attachment allows the positioner to be replaced quickly while the process is running by blocking the air in the actuator.

The signal pressure can be blocked in the actuator by unscrewing the red retaining screw (20) and turning the air blocker (19) on the bottom of the adapter block.

Attachment to Type 3277 Actuator (see Fig. 9)

→ Required mounting parts and accessories: Table 5 on page 25.

Mount the positioner on the yoke. The signal pressure is routed to the actuator over the connecting plate (12), for actuators with fail-safe action "actuator stem extends" internally through a bore in the valve yoke and for "actuator stem retracts" through external piping.

Only the Y1 port is required for positioner attachment. The Y2 port can be used for air purging of the spring chamber.

1. Place follower clamp (3) on the actuator stem, align it and screw tight so that the

mounting screw is located in the groove of the actuator stem.

2. Place the adapter bracket (6) on the positioner and mount using the screws (6.1). Make sure that the seals are correctly seated. For positioners **with air purging**, remove the stopper (5) before mounting the positioner. For positioners **without air purging**, replace the screw plug (4) with a vent plug.
3. For actuators with 355, 700 or 750 cm², remove the follower pin (2) on the M lever (1) on the back of the positioner from pin position 35, reposition it in the hole for pin position 50 and screw tight.

For actuators 175, 240 and 350 cm² with 15 mm travel, keep the follower pin (2) in pin position 35.

4. Insert the molded seal (6.2) in the groove of the adapter bracket (6).
5. Insert the molded seal (17.1) into the turnboard (17) and mount the turnboard to the adapter block (13) using the screws (17.2).
6. Mount the blank plate (18) to the turnboard (17) using the screws (18.1). Make sure that the seals are correctly seated.

i Note

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted (▶ AB 11).





Fig. 9: Attachment according to VDI/VDE 3847-1 onto Type 3277 Actuator

Mounting and start-up

7. Insert the screws (13.1) through the middle holes of the adapter block (13).
8. Place the connecting plate (12) together with the seal (12.1) onto the screws (13.1) corresponding to the fail-safe action "actuator stem extends" or "actuator stem retracts". The fail-safe action that applies is determined by aligning the groove of the adapter block (13) with the groove of the connecting plate (12) (Fig. 10).



9. Mount the adapter block (13) together with the connecting plate (12) to the actuator using the screws (13.1).
10. Insert the vent plug (11.1) into the **Exh.** connection.
11. For fail-safe action "actuator stem extends", seal the Y1 port with a blanking plug.

For fail-safe action "actuator stem retracts", connect the Y1 port to the signal pressure connection of the actuator.

Place positioner on the adapter block (13) in such a manner that the follower pin (2) rests on the top of the follower clamp (3). Adjust the lever (1) correspondingly and open the positioner cover to hold the positioner shaft in position at the cap or rotary pushbutton.

The lever (1) must rest on the follower clamp with spring force.

Fasten the positioner to the adapter block (13) using the two fastening screws (6.3). Make sure the molded seal (6.2) is properly seated.

12. Mount cover (11) on the other side to the yoke. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.

Attachment to NAMUR rib (see Fig. 11)

- Required mounting parts and accessories: Table 5 on page 25.
- Observe travel tables on page 28.

1. Series 240 Valves, actuator size up to 1400-60 cm²: Screw the two bolts (14) to the bracket of the stem connector or directly to the stem connector (depending on the version), place the follower plate (3) on top and use the screws (14.1) to fasten it.

Type 3251 Valve, 350 to 2800 cm²: Screw the longer follower plate (3.1) to the bracket of the stem connector or directly to the stem connector (depending on the version).

Type 3254 Valve, 1400-120 to 2800 cm²: Screw the two bolts (14) to the bracket (16). Fasten the bracket (16) on to the stem connector, place the follower plate (3) on top and use the screws (14.1) to fasten it.

Mount the positioner on the NAMUR rib as shown in Fig. 11.

2. For attachment to the NAMUR rib, fasten the NAMUR connection block (10) directly into the existing yoke bore using the screw and toothed lock washer (11). Align the marking on the NAMUR valve connection (on the side marked '1') to 50 % travel.

For attachment to **valves with rod-type yokes** using the formed plate (15), which is placed around the yoke: screw the four studs into the NAMUR connection block (10). Place the NAMUR connection block

on the rod and position the formed plate (15) on the opposite side. Use the nuts and toothed lock washers to fasten the formed plate onto the studs. Align the marking on the NAMUR valve connection (on the side marked '1') to 50 % travel.

3. Place the adapter bracket (6) on the positioner and mount using the screws (6.1). Make sure that the seals are correctly seated. For positioners **with air purging**, remove the stopper (5) before mounting the positioner. For positioners **without air purging**, replace the screw plug (4) with a vent plug.
4. Select required lever size (1) **M**, **L** or **XL** and pin position according to the actuator size and valve travel listed in the travel table on page 28.

Should a pin position other than position 35 with the standard M lever be required or an L or XL lever size be required, proceed as follows:

- Fasten the follower pin (2) in the assigned lever hole (pin position as specified in the travel table). Only use the longer follower pin (2) included in the mounting kit.
- Place the lever (1) on the shaft of the positioner and fasten it tight using the disk spring (1.2) and nut (1.1). Move lever once all the way as far as it will go in both directions.
- 5. Insert the molded seal (6.2) in the groove of the adapter bracket.

Mounting and start-up

6. Insert the molded seal (17.1) into the turnboard (17) and mount the turnboard to the adapter block (13) using the screws (17.2).
7. Mount the blank plate (18) to the turnboard using the screws (18.1). Make sure that the seals are correctly seated.

i Note

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted (► AB 11).

8. Fasten the adapter block (13) to the NAMUR connection block using the screws (13.1).
9. Insert the vent plug into the Exh. connection.
10. Place the positioner on the adapter block (13) in such a manner that the follower pin (2) rests on the top of the follower plate (3, 3.1). Adjust the lever (1) correspondingly.
Fasten the positioner to the adapter block (13) using the two fastening screws (6.3). Make sure the molded seal (6.2) is properly seated.
11. For **single-acting actuators without air purging**, connect the Y1 port of the adapter block to the signal pressure connection of the actuator. Seal the Y2 port with a blanking plug.

For **double-acting actuators and actuators with air purging**, connect the Y2 port of the adapter block to the signal pressure connection of the second actuator chamber or spring chamber of the actuator.


5.7 Attachment according to VDI/VDE 3847-2

Attachment according to VDI/VDE 3847-2 for PFEIFFER SRP (single-acting) and DAP (double-acting) rotary actuators in sizes 60 to 1200 with NAMUR interface and air purging of the actuator's spring chamber allows the direct attachment of the positioner without additional piping.

Additionally, the positioner can be replaced quickly while the process is running by blocking the air in single-acting actuators.

Procedure to block the actuator in place (see Fig. 12):

1. Unscrew the red retaining screw (1).
2. Turn the air blocker (2) on the bottom of the adapter block according to the inscription.



5.7.1 Version for single-acting actuator

Mounting onto a PFEIFFER Type 31a (edition 2020+) SRP Rotary Actuator

→ Refer to Fig. 14.

1. Fasten the adapter block (1) to the actuator's NAMUR interface using the four fastening screws (2).

→ Make sure that the seals are correctly seated.

2. Mount the follower wheel (3) onto the actuator shaft. Use the matching shaft adapter (see Table 6 on page 26).

3. Place the adapter bracket (4) onto the adapter block (1) and fasten it using the fastening screws (5).

→ Make sure that the seals are correctly seated.

4. Insert and fasten the follower pin in the 90° position on the positioner's lever (see Fig. 13). Only use the longer follower pin included in the mounting kit.

5. Align the positioner on the adapter bracket (1) in such a way that the follower pin engages into the actuator's follower wheel (3).

6. Fasten the positioner onto the adapter bracket (4) using the fastening screws (6).

→ Make sure that the seals are correctly seated.




Fig. 12: Adapter block for attachment according to VDI/VDE 3847-2




Fig. 13: Follower pin in 90° position




Fig. 14: Mounting on a single-acting actuator

5.7.2 Version for double-acting actuator

A reversing amplifier must be additionally mounted for applications with double-acting (DAP) actuators or applications with single-acting (SAP) actuators that include partial stroke testing.

In this case, a special adapter bracket (4) is required for mounting.

→ Refer to Fig. 16.

1. Fasten the adapter block (1) to the actuator's NAMUR interface using the four fastening screws (2).

→ Make sure that the seals are correctly seated.

2. Mount the follower wheel (3) onto the actuator shaft. Use the matching adapter (see Table 6 on page 26).

3. Place the adapter bracket (4) onto the adapter block (1) and fasten it using the fastening screws (5).

→ Make sure that the seals are correctly seated.

4. Insert and fasten the follower pin into the 90° position on the positioner's lever (see Fig. 13 on page 60).

5. Align the positioner on the adapter bracket (1) in such a way that the follower pin engages into the actuator's follower wheel (3).

6. Fasten the positioner onto the adapter bracket (4) using the fastening screws (6).

7. Mount the Type 3710 Reversing Amplifier (7) together with the two guide bush-

ings (8) and terminal plate (9) onto the adapter bracket using the associated fastening screws (10).

→ Make sure that the seals are correctly seated.

8. Remove the vent plug at the adapter block and seal the opening with the G ¼ screw plug.

9. Mount the turnboard marked '**Doppel**' for double-acting actuators or the turnboard marked '**PST**' for single-acting actuators with partial stroke testing. See Fig. 15.

→ Make sure that the seals are correctly seated.





Fig. 15: Mounting the turnboard



Mounting and start-up

Intermediate plate for AA4 interface


→ Refer to Fig. 17.

An intermediate plate (1) must be mounted between the adapter block and adapter bracket for PFEIFFER SRP and DAP rotary actuators in sizes 900 and 1200 with AA4 interface. This plate is included in the accessories for the shaft adapter AA4 (see Table 6 on page 26).

Mounting a solenoid valve

→ Refer to Fig. 18.

A solenoid valve can also be mounted in place of the blank plate (18). The orientation of the turnboard (17) determines the mounting position of the solenoid valve. Alternatively, a restrictor plate can be mounted. Further information can be found in the document ► AB 11 (Accessories for Solenoid Valves).






Fig. 18: Mounting a solenoid valve

5.8 Attachment to Type 3510 Micro-flow Valve

→ Refer to Fig. 19

→ Required mounting parts and accessories: Table 4 on page 25.

→ Observe travel tables on page 28.

The positioner is attached to the valve yoke using a bracket.

1. Fasten the bracket (9.1) to the stem connector.
2. Screw the two bolts (9.2) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (9.3) for fastening.
3. Mount the travel indication scale (accessories) to the outer side of the yoke using the hex screws (12.1), ensuring that the scale is aligned with the stem connector.
4. Fasten the hex bar (11) onto the outer side of yoke by screwing the M8 screws (11.1) directly into the holes on the yoke.
5. Fasten the bracket (10) to the hex bar using the hex screw (10.1), washer and tooth lock washer.
6. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals are seated properly.
7. Unscrew the standard M lever (1) including follower pin (2) from the positioner shaft.
8. Take the S lever (1) and screw the follower pin (2) in the hole for pin position 17.

9. Place the S lever on the positioner shaft and screw tight using the disk spring (1.2) and nut (1.1).

Move lever once all the way as far as it will go in both directions.

10. Place positioner on the bracket (10) in such a manner that the follower pin slides into the groove of the follower pin (3). Adjust the lever (1) correspondingly. Screw the positioner to the bracket (10) using both its screws.

5.9 Attachment to rotary actuators

→ Refer to Fig. 21

→ Required mounting parts and accessories: Table 7 on page 26.

→ Observe travel tables on page 28.

The positioner is mounted to the rotary actuator using two pairs of brackets.

Prior to attaching the positioner to the SAMSON Type 3278 Rotary Actuator, mount the associated adapter (5) to the free end of the rotary actuator shaft.

i Note

On attaching the positioner as described below, it is imperative that the actuator's direction of rotation is observed.

1. Place follower clamp (3) on the slotted actuator shaft or adapter (5).




Fig. 19: Attachment to Type 3510 Micro-flow Valve

Mounting and start-up

2. Place coupling wheel (4) with flat side facing the actuator on the follower clamp (3). Refer to Fig. 22 to align slot so that it matches the direction of rotation when the valve is in its closed position.
3. Fasten the coupling wheel (4) and follower clamp (3) tightly onto the actuator shaft using screw (4.1) and disk spring (4.2).
4. Fasten the bottom pair of brackets (10.1) with the bends pointing either facing to the inside or to the outside (depending on the actuator size) onto the actuator housing. Position the top pair of brackets (10) and fasten.
5. Mount connecting plate (6) or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals are seated properly. Double-acting springless rotary actuators require the use of a reversing amplifier on the connection side of the positioner housing (see Chapter 5.10).
6. Unscrew the standard follower pin (2) from the positioner's **M** lever (1). Use the metal follower pin (\varnothing 5 mm) included in the mounting kit and screw tight into the hole for pin position **90°**.
7. Place positioner on the top bracket (10) and fasten tight. Taking the actuator's direction of rotation into account, adjust lever (1) so that it engages in the slot of the coupling wheel (4) with its follower pin (Fig. 22). It must be guaranteed that the lever (1) is parallel to the long side of the positioner when the actuator is at half its angle of rotation.
8. Stick the scale plate (4.3) on the coupling wheel so that the arrow tip indicates the closed position and it can be easily read when the valve is installed.




Fig. 20: Mounting the coupling wheel on Type 3278

5.9.1 Heavy-duty version


→ Refer to Fig. 23

→ Required mounting parts and accessories: Table 7 on page 26.

Both mounting kits contain all the necessary mounting parts. The parts for the actuator size used must be selected from the mounting kit.

Prepare actuator and mount possibly required adapter supplied by the actuator manufacturer.

1. Mount the housing (10) onto the rotary actuator. In case of VDI/VDE attachment,



Mounting and start-up

place spacers (11) underneath, if necessary.

- For **SAMSON Type 3278 and VETEC S160 Rotary Actuators**, fasten the adapter (5) onto the free end of the shaft and for **VETEC R Actuator**, place on the adapter (5.1). For **Type 3278, VETEC S160 and VETEC R Actuators**, place on the adapter (3). or **VDI/VDE version**, only use the adapter when it is required due to the actuator size.
- Stick adhesive label (4.3) onto the coupling in such a manner that the yellow part of the sticker is visible in the window of the housing when the valve is OPEN. Adhesive labels with explanatory symbols are enclosed and can be stuck on the enclosure, if required.

- Fasten coupling wheel (4) on the slotted actuator shaft or adapter (3) using screw (4.1) and disk spring (4.2).
- Unscrew the standard follower pin (2) from the positioner's M lever (1). Attach the follower pin ($\varnothing 5$ mm) included in the mounting kit to pin position 90° .
- Mount connecting plate (6) for required $G \frac{1}{4}$ connecting thread or pressure gauge bracket (7) with pressure gauges on the positioner, making sure the two seals (6.1) are seated properly. Double-acting springless rotary actuators require the use of a reversing amplifier on the connection side of the positioner housing (see Chapter 5.10).
- For actuators with a volume of less than 300 cm^3 , screw the screw restriction (order no. 1400-6964) into the signal pressure output of the positioner (or the output of the pressure gauge bracket or connecting plate).
- Place positioner on housing (10) and screw it tight. Taking the actuator's direction of rotation into account, adjust lever (1) so that it engages in the correct slot with its follower pin (Fig. 22).




Fig. 22: Direction of rotation




Fig. 23: Attachment to rotary actuators (heavy-duty version)

5.10 Reversing amplifier for double-acting actuators

For the use with double-acting actuators, the positioner must be fitted with a reversing amplifier:

- SAMSON Type 3710 Reversing Amplifier, ► EB 8392
- If a different reversing amplifier (item no. 1079-1118 or 1079-1119) is used, mount it as described in Chapter 5.10.1.

The following applies to all reversing amplifiers:

The signal pressure of the positioner is supplied at the output 1 of the reversing amplifier. An opposing pressure, which equals the required supply pressure (Z) when added to the pressure at output 1, is applied at output 2.

The following relationship applies:

output 1 + output 2 = Supply pressure (Z).

Connect output 1 to the signal pressure connection on the actuator that causes the valve to open when the pressure rises.

Connect output 2 to the signal pressure connection on the actuator that causes the valve to close when the pressure rises.

- Set slide switch on positioner to AIR TO OPEN.

i Note

How the outputs are marked depends on the reversing amplifier used:

- **Type 3710:** Output 1/2 = Y_1/Y_2
 - **1079-1118 and 1079-1119:**
Output 1/2 = A_1/A_2
-

5.10.1 Reversing amplifier (1079-1118 or 1079-1119)

→ Refer to Fig. 24

1. Mount the connecting plate (6) from the accessories in Table 6 to the positioner. Make sure that both O-rings (6.1) are seated correctly.
2. Thread the special nuts (1.3) from the accessories of the reversing amplifier into the boreholes of the connecting plate.
3. Insert the gasket (1.2) into the recess of the reversing amplifier and slide both the hollowed special screws (1.1) into the connecting boreholes **A₁** and **Z**.
4. Place the reversing amplifier onto the connecting plate (6) and screw tight using both the special screws (1.1).
5. Use a screwdriver (8 mm wide) to screw the enclosed filters (1.6) into the connection boreholes **A₁** and **Z**.

! NOTICE

Air can escape uncontrolled from the signal pressure connection.

Do not unscrew the sealing plug (1.5) out of the reversing amplifier.

i Note

The rubber seal (1.4) is not required and can be removed when the sealing plug is used.

6. After initialization, set Code 16 (Pressure limit) to No.




Fig. 24: Mounting a reversing amplifier (1079-1118 or 1079-1119)

Mounting and start-up

Pressure gauge attachment

The mounting sequence shown in Fig. 24 remains unchanged. Screw a pressure gauge bracket onto the connections **A₁** and **Z**.

| | | |
|----------------|-------|-----------|
| Pressure gauge | G ¼ | 1400-7106 |
| bracket | ¼ NPT | 1400-7107 |

Pressure gauges for supply air Z and output A₁ as listed in Table 8 to Table 9.

5.11 Attachment of external position sensor



Fig. 25: Positioner unit with sensor mounted on a micro-flow valve

→ Required mounting parts and accessories: Table 8 on page 27.

In the positioner version with an external position sensor, the sensor located in a separate housing is attached over a plate or bracket to the control valve. The travel pick-off corresponds to that of a standard device. The positioner can be mounted as required to a wall or a pipe.

For the pneumatic connection either a connecting plate (6) or a pressure gauge bracket (7) must be fixed to the housing, depending on the accessory chosen. Make sure the seals (6.1) are correctly inserted (see Fig. 9, bottom right).

For the electrical connection a 10 meter connecting lead with M12x1 connectors is included in the scope of delivery.

i Note

- In addition, the instructions in Chapters 5.15 and 5.16 apply for the pneumatic and electrical connection.
- Since 2009, the back of the position sensor (20) is fitted with two pins acting as mechanical stops for the lever (1). If this position sensor is mounted using old mounting parts, two corresponding $\varnothing 8$ mm holes must be drilled into the mounting plate/bracket (21). A template is available for this purpose. See Table 8.

5.11.1 Mounting the position sensor with direct attachment

Type 3277-5 Actuator with 120 cm² (Fig. 6)

The signal pressure from the positioner is routed over the signal pressure connection of the connecting plate (9, Fig. 26 left) to the actuator diaphragm chamber. To proceed, first screw the connecting plate (9) included in the accessories onto the actuator yoke.

- Turn the connecting plate (9) so that the correct symbol for the fail-safe action "actuator stem extends" or "actuator stem retracts" is aligned with the marking (Fig. 27, below).
- Make absolutely sure that the gasket for the connecting plate (9) is correctly inserted.
- The connecting plate has threaded holes with NPT and G threads. Seal the threaded connection that is not used with the rubber seal and square plug.

Type 3277 Actuator with 175 to 750 cm²:

The signal pressure is routed to the connection at the side of the actuator yoke for the version with fail-safe action "actuator stem extends". For the fail-safe action "actuator stem retracts" the connection on the top diaphragm case is used. The connection at the side of the yoke must be fitted with a venting plug (accessories).

Mounting the position sensor

1. Place the lever (1) on the sensor in mid-position and hold it in place. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
2. Screw the position sensor (20) onto the mounting plate (21).
3. Depending on the actuator size and rated valve travel, determine which lever and position of the follower pin (2) is to be used from the travel table on page 28. The positioner is delivered with the **M** lever in pin position **35** on the sensor. If necessary, remove the follower pin (2) from its pin position and move it to the hole for the recommended pin position and screw tight.
4. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever **in mid-position** and **hold it in place**. Screw on the nut (1.1).
5. Place follower clamp (3) on the actuator stem, align it and screw tight so that the mounting screw is located in the groove of the actuator stem.

Mounting and start-up

6. Place the mounting plate together with the sensor onto the actuator yoke so that the follower pin (2) rests on the top of the follower clamp (3). It must rest on it with spring force. Fasten the mounting plate (21) onto the actuator yoke using both fixing screws.
7. Mount cover (11) on the other side. Make sure that the vent plug is located at the bottom when the control valve is installed to allow any condensed water that collects to drain off.




Fig. 26: Mounting for Type 3277-5 Actuator (left) and Type 3277 Actuator (right)

5.11.2 Mounting the position sensor with attachment according to IEC 60534-6


- Required mounting parts and accessories: Table 8 on page 27.
- Refer to Fig. 27

 1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
 2. Screw the position sensor (20) onto the bracket (21).

The standard attached **M** lever with the follower pin (2) at position **35** is designed for

120 to 350 cm² actuators with 15 mm rated travel. For other actuator sizes or travels, select the lever and pin position from the travel table on page 28. L and XL levers are included in the mounting kit.

3. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in **mid-position** and **hold it in place**. Screw on the nut (1.1).
4. Screw the two bolts (14) to the bracket (9.1) of the stem connector (9), place the follower plate (3) on top and use the screws (14.1) for fastening.
5. Place the bracket with the sensor at the NAMUR rib in such a manner that the follower pin (2) rests in the slot of the follower plate (3), then screw the bracket using its fixing screws onto the valve.



5.11.3 Mounting the position sensor to Type 3510 Micro-flow Valve

→ Required mounting parts and accessories: Table 8 on page 27.

→ Refer to Fig. 28

1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unscrew the nut (1.1) and remove the standard attached **M** lever (1) together with the disk spring (1.2) from the sensor shaft.

2. Screw the position sensor (20) onto the bracket (21).
3. Select the **S** lever (1) from the accessories and screw the follower pin (2) into the hole for pin position **17**. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever in mid-position and hold it in place. Screw on the nut (1.1).
4. Place follower clamp (3) on the valve stem connector, align at a right angle and screw tight.
5. Position the bracket (21) with the position sensor on the valve yoke and screw tight, making sure the follower pin (2) slides into the groove of the follower clamp (3).




Fig. 28: Mounting on a micro-flow valve

5.11.4 Mounting on rotary actuators

→ Required mounting parts and accessories: Table 8 on page 27.


→ Refer to Fig. 29

1. Place the lever (1) on the position sensor in **mid-position** and **hold it in place**. Unthread the nut (1.1) and remove the lever together with the disk spring (1.2) from the sensor shaft.
2. Screw the position sensor (20) onto the mounting plate (21).

3. Replace the follower pin (2) normally attached to the lever (1) with the metal follower pin (Ø 5 mm) from the accessories and screw it into the hole for pin position 90°.
4. Place the lever (1) and disk spring (1.2) on the sensor shaft. Place the lever **in mid-position** and **hold it in place**. Screw on the nut (1.1).

Follow the instructions describing attachment to the standard positioner in Chapter 5.9.

Instead of the positioner, attach the position sensor (20) with its mounting plate (21).



- | | |
|-----|-----------------|
| 1 | Lever |
| 1.1 | Nut |
| 1.2 | Disk spring |
| 2 | Follower pin |
| 20 | Position sensor |
| 21 | Mounting plate |

5.12 Mounting the leakage sensor

→ Refer to Fig. 30

Normally, the control valve is delivered with positioner and leakage sensor already mounted.

If the leakage sensor is mounted after the valve has been installed or it is mounted onto another control valve, proceed as described in the following.

! NOTICE


Risk of malfunction due to incorrect fastening. Fasten the leakage sensor using a torque of 20 ± 5 Nm.

The M8 threaded connection on the NAMUR rib should preferably be used to mount the sensor (Fig. 30).

💡 Tip

If the positioner was mounted directly onto the actuator (integral attachment), the NAMUR interfaces on either side of the valve yoke can be used to mount the leakage sensor.

The start-up of the leakage sensor is described in detail in the Operating Instructions for EXPERTplus Valve Diagnostics.



5.13 Retrofitting an inductive limit switch

Required retrofit kit:

Limit switch Order no. 1402-1770

i Note

The same requirements apply to retrofitting a unit as to servicing the positioner. For explosion-protected positioners, the requirements in Servicing explosion-protected devices need to be kept. Check the "Limit switch, inductive" box on the nameplate after installing the limit switch.

1. Take off the rotary pushbutton (3) and cap (1), unthread the five fastening screws (2) and lift off the plastic cover (9) together with the display, taking care not to damage the ribbon cable (between PCB and display).
2. Use a knife to cut an opening at the marked location (4).
3. Push the connector (11) with cable through the opening and secure the proximity switch (7) on the cover with a dot of glue.
4. If necessary, remove the jumper at the socket X9 and push the cable connector (11) on the socket.
5. Guide the cable in such a manner that the plastic cover can be placed back onto the positioner. Insert the fixing screws (2) and screw tight. Attach the clamping plate (8) onto the proximity switch.
6. Attach the rotary switch (5). Make sure the flattened side of the positioner shaft is

turned so that the rotary switch (5) can be attached with the metal tag next to the proximity switch.

7. On start-up of the positioner, set the option inductive alarm under Code 38 from No to YES.




Fig. 31: Retrofitting an inductive limit switch

5.14 Attaching positioners with stainless steel housings

Positioners with stainless steel housings require mounting parts that are completely made of stainless steel or free of aluminum.

i Note

The pneumatic connecting plate and pressure gauge bracket are available in stainless steel (order numbers listed below). The Type 3710 Pneumatic Reversing Amplifier is also available in stainless steel.

| | | |
|--|--------------|------------------------|
| Connecting plate (stainless steel) | G ¼ ¼ NPT | 1400-7476 1400-7477 |
| Pressure gauge bracket (stainless steel) | G ¼ ¼ NPT | 1402-0265 1400-7108 |

Table 7 to Table 9 apply for attaching positioners with stainless steel housings with the following restrictions:

Direct attachment

All mounting kits from Table 2 and Table 3 can be used. The connection block is not required. The stainless steel version of the pneumatic connecting plate routes the air internally to the actuator.

Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes)

All mounting kits from Table 4 can be used. Connecting plate in stainless steel.

Attachment to rotary actuators

All mounting kits from Table 7 can be used except for the heavy-duty version. Connecting plate in stainless steel.

5.15 Air purging function for single-acting actuators

The instrument air leaving the positioner is diverted to the actuator spring chamber to provide corrosion protection inside the actuator. Observe the following:

Direct attachment to Type 3277-5 (stem extends FA/stem retracts FE)

The air purging function is automatically provided.

Direct attachment to Type 3277, 175 to 750 cm²

FA: Remove the stopper (12.2, Fig. 7) at the black connection block and make a pneumatic connection to the spring chamber on the vented side.

! NOTICE

Mounting possibly incorrect when old powder-paint-coated aluminum connection blocks are used. Mount old powder-paint-coated aluminum connection blocks as described in sections on Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes) and Attachment to rotary actuators.

FE: The air purging function is automatically provided.

Attachment according to IEC 60534-6 (NAMUR rib or attachment to rod-type yokes) and to rotary actuators

The positioner requires an additional port for the exhaust air that can be connected over piping. An adapter available as an accessory is used for this purpose:

| | | |
|------------------|-------|-----------|
| Threaded bushing | G ¼ | 0310-2619 |
| (M20x1.5) | ¼ NPT | 0310-2550 |

i Note

*The adapter uses one of the M20x1.5 connections in the housing which means **only one** cable gland can be installed.*

Should other valve accessories be used which vent the actuator (e.g. solenoid valve, volume booster, quick exhaust valve), this exhaust air must also be included in the purging function. The connection over the adapter at the positioner must be protected with a check valve (e.g. check valve G ¼, order no. 8502-0597) mounted in the piping. Otherwise the pressure in the positioner housing would rise above the ambient pressure and damage the positioner when the exhausting components respond suddenly.

5.15 Pneumatic connections

⚠ WARNING

Risk of injury by possible movement of exposed parts (positioner, actuator or valve) after connecting the signal pressure.
Do not touch or block exposed moving parts.

📌 NOTICE

Incorrect connection of the supply air will damage the positioner and will lead to malfunction.

Screw the screw fittings into the connecting plate, pressure gauge mounting block or connection block from the accessories.

The pneumatic ports are located on the back of the positioner (see Fig. 32).

📌 NOTICE

Risk of malfunction due to failure to comply with required air quality.

Only use supply air that is dry and free of oil and dust.

Read the maintenance instructions for upstream pressure reducing stations.

Blow through all air pipes and hoses thoroughly before connecting them.




Fig. 32: Pneumatic connections

5.15.1 Connecting the supply air

📌 NOTICE

Risk of malfunction due to incorrect sequence of mounting, installation and start-up.

Keep the following sequence.

1. Remove the protective caps from the pneumatic connections.
2. Mount the positioner on the valve.
3. Connect the supply air.
4. Connect the electrical power.
5. Perform settings.

Mounting and start-up

The pneumatic connections in the connecting plate, pressure gauge mounting block and connection block are optionally designed as a bore with ¼ NPT or G ¼ thread. Customary fittings for metal or copper tubing or plastic hoses can be used.

Signal pressure connection

The signal pressure connection depends on how the positioner is mounted onto the actuator:

- **Type 3277 Actuator**
The signal pressure connection is fixed.
- **Attachment according to IEC 60534-6 (NAMUR)**
For "actuator stem retracts" fail-safe action: connect the signal pressure to the connection on top of the actuator.
For "actuator stem extends" fail-safe action: connect the signal pressure to the connection on the bottom of the actuator.
- **Rotary actuators**
For rotary actuators, the manufacturer's specifications for connection apply.

5.15.2 Signal pressure gauges



Tip

To monitor the supply air and signal pressure, we recommend mounting pressure gauges (see accessories in Chapter 3.6).

Mounting the pressure gauges:

- See Chapter 5.5 and Fig. 8

5.15.3 Supply pressure

The required supply air pressure depends on the bench range and the actuator's direction of action (fail-safe action).

The bench range is written on the nameplate either as the bench range or signal pressure range depending on the actuator. The direction of action is marked FA or FE or by a symbol.

Actuator stem extends FA (AIR TO OPEN)

Fail-close (for globe and angle valves):

- Required supply pressure = Upper bench range value + 0.2 bar, at least 1.4 bar.

Actuator stem retracts FE (AIR TO CLOSE)

Fail-open (for globe and angle valves):

For tight-closing valves, the maximum signal pressure $p_{st_{max}}$ is roughly estimated as follows:

$$p_{st_{max}} = F + \frac{d^2 \cdot \pi \cdot \Delta p}{4 \cdot A} \text{ [bar]}$$

d = Seat diameter [cm]

Δp = Differential pressure across the valve [bar]

A = Actuator area [cm²]

F = Upper bench range value of the actuator [bar]

If there are no specifications, calculate as follows:

- Required supply pressure = Upper bench range value + 1 bar

5.15.4 Signal pressure (output)

The signal pressure at the output (38) of the positioner can be restricted to 1.4 bar, 2.4 bar or 3.7 bar in Code 16. The limitation is not activated [No] by default.

5.16 Electrical connections

For electrical installation, observe the relevant electrotechnical regulations and the accident prevention regulations that apply in the country of use. In Germany, these are the VDE regulations and the accident prevention regulations of the employers' liability insurance.

⚠ DANGER

Risk of fatal injury due to the formation of an explosive atmosphere.

The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1) Explosive Atmospheres – Electrical Installations Design, Selection and Erection.

⚠ WARNING

Incorrect electrical connection will render the explosion protection unsafe.

- *Adhere to the terminal assignment.*
- *Do not undo the enameled screws in or on the housing.*
- *Do not exceed the maximum permissible values specified in the EC type examination certificates when interconnecting intrinsically safe electrical equipment (U_i or U_{0r} , I_i or I_{0r} , P_i or P_{0r} , C_i or C_0 and L_i or L_0).*

Selecting cables and wires

Observe **clause 12 of EN 60079-14: 2008** (VDE 0165, Part 1) for installation of the intrinsically safe circuits.

Clause 12.2.2.7 applies when running multi-core cables and wires with more than one intrinsically safe circuit.

The radial thickness of the insulation of a conductor for common insulating materials (e.g. polyethylene) must not be smaller than 0.2 mm. The diameter of an individual wire in a fine-stranded conductor must not be smaller than 0.1 mm. Protect the conductor ends against splicing, e.g. by using wire-end ferrules. When two separate cables or wires are used for connection, an additional cable gland can be installed. Seal cable entries left unused with plugs. Fit equipment used in ambient temperatures **below -20 °C** with metal cable entries.

Equipment for use in zone 2/zone 22

In equipment operated according to type of protection Ex nA II (non-sparking equipment)

Mounting and start-up

according to EN 60079-15: 2003, circuits may be connected, interrupted or switched while energized only during installation, maintenance or repair.

Equipment connected to energy-limited circuits with type of protection Ex nL (energy-limited equipment) according to EN 60079-15: 2003 may be switched under normal operating conditions.

The maximum permissible values specified in the statement of conformity and its addenda apply when interconnecting the equipment with energy-limited circuits in type of protection Ex nL IIC.

Cable entry

Cable entry with M20x1.5 cable gland. See section on Accessories for clamping range. There is a second M20x1.5 threaded hole in the housing that can be used for additional connection, when required.

The screw terminals are designed for wire cross-sections of 0.2 to 2.5 mm². Tighten the screws by 0.5 to 0.6 Nm.

i Note

The power supply for the positioner can be supplied either over the connection to the fieldbus segment or over a DC voltage source (9 to 32 V) connected to the bus terminals in the positioner.

Observe the relevant regulations for installation in hazardous areas.

Accessories

| Cable glands M20x1.5 | Order no. |
|--|-----------|
| Black plastic (6 to 12 mm clamping range) | 8808-1011 |
| Blue plastic (6 to 12 mm clamping range) | 8808-1012 |
| Nickel-plated brass (6 to 12 mm clamping range) | 1890-4875 |




Fig. 33: Electrical connections

| | |
|---|-----------|
| Nickel-plated brass (10 to 14 mm clamping range) | 1922-8395 |
| Stainless steel 1.4305 (8 to 14.5 mm clamping range) | 8808-0160 |

EMC cable gland M20x1.5:

| | |
|--|-----------|
| Nickel-plated brass (7 to 12 mm clamping range) | 8808-0143 |
|--|-----------|

Adapter M20x1.5 to ½ NPT

| | |
|------------------------|-----------|
| Powder-coated aluminum | 0310-2149 |
| Stainless steel | 1400-7114 |

Bus line

Route the two-wire bus line to the screw terminals marked "IEC 1158-2", whereby no polarity needs to be observed.

To connect the limit switch, binary inputs and forced venting, an additional cable gland that needs to be fitted in place of the existing blanking plug is necessary.

NOTICE

Degree of protection may be impaired.

Do not use the positioner with open cable glands.

Seal cable glands left unused with blanking plugs.

Limit switch

The operation of the limit switch requires a switching amplifier to be connected in the output circuit. Its function is to control the limit values of the control circuit according to EN 60947-5-6, thus ensuring operational reliability of the positioner.

Observe the relevant regulations for installation in hazardous areas.

Binary input BI1

An active contact can be operated at binary input 1. The positioner can report the switching state over the bus protocol.

Binary input BI2

A passive, floating contact can be operated at binary input 2. The positioner can report the switching state over the bus protocol.

Solenoid valve

For positioners fitted with the optional solenoid valve for the forced venting function, a voltage of 24 V DC must be connected to the relevant terminals +81 and -82.

If there is no voltage connected for the solenoid valve at terminals +81 and -82 or when the voltage signal is interrupted, the positioner vents the actuator.

NOTICE

The actuator does not respond to the set point when the voltage is too low.

Observe the switching thresholds specified in the technical data.

5.16.1 Establishing communication

The communication structure between the controller, logic solvers (PLC) or automation system or between a computer or work station and the positioner(s) is implemented to conform with IEC 61158-2.

i Note

The action of the positioner upon failure of the FOUNDATION™ fieldbus communication can be determined over the bus parameters or over the SAMSON TROVIS-VIEW software:

- The valve remains in its last position.
- The valve moves to the fail-safe position.
- The valve moves to a defined fault state value.

Bus parameters: ► KH 8384-5

- FEATURES_SEL (RES) > FAULTSTATE
- XD_FSTATE_OPT (AO TRD): Action on fault detection
- XD_FSTATE_VAL (AO FB): Fail-safe value

TROVIS-VIEW:

The parameters can be found in the folder [Settings > Positioner (AO, TRD) > Fail-safe action].

The action selected only takes effect if the positioner is powered. Should a power failure occur at the same time, the actuator is vented and the valve moves to the fail-safe position.




Fig. 34: Connection acc. to FOUNDATION™ fieldbus, for safe areas (top) and for hazardous areas (bottom)

6 Operation

⊗ Rotary pushbutton

The rotary pushbutton is located underneath the front protective cover. The positioner is operated on site using the rotary pushbutton:

Turn ⊗: Select codes and values

Press ⊗: confirm setting.

AIR TO OPEN/AIR TO CLOSE slide switch

- AIR TO OPEN applies to a valve opening as the signal pressure increases.
- AIR TO CLOSE applies to a valve closing as the signal pressure increases.

The signal pressure is the pneumatic pressure at the output of the positioner applied to the actuator.

Volume restriction Q

The volume restriction serves to adapt the air output capacity to the size of the actuator. Depending on the air passage at the actuator, two fixed settings are available.

- For actuators smaller than 240 cm² and with a signal pressure connection at the side (Type 3271-5), set restriction to MIN SIDE.
- For a connection at the back (Type 3277-5), set restriction to MIN BACK.
- For actuators 240 cm² and larger, set to MAX SIDE for a side connection and to MAX BACK for a connection at the back.




Fig. 35: Operating controls







Fig. 36: Display



Readings


Icons assigned to certain codes, parameters and functions are indicated on the display.

Operating modes:

-  **(manual mode)**
The positioner follows the manual set point (Code 1) instead of the set point of the process control system.
 blinks: The positioner is not initialized. Operation only possible over manual set point (Code 1).
-  **(automatic mode)**
The positioner is in closed-loop operation and follows the set point of the process control system.
- **S SAFE**
The positioner vents the output. The valve moves to the mechanical fail-safe position.



Bar graph:

In manual  and automatic  modes, the bars indicate the set point deviation that depends on the sign (+/-) and the value. One bar element appears per 1 % set point deviation.

If the positioner has not been initialized, ( blinks on the display), the bar graph indicates the lever position in degrees in relation to the mid-axis. One bar element corresponds to approximately a 5° angle of rotation. The fifth bar element blinks (reading > 30°) if the permissible angle of rotation has

been exceeded. Lever and pin position must be checked.

Status messages

-  Maintenance alarm
-  Maintenance demanded/Maintenance required

These icons indicate that an error has occurred.

A classified status can be assigned to each error. Classifications include “No message”, “Maintenance required”, “Maintenance demanded” and “Maintenance alarm” (see ► EB 8389 on EXPERTplus valve diagnostics).

⇨ Enable configuration

This indicates that the codes marked with an asterisk (*) in the code list are enabled for configuration (see Chapter 11.8).

7 Operating the positioner

NOTICE



Risk of malfunction due to incorrect sequence of mounting, installation and start-up.

Keep the following sequence.

1. Remove the protective caps from the pneumatic connections.
2. Mount the positioner on the valve.
3. Connect the supply air.
4. Connect the electrical power.
5. Perform settings.

Reading after connecting the electrical power supply:



After *tESinG* runs across the display, the  fault alarm icon appears and the  hand icon blinks on the display when the **positioner has not been initialized**. The reading indicates the lever position in degrees in relation to the mid-axis.

Code 0 is displayed when a **positioner has been initialized**. The positioner is in the last active operating mode.

The positioner performs a test in the start-up phase while following its automation task at the same time.

WARNING

Risk of injury due to the actuator stem extending or retracting.

Do not touch or block the actuator stem.

During the start-up phase, operation on site is unrestricted, yet write access is limited.

7.1 Determining the fail-safe position

Define the fail-safe position of the valve taking the valve type and the actuator's direction of action into account. Position the AIR TO OPEN/AIR TO CLOSE slide switch accordingly:


- **AIR TO OPEN** setting
Signal pressure opens the valve, e.g. for a fail-close valve
The AIR TO OPEN setting always applies to double-acting actuators.
- **AIR TO CLOSE** setting
Signal pressure closes the valve, e.g. for a fail-open valve

For checking purposes: After successfully completing initialization, the positioner display must read 0 % when the valve is closed and 100 % when the valve is open. If this is not the case, change the slide switch position and re-initialize the positioner.

i Note

The switch position is prompted prior to an initialization. After an initialization has been completed, changing the switch position does not have any effect on the operation of the positioner.

7.2 Adjusting the volume restriction Q



| Signal pressure | Transit time | |
|------------------------|--------------|----------|
| | <1 s | ≥1 s |
| Connection at the side | MIN SIDE | MAX SIDE |
| Connection at the back | MIN BACK | MAX BACK |

* Intermediate settings are not permitted.

Fig. 37: Volume restriction Q

The volume restriction Q serves to adapt the air output capacity to the size of the actuator:

- Actuators with a **transit time <1 s**, e.g. linear actuators with an effective area smaller than 240 cm², require a restricted air flow rate (MIN).
- Actuators with a **transit time ≥1 s** do not require the air flow rate to be restricted (MAX).

The position of volume restriction Q also depends on how the signal pressure is routed at the actuator in **SAMSON actuators**:

'SIDE' inscription

- For actuators with a signal pressure connection at the side, e.g. Type 3271-5
- For actuators from other manufacturers

'BACK' inscription

- For actuators with a signal pressure connection at the back, e.g. Type 3277-5





NOTICE

Malfunction due to changed start-up settings.

Initialize an initialized positioner again after the position of the volume restriction has been changed.


7.3 Adapting the display direction

The display contents can be turned by 180° to adapt the display reading to the actuator's mounting situation. If the displayed data appear upside down, proceed as follows:

1. Turn  until Code 2 appears.
2. Press , the code number 2 blinks.
3. Turn  and select the desired reading direction.
4. Press  to confirm.



Reading direction for right attachment of pneumatic connections



Reading direction for left attachment of pneumatic connections

7.4 Limiting the signal pressure

If the maximum actuator force may cause damage to the valve, the signal pressure must be limited.






- ➔ Do not activate pressure limitation for double-acting actuators (AIR TO OPEN (AIO) fail-safe position). Default setting is 'No'.


Enable configuration at the positioner before limiting the signal pressure.

Operating the positioner

Enable configuration:





Configuration is locked again if no settings are entered within 120 s.


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration
Default: No


Limit the signal pressure:

1. Turn  until Code 16 appears.
2. Press , the code number 16 blinks.
3. Turn  until the required pressure limit (1.4/2.4/3.7 bar) appears.
4. Press  to confirm.








Pressure limit
Default: No

7.5 Checking the operating range of the positioner

To check the mechanical attachment and the proper functioning, the valve should be moved through the operating range of the positioner in the  manual mode with the manual set point.


Select manual mode ():

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until MAN appears.
4. Press . The positioner changes to the manual mode ().



Operating mode
Default: MAN

Check the operating range:

5. Turn ⊗ until Code 1 appears.
6. Press ⊗, the code number 1 and  icon blink.
7. Turn ⊗ until the pressure in the positioner builds up and the control valve moves to its final positions so that the travel/angle can be checked.



Manual set point w
(current angle of
rotation is indicated)

The angle of rotation of the lever on the back of the positioner is indicated.

A horizontal lever (mid position) is equal to 0°.

To ensure the positioner is working properly, the outer bar elements must not blink while the valve is moving through the operating range.

Exit Code 1 by pressing the rotary pushbutton (⊗).

The permissible range has been exceeded when the displayed angle is more than 30° and the outer right or left bar element blinks. The positioner goes to the fail-safe position (SAFE). After canceling the fail-safe position (SAFE) (see Chapter 7.11.2) it is absolutely essential that you check the lever and pin position as described in Chapter 5.

⚠ WARNING

Risk of injury due to the actuator stem extending or retracting.

Before exchanging the lever or changing the pin position, disconnect the supply air and electrical auxiliary power.

7.6 Initializing the positioner

⚠ WARNING

Risk of injury by exposed moving parts on the positioner, actuator or valve.

Do not touch or block exposed moving parts.

NOTICE

The process is disturbed by the movement of the actuator or valve.

Do not perform the initialization while the process is running. First isolate the plant by closing the shut-off valves.

- Check the max. permissible signal pressure of the valve before starting initialization. During initialization, the positioner issues an output signal pressure up to the maximum supply pressure supplied. If necessary, limit the signal pressure by connecting an upstream pressure reducing valve.
-

Note

Reset positioner to its default settings (see Chapter 7.9) before mounting it on a different actuator or changing its mounting position.

During initialization the positioner adapts itself optimally to the friction conditions and the signal pressure required by the control valve. The type and extent of auto tuning depends on the initialization mode selected:


- **Maximum range (MAX)** (standard range)
Initialization mode for simple start-up of valves with two clearly defined mechanical end positions, e.g. three-way valves (see Chapter 7.6.1)
- **Nominal range (NOM)**
Initialization mode for all globe valves (see Chapter 7.6.2)
- **Manually selected range (MAN)**
Initialization mode for globe valves with an unknown nominal range (see Chapter 7.6.3)
- **Substitute calibration (SUB)**
This mode allows a positioner to be replaced while the plant is running, with the least amount of disruption to the plant (see Chapter 7.6.4).

For normal operation, simply start initialization by pressing the INIT key after mounting the positioner on the valve and defining the fail-safe position and setting the volume restriction. The positioner only needs to work with its default settings. If necessary, perform a reset (see Chapter 7.9).

i Note

An initialization procedure in progress can be canceled by pressing the rotary pushbutton. STOP is displayed for three seconds and the positioner changes to the fail-safe position (SAFE). Clear the fail-safe position again over Code 0 (see Chapter 7.11.2).

The time required for the initialization procedure depends on the actuator transit time, which means that initialization can take a few minutes.

After a successful initialization, the positioner runs in closed-loop operation indicated by the  closed-loop operation icon.

A malfunction leads to the process being canceled. The initialization error is displayed according to how it has been classified by the condensed state. Refer to Chapter 9.




Alternating readings
Initialization in progress
Icon depending on
initialization mode
selected



Bar graph display
indicating the progress
of the initialization



Initialization successfully
completed. Positioner in
automatic mode ()

i Note

When Code 48 - h0 = YES, the diagnostics automatically start to plot the reference graphs (drive signal steady-state d1 and hysteresis d2) after initialization has been completed. This is indicated by tES1 and d1 or d2 appearing on the display in alternating sequence. An error during the plotting of the reference graphs is indicated on the display over Code 48 - h1 and Code 81. The reference graphs do not have any effect on closed-loop operation.

Operating the positioner

Fail-safe action AIR TO CLOSE

If the slide switch is set to AIR TO CLOSE, the positioner automatically switches to the direction of action increasing/decreasing (↗↘) after initialization has been completed. This results in the assignment (left) between set point and valve position.

The tight-closing function is activated.

Set Code 15 (set point cutoff increase) to 99 % **for three-way valves**.






| Fail-safe position | Direction of action | Set point Valve | |
|---|---------------------|-----------------|---------|
| | | CLOSED at | OPEN at |
| Actuator stem extends (FA) AIR TO OPEN | ↗↗ | 0 % | 100 % |
| Actuator stem retracts (FE) AIR TO CLOSE | ↗↘ | 100 % | 0 % |


7.6.1 MAX – Initialization based on maximum range

The positioner determines travel/angle of rotation of the closing member from the CLOSED position to the opposite travel stop and adopts this travel/angle of rotation as the operating range from 0 to 100 %.

Enable configuration:





Configuration is locked again if no settings are entered within 120 s.


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration
Default: No

Select the initialization mode:

1. Turn  until Code 6 appears.
2. Press , the code number 6 blinks.
3. Turn  until MAX appears.
4. Press  to confirm the MAX initialization mode.



Default: MAX





Start initialization:

→ Press INIT key.

The rated travel/angle of rotation is indicated in % after initialization. Code 5 (nominal range) remains locked. The parameters for travel/angle range start (Code 8) and travel/angle range end (Code 9) can also only be displayed and modified in %.

For a reading in mm/°, enter the pin position (Code 4).

Enter the pin position:

1. Turn  until Code 4 appears.
2. Press , the code number 4 blinks.
3. Turn  to select pin position on lever (see relevant section on attachment).
4. Press  to confirm.



Pin position
Default: No

The nominal range is displayed in mm/°.

7.6.2 NOM – Initialization based on nominal range

The calibrated sensor allows the effective valve travel to be set very accurately. During initialization, the positioner checks whether the control valve can move through the indicated nominal range (travel or angle) without collision. If this is the case, the indicated nominal range is adopted with the limits of travel/angle range start (Code 8) and travel/angle range end (Code 9) as the operating range.






i Note

The maximum possible travel must always be greater than the rated travel entered. If this is not the case, initialization is automatically canceled (error message Code 52) because the rated travel could not be achieved.

Enable configuration:

Configuration is locked again if no settings are entered within 120 s.









Operating the positioner


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration
Default: No

Enter the pin position and nominal range:

1. Turn  until Code 4 appears.
2. Press , the code number 4 blinks.
3. Turn  to select pin position on lever (see relevant section on attachment).
4. Press  to confirm.
5. Turn  until Code 5 appears.
6. Press , the code number 5 blinks.
7. Turn  and set rated travel of the valve.
8. Press  to confirm.








Pin position
Default: No



Nominal range
(locked when Code 4 =
No)

Select the initialization mode:

1. Turn  until Code 6 appears.
2. Press , the code number 6 blinks.
3. Turn  until NOM appears.
4. Press  to confirm the NOM initialization mode.



Init mode
Default: MAX

Start initialization:

- Press INIT key.
- After the initialization has been successfully completed:
Check the direction of action (Code 7) and, if necessary, change it.


7.6.3 MAN – Initialization based on a manually selected range

Before starting initialization, move the control valve manually to the OPEN position. Turn the rotary pushbutton (⊗) clockwise in small steps. The valve must be moved with a monotonically increasing signal pressure. The positioner calculates the differential travel/angle from the OPEN and CLOSED positions and adopts it as the operating range with limits of lower travel/angle range value (Code 8) and upper travel/angle range value (Code 9).

Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn ⊗ until Code 3 appears (reading: No).
2. Press ⊗, the code number 3 blinks.
3. Turn ⊗ until YES appears.
4. Press ⊗ to confirm (reading: ↵).



Enable configuration
Default: No

Enter the pin position:

1. Turn ⊗ until Code 4 appears.
2. Press ⊗, the code number 4 blinks.
3. Turn ⊗ to select pin position on lever (see relevant section on attachment).
4. Press ⊗ to confirm.



Pin position
Default: No

Select the initialization mode:









1. Turn ⊗ until Code 6 appears.
2. Press ⊗, the code number 6 blinks.
3. Turn ⊗ until MAN appears.
4. Press ⊗ to confirm the MAN initialization mode.



Init mode
Default: MAX

Operating the positioner

Enter OPEN position:

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until MAN appears.
4. Press  to confirm.
5. Turn  until Code 1 appears.
6. Press , the code number 1 blinks.
7. Turn  until the valve reaches its OPEN position.
8. Press  to confirm the OPEN position.



Manual set point
(current angle of rotation is indicated)

Start initialization:

- Press INIT key.

7.6.4 Sub – Substitute calibration

A complete initialization procedure takes several minutes and requires the valve to move through its entire travel range several times. In the SUB initialization mode, the control parameters are estimated and not determined by an initialization procedure. As a result, a high level of accuracy cannot be expected. A different initialization mode should be selected if the plant allows it.

The substitute calibration is used to replace a positioner while the process is running. For this purpose, the control valve is usually fixed mechanically in a certain position or pneumatically by means of a pressure signal which is routed to the actuator externally. The blocking position ensures that the plant continues to operate with this valve position.

By entering the blocking position (Code 35), closing direction (Code 34), pin position (Code 4), nominal range (Code 5) and direction of action (Code 7), the positioner can calculate the positioner configuration.


NOTICE

Perform a reset before re-initializing the positioner if the substitute positioner has already been initialized. Refer to Chapter 7.9.

Enable configuration:

Configuration is locked again if no settings are entered within 120 s.

1. Turn ⊗ until Code 3 appears (reading: No).
2. Press ⊗, the code number 3 blinks.
3. Turn ⊗ until YES appears.
4. Press ⊗ to confirm (reading: →).



Enable configuration
Default: No

Enter the pin position and nominal range:

1. Turn ⊗ until Code 4 appears.
2. Press ⊗, the code number 4 blinks.
3. Turn ⊗ to select pin position on lever (see relevant section on attachment).
4. Press ⊗ to confirm.
5. Turn ⊗ until Code 5 appears.
6. Press ⊗, the code number 5 blinks.
7. Turn ⊗ and set rated travel of the valve.
8. Press ⊗ to confirm.




Pin position
Default: No



Nominal range
(locked when Code 4 = No)

Select the initialization mode:





1. Turn ⊗ until Code 6 appears.
2. Press ⊗, the code number 6 blinks.
3. Turn ⊗ until SUB appears.
4. Press ⊗ to confirm the SUB initialization mode.



Init mode
Default: MAX

Operating the positioner





Enter the direction of action:


1. Turn  until Code 7 appears.
2. Press , the code number 7 blinks.
3. Turn  to select the direction of action (↖/↗).
4. Press  to confirm.



Direction of action
Default: ↖↗

Deactivate travel limit:

1. Turn  until Code 11 appears.
2. Press , the code number 11 blinks.
3. Turn  until No appears.
4. Press  to deactivate the travel limit function.








Travel limitation
Default: No

Change pressure limit and control parameters:

Note

Do not change the pressure limit (Code 16). Only change the control parameters K_p (Code 17) and T_V (Code 18) if the settings of the replaced positioner are known.

1. Turn  until the required Code 16/17/18 appears.
2. Press , the code number 16/17/18 blinks.
3. Turn  to set the control parameter selected.
4. Press  to confirm.



Pressure limit
Default: No










K_p level
Default: 7




T_v level
Default: 2

Enter closing direction and blocking position:

1. Turn  until Code 34 appears.
2. Press , the code number 34 blinks.
3. Turn  and set the closing direction (CCL = counterclockwise/CL = clockwise).
4. Press , to confirm.
5. Turn  until Code 35 appears.
6. Press , the code number 35 blinks.
7. Turn  to set the blocking position, e.g. 5 mm (read off at travel indicator scale of the blocked valve or measure with a ruler).
8. Set switch for fail-safe position AIR TO OPEN or AIR TO CLOSE according to Chapter 7.1.
9. Adjust volume restriction as described in Chapter 7.2.



Closing direction
(direction of rotation causing the valve to move to the CLOSED position (view onto positioner display)
Default: CCL (counterclockwise)



Blocking position
Default: 0

Operating the positioner










Start initialization:

- Press INIT key.
The positioner switches to MAN mode.
The blocking position is indicated.

Since initialization has not been completed, the error code 76 (no emergency mode) and possibly also error code 57 (control loop) may appear on the display. These alarms do not influence the positioner's readiness for operation.

Cancel the blocking position and change to automatic mode (AUTO):

For the positioner to follow its set point again, the blocking position must be canceled and the positioner must be set to automatic mode as follows:

1. Turn  until Code 1 appears.
2. Press , the code number 1 and  icon blink.
3. Turn  to build up pressure in the positioner to move the valve slightly past the blocking position.
4. Press  to cancel the mechanical blocking.
5. Turn  until Code 0 appears.
6. Press , the code number 0 blinks.
7. Turn  until *AUTO* appears.
8. Press  to confirm. The positioner switches to automatic mode. The current valve position is indicated in %.

- If the positioner shows a tendency to oscillate in automatic mode, the parameters K_p and T_v must be slightly corrected. Proceed as follows:
 - Set T_v (Code 18) to 4.
 - If the positioner still oscillates, the gain K_p (Code 17) must be decreased until the positioner shows a stable behavior.

Zero point calibration

- Finally, if process operations allow it, the zero point must be calibrated according to Chapter 7.7.

7.7 Zero calibration

In case of inconsistencies in the closed position of the valve, e.g. with soft-seated plugs, it might be necessary to recalibrate zero.

⚠ WARNING

Risk of injury due to the actuator stem extending or retracting.
Do not touch or block the actuator stem.






ⓘ NOTICE


The process is disturbed by the movement of the actuator stem.
Do not perform zero calibration while the process is running. First isolate the plant by closing the shut-off valves.

The positioner must be connected to the supply air to perform the zero calibration.

Enable configuration:




Configuration is locked again if no settings are entered within 120 s.


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration
Default: No

Perform zero calibration:

1. Turn  until Code 6 appears.
 2. Press , the code number 6 blinks.
 3. Turn  until ZP appears.
- ➔ Press INIT key.
Zero calibration starts. The positioner moves the valve to the CLOSED position and recalibrates the internal electrical zero point.



Init mode
Default: MAX

7.8 Adjusting the inductive limit switch

The positioner version with an inductive limit switch has an adjustable tag (1) mounted on the axis of rotation, which operates the proximity switch (3).

For operation of the inductive limit switch, the corresponding switching amplifier (see Chapter 5.16) must be connected to the output circuit.

When the tag (1) is located in the inductive field of the switch, the switch assumes a high resistance. When it moves outside the field, the switch assumes a low resistance.

Normally, the limit switch is adjusted in such a way that it will provide a signal in both end positions of the valve. The switch, however, can also be adjusted to indicate intermediate valve positions.

The required switching function, i.e. whether the output relay is to be picked up or released when the tag enters the field, must be selected at the switching amplifier, if required.

Adjusting the switching point

i Note

During adjustment or testing, the switching point must always be approached from mid-position (50 %).

To guarantee the switching under all ambient conditions, adjust the switching point approx. 5 % before the mechanical stop (OPEN – CLOSED).

For CLOSED position:

1. Initialize the positioner.
2. Move the valve to 5 % in the MAN mode (see display).
3. Adjust the tag at the yellow adjustment screw (2) until the tag enters or leaves the field and the switching amplifier responds.
You can measure the switching voltage as an indicator.

Contact function:

- Tag leaving the field > contact is closed.
- Tag entering the field > contact is opened.

For OPEN position:

1. Initialize the positioner.
2. Move the valve to 95 % in the MAN mode (see display).
3. Adjust the tag (1) at the yellow adjustment screw (2) until the tag enters or leaves the field of the proximity switch (3).
You can measure the switching voltage as an indicator.

Contact function:

- Tag leaving the field > contact is closed.
- Tag entering the field > contact is opened.









Fig. 38: *Adjusting the limit switch*


7.9 Reset to default settings

This function resets all start-up and setting parameters as well as the diagnosis to the factory default settings (see code list in Chapter 11.8).

Enable configuration:






Configuration is locked again if no settings are entered within 120 s.


1. Turn  until Code 3 appears (reading: No).
2. Press , the code number 3 blinks.
3. Turn  until YES appears.
4. Press  to confirm (reading: ).



Enable configuration
Default: No

Reset start-up parameters:

1. Turn  until Code 36 appears (reading: ).
2. Press , the code number 36 blinks.
3. Turn  until *Std* appears.
4. Press  to confirm. All start-up parameters as well as the diagnosis are reset to their default values.



Reset
Default: No

Note

Code 36 - diAG allows just the diagnosis data (EXPERTplus) to be reset. Refer to the Operating Instructions for EXPERTplus valve diagnostics ► EB 8389.

7.10 Enabling and selecting parameters


All codes and their meaning and default settings are listed in the code list in Chapter 11.3.

Codes which are marked with an asterisk must be enabled with Code 3 before the associated parameters can be configured as described below.

Turn  until Code 3 appears (reading: No).

Press , the code number 3 blinks.


Change the setting in Code 3.


Turn  until YES appears.

Press , reading: 


Configuration is enabled.


You can now configure codes one after the other:

Turn  to select the required code.


Press , to activate the selected code. The code number starts to blink.

Turn  to select the setting.

Press  to confirm the selected setting.



Code 3
Configuration not enabled




Configuration enabled

If no settings are entered within 120 seconds, the enabled configuration function becomes invalid and the display returns to Code 0.


Cancel the setting:

To cancel a value before it is confirmed (by pressing ) proceed as follows:

Turn  until ESC appears.

Press , to confirm.


The entered value is not adopted.



Canceling the reading

7.11 Operating modes






7.11.1 Automatic and manual modes

After initialization has been completed successfully, the positioner is in  automatic mode (AUTO).



Automatic mode


Switching to manual mode (MAN):

1. Turn  until Code 0 appears.
2. Press , reading: *AUTO*, the code number 0 blinks.
3. Turn  until *MAN* appears.
4. Press . The positioner changes to the manual mode (.






Automatic mode

The manual mode starts using the last set point of the automatic mode, ensuring a bumpless changeover. The current position is displayed in %.



Manual mode





Adjusting the manual set point:

1. Turn  until Code 1 appears.
2. Press , the code number 1 blinks.
3. Turn  until sufficient pressure has been built up in the positioner and the control valve moves to the required position.







The positioner automatically returns to Code 0 if no settings are made within 120 seconds, but remains in the manual mode.

Switch to automatic mode

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  until *AUTO* appears.
4. Press . The positioner switches to automatic mode.

7.11.2 Fail-safe position (SAFE)





If you want to move the valve to the fail-safe position determined during start-up (see Chapter 7.1), proceed as follows:

1. Turn  until Code 0 appears.
2. Press , reading: current operating mode (*AUTO* or *MAN*), the code number 0 blinks.
3. Turn  until *SAFE* appears.
4. Press , reading: *S*

The valve moves to the fail-safe position. If the positioner has been initialized, the current valve position in % is indicated on the display.



Exiting the fail-safe position:

1. Turn  until Code 0 appears.
2. Press , the code number 0 blinks.
3. Turn  and select the required operating mode (*AUTO* or *MAN*).
4. Press  to confirm.
5. The positioner switches to the operating mode selected.

8 Servicing

i Note

The positioner was checked by SAMSON before it left the factory.

- The product warranty becomes void if service or repair work not described in these instructions is performed without prior agreement by SAMSON's After-sales Service department.
- Only use original spare parts by SAMSON, which comply with the original specifications.

The positioner does not require any maintenance.

Housing cover

Occasionally, the window in the cover may need to be cleaned.

! NOTICE

Incorrect cleaning will damage the window. The window is made of Makrolon® (new design) and will be damaged when cleaned with abrasive cleaning agents or agents containing solvents.

- Do not rub the window dry.
- Do not use any cleaning agents containing chlorine or alcohol or abrasive cleaning agents.
- Use a non-abrasive, soft cloth for cleaning.

Filters

There are filters with a 100 µm mesh size in the pneumatic connections for supply and output which can be removed and cleaned, if required.

Supply air pressure reducing stations

The maintenance instructions of any upstream supply air pressure reducing stations must be observed.

8.1 Firmware update

Firmware updates on positioners currently in operation can be performed as described below. Only individuals with a written approval may perform updates. Approved individuals are named by SAMSON's Total Quality Management and assigned a test mark.

Laptops and computers connected to the power supply must only be interconnected with intrinsically safe equipment if the SAMSON isolated USB interface adapter (order no. 1400-9740) is connected in-between for software programming or test routines.

Updates outside the hazardous area:

- ➔ Remove the positioner and perform the update outside the hazardous area.

Updates on site:

- ➔ Updates on site are only permitted after the plant operator presented a signed hot work permit.


Servicing

- After updating has been completed, add the current firmware to the nameplate (e.g. using a label).
- The individual approved by SAMSON confirms the update by attaching the assigned test mark (stamp).

8.2 Preparation for return shipment

Defective positioners can be returned to SAMSON for repair.

Proceed as follows to return devices to SAMSON:

1. Put the control valve out of operation. See associated valve documentation.
2. Remove the positioner (see Chapter 10.2).
3. Send the positioner to your nearest SAMSON subsidiary. SAMSON subsidiaries are listed on our website at  www.samsongroup.com > About SAMSON > Sales offices.

9 Malfunctions

A status classification is assigned to all status and fault alarms in the positioner. The default settings of the status classification are listed in the code list.

i Note

The assignment of the status classification can be changed in TROVIS-VIEW and over the FOUNDATION™ fieldbus parameters. Refer to the Operating Instructions for the valve diagnostics ► EB 8389 and the Configuration Manual ► KH 8384-5 on the enclosed CD-ROM for more details.

To provide a better overview, the classified messages are summarized in a condensed state for the positioner according to the NAMUR Recommendation NE 107. The status messages are divided into the following categories:




- **Maintenance alarm**
The positioner cannot perform its control task due to a functional fault in the positioner itself or in one of its peripherals or an initialization has not yet been successfully completed.
- **Maintenance required**
The positioner still performs its control task (with restrictions). A maintenance demand or above average wear has been determined. The wear tolerance will soon be exhausted or is reducing at a faster rate than expected. Maintenance is necessary in the medium term.

- **Maintenance demanded**
The positioner still performs its control task (with restrictions). A maintenance demand or above average wear has been determined. The wear tolerance will soon be exhausted or is reducing at a faster rate than expected. Maintenance is necessary in the short term.
- **Out of specification**
The positioner is running outside the specified operating conditions.
- **Function check**
Test or calibration procedures are performed in the positioner. The positioner is temporarily unable to perform its control task as long as the procedure is taking place.

i Note

If an event is classified as “No message”, this event does not have any affect on the condensed state.


The condensed state is displayed represented by the following icons:

| Condensed state | Positioner display |
|---|--|
| Maintenance alarm |  |
| Function check | Text e.g. tESing, <i>TunE</i> or <i>tESr</i> |
| Maintenance required/maintenance demanded |  |
| Out of specification |  blinking |

Malfunctions

If the positioner has not been initialized, the maintenance alarm icon (⚡) is displayed as the positioner cannot follow its set point.

If fault alarms exist, the possible source of error is displayed in Code 49 onwards. In this case, Err is displayed.



Example:
Error caused by pin position

Refer to the code list (Chapter 11.3) for possible causes and the recommended action.

9.1 Confirming error messages

Enable configuration:

1. Turn ⊕ until Code 3 appears (reading: No).
2. Press ⊕, the code number 3 blinks.
3. Turn ⊕ until YES appears.
4. Press ⊕ to confirm (reading: ↗).

Confirming error message:

1. Turn ⊕ until the the error code that you want appears.
2. Press ⊕ to confirm the error message.

9.2 Emergency action

Fail-safe action is triggered by the i/p converter or solenoid valve and upon supply air failure. The positioner fully discharges its pneumatic output to the atmosphere, causing the mounted actuator to be vented. As a result, the valve moves to the fail-safe position. The fail-safe position depends on how the springs are arranged in the pneumatic actuator (air-to-close or air-to-open).

When the supply air fails, the optional solenoid valve is triggered or after reaching the shutdown signal, all positioner functions, except open/closed loop control, remain active (including diagnostics as well as position and status feedback).

Tip

Emergency action in the event of valve or actuator failure is described in the associated valve and actuator documentation.

➔ The plant operator is responsible for emergency action to be taken in the plant.

10 Decommissioning and removal

⚠ DANGER

Risk of fatal injury due to ineffective explosion protection.

The explosion protection becomes ineffective when the positioner cover is opened.

The following regulations apply to installation in hazardous areas: EN 60079-14 (VDE 0165, Part 1).

ⓘ NOTICE

The process is disturbed by interrupting closed-loop control.

Do not mount or service the positioner while the process is running and only after isolating the plant by closing the shut-off valves.

10.1 Decommissioning

To decommission the positioner before removing it, proceed as follows:

1. Disconnect and lock the air supply and signal pressure.
2. Open the positioner cover and disconnect the wires for the control signal.

10.2 Removing the positioner

1. Disconnect the wires for the control signal from the positioner.
2. Disconnect the lines for supply air and signal pressure (not required for direct attachment using a connection block).

3. To remove the positioner, loosen the three fastening screws on the positioner.

10.3 Disposal



SAMSON is a producer registered in Europe, agency in charge ▶ www.samsongroup.com > About SAMSON > Environment, Social & Governance > Material Compliance > Waste electrical and electronic equipment (WEEE).
WEEE reg. no.: DE 62194439

Information on substances listed as substances of very high concern (SVHC) on the candidate list of the REACH regulation can be found in the document “Additional Information on Your Inquiry/Order”, which is added to the order documents, if applicable. This document includes the SCIP number assigned to the devices concerned. This number can be entered into the database on the European Chemicals Agency (ECHA) website (▶ <https://www.echa.europa.eu/scip-database>) to find out more information on the SVHC contained in the device.

- ➔ Observe local, national and international refuse regulations.
- ➔ Do not dispose of components, lubricants and hazardous substances together with your other household waste.

i Note

We can provide you with a recycling passport according to PAS 1049 on request. Simply e-mail us at aftersaleservice@samsongroup.com giving details of your company address.

Decommissioning and removal



Tip

On request, we can appoint a service provider to dismantle and recycle the product.

11 Appendix

11.1 After-sales service

Contact SAMSON's After-sales Service for support concerning service or repair work or when malfunctions or defects arise.

E-mail address

You can reach our after-sales service at aftersalesservice@samsongroup.com.

Addresses of SAMSON AG and its subsidiaries

The addresses of SAMSON AG, its subsidiaries, representatives and service facilities worldwide can be found on our website (www.samsongroup.com) or in all SAMSON product catalogs.

Required specifications

Please submit the following details:

- Order number and position number in the order
- Type, serial number, firmware version, device version

11.2 Certificates

The certificates valid at the time when these instructions were published are included on the next pages. The latest certificates can be found on our website (www.samsongroup.com > Products > Valve accessories > Type 3730-5 > Downloads > Certificates).

11.3 Code list


| Code no. | Parameter – Readings/values [default setting] | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|------------------------|--------------------|----------------------------|----|-----|-------------|----|-----|-------------|----|------|-------------|----|------|--------------|----|------|--------------|-----|------|---------------|-----|-------|---------------|-----|------|---------------|
| Note: Codes marked with an asterisk (*) must be enabled with Code 3 prior to configuration. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Operating mode [MAN] Manual mode AUTO Automatic mode SAFE Fail-safe position ESC Stop | Switchover from automatic to manual mode is bumpless. In fail-safe position, the S icon is displayed. In MAN and AUTO mode, the system deviation is represented by the bar graph elements. The reading indicates the valve position or angle of rotation in % when the positioner is initialized. If the positioner is not initialized, the position of the lever in relation to the longitudinal axis is displayed in degrees (°). | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Manual w [0] to 100 % of the nominal range | Adjust the manual set point with the rotary pushbutton. The current travel/angle is displayed in % when the positioner is initialized. If the positioner is not initialized, the position of the lever in relation to the longitudinal axis is indicated in degrees (°). i Note <i>It can only be selected when Code 0 = MAN</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Reading direction 1234, ↻, ESC | The reading direction of the display is turned by 180°. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Enable configuration [No], YES, ESC | Enables changing of data (automatically deactivated when the rotary pushbutton has not been operated for 120 s). FF blinks on the display when the on-site operation is locked. Codes marked with an asterisk (*) can only be read and not overwritten. Similarly, codes can only read over the SSP interface. | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4* | Pin position [No], 17, 25, 35, 50, 70, 100, 200 mm, 90° with rotary actuators, ESC Note: <i>If you select a pin position in Code 4 that is too small, the positioner switches to SAFE mode for reasons of safety.</i> | Follower pin must be mounted in the proper position depending on the valve travel/opening angle. Pin position must be entered for nominal (NOM) or substitute (SUB) initialization. <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Pin position Code 4</th> <th>Standard Code 5</th> <th>Adjustment range Code 5</th> </tr> </thead> <tbody> <tr><td>17</td><td>7.5</td><td>3.6 to 17.7</td></tr> <tr><td>25</td><td>7.5</td><td>5.0 to 25.0</td></tr> <tr><td>35</td><td>15.0</td><td>7.0 to 35.4</td></tr> <tr><td>50</td><td>30.0</td><td>10.0 to 50.0</td></tr> <tr><td>70</td><td>40.0</td><td>14.0 to 70.7</td></tr> <tr><td>100</td><td>60.0</td><td>20.0 to 100.0</td></tr> <tr><td>200</td><td>120.0</td><td>40.0 to 200.0</td></tr> <tr><td>90°</td><td>90.0</td><td>24.0 to 100.0</td></tr> </tbody> </table> | Pin position Code 4 | Standard Code 5 | Adjustment range Code 5 | 17 | 7.5 | 3.6 to 17.7 | 25 | 7.5 | 5.0 to 25.0 | 35 | 15.0 | 7.0 to 35.4 | 50 | 30.0 | 10.0 to 50.0 | 70 | 40.0 | 14.0 to 70.7 | 100 | 60.0 | 20.0 to 100.0 | 200 | 120.0 | 40.0 to 200.0 | 90° | 90.0 | 24.0 to 100.0 |
| Pin position Code 4 | Standard Code 5 | Adjustment range Code 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | 7.5 | 3.6 to 17.7 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | 7.5 | 5.0 to 25.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35 | 15.0 | 7.0 to 35.4 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 50 | 30.0 | 10.0 to 50.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 70 | 40.0 | 14.0 to 70.7 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 100 | 60.0 | 20.0 to 100.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 200 | 120.0 | 40.0 to 200.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90° | 90.0 | 24.0 to 100.0 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Code no. | Parameter – Readings/ values [default setting] | Description |
|----------|---|---|
| 5* | Nominal range mm or angle °, ESC | Nominal valve travel or opening angle must be entered for nominal (NOM) or substitute (Sub) initialization. The possible adjustment range depends on the pin position from the table for Code 4. Code 5 is generally locked until Code 4 is set to No, i.e. after a pin position has been entered, Code 5 can be configured. Indicates maximum travel/angle reached during initialization after initialization has been successfully completed. |
| 6* | Init mode [MAX] Maximum range NOM Nominal range MAN Manual setting Sub Emergency mode ZP Zero calibration ESC Stop | Select the initialization mode MAX: Travel/angle of the closure member from the CLOSED position to the opposite stop in the actuator. NOM: Travel/angle of the closure member measured from the CLOSED position to the indicated OPEN position. MAN: Manually selected range Sub: Substitute calibration (without initialization) |
| 7* | w/x [↗↗] Increasing/ increasing ↗↘ Increasing/ decreasing ESC | Direction of action of the set point w in relation to the travel/angle x Automatic adaptation: AIR TO On completing initialization, the direction of action remains OPEN: increasing/increasing (↗↗). A globe valve opens as the set point increases. AIR TO On completing initialization, the direction of action changes CLOSE: to increasing/decreasing (↗↘). A globe valve closes as the set point increases. |
| 8* | Travel/angle range start (lower x-range value) [0.0] to 80.0 % of the nominal range, ESC Note: Specified in mm or angle ° provided Code 4 is activated. | Lower range value for travel/angle in nominal or operating range The operating range is the actual travel/angle of the valve and is limited by the lower travel/angle range value (Code 8) and the upper travel/angle range value (Code 9). Usually, the operating range and the nominal range are identical. The nominal range can be limited to the operating range by the lower and upper x-range values. The value is displayed or must be entered. The characteristic is adapted. See also the example in Code 9. |

| Code no. | Parameter – Readings/values [default setting] | Description |
|----------|--|---|
| 9* | <p>Travel/angle range end (upper x-range value)</p> <p>20.0 to [100.0 %] of the nominal range, ESC</p> <p><i>Note: Specified in mm or angle ° provided Code 4 is activated.</i></p> | <p>Upper range value for travel/angle in nominal or operating range</p> <p>The value is displayed or must be entered.</p> <p>The characteristic is adapted.</p> <p>Example: The operating range is modified, for example to limit the range of a control valve which has been sized too large. For this function, the entire resolution range of the set point is converted to the new limits.</p> <p>0 % on the display corresponds to the adjusted lower limit and 100 % to the adjusted upper limit.</p> |
| 10* | <p>Travel/angle lower limit (lower x-limit)</p> <p>0.0 to 49.9 % of the operating range, [No], ESC</p> | <p>Limits travel/opening angle to the entered value (lower limit). The characteristic is not adapted.</p> <p>The characteristic is not adapted to the reduced range. See also example in Code 11.</p> |
| 11* | <p>Travel/angle upper limit (upper x-limit)</p> <p>50.0 to 120.0 %, [100 %] of the operating range, No, ESC</p> | <p>Limits travel/angle to the entered value (upper limit). The characteristic is not adapted.</p> <p>Example: In some applications, it is better to limit the valve travel, e.g. if a certain minimum medium flow is required or a maximum flow must not be reached.</p> <p>The lower limit must be adjusted with Code 10 and the upper limit with Code 11.</p> <p>If a tight-closing function has been set up, it has priority over the travel limitation.</p> <p>When set to No, the valve can be opened past the rated travel with a set point outside of the 0 to 100 % range.</p> |
| 14* | <p>Set point cutoff decrease</p> <p>0.0 to 49.9 %, [1.0 %] of the span adjusted in Code 12/13, No, ESC</p> | <p>If the set point w reaches up to the entered percentage at the final value that causes the valve to close, the actuator is immediately completely vented (with AIR TO OPEN) or filled with air (with AIR TO CLOSE). This action always lead to maximum tight-closing of the valve.</p> <p>Codes 14/15 have priority over Codes 8/9/10/11.</p> <p>Codes 21/22 have priority over Codes 14/15.</p> |

| Code no. | Parameter – Readings/ values [default setting] | Description |
|----------|---|--|
| 15* | Set point cutoff increase 50.0 to 100.0 % of the span adjusted in Code 12/13, [No], ESC | If the set point w reaches up to the entered percentage at the final value that causes the valve to open, the actuator is immediately filled with air (with AIR TO OPEN) or completely vented (with AIR TO CLOSE). This action always lead to the valve being completely opened. The signal pressure can be limited in Code 16. Codes 14/15 have priority over Codes 8/9/10/11. Codes 21/22 have priority over Codes 14/15. Example: set the cutoff to 99 % for three-way valves. |
| 16* | Pressure limit 1.4, 2.4, 3.7 bar, [No], ESC | The signal pressure to the actuator can be limited in stages. After changing a pressure limit already set, the actuator must be vented once (e.g. by selecting the fail-safe position (SAFE) over Code 0). NOTICE <i>Do not activate pressure limitation for double-acting actuators (with fail-safe position AIR TO OPEN).</i> |
| 17* | Proportional-action coefficient K_p (level) 0 to 17, [7], ESC | Read or change K_p Note Note concerning changing the K_p and T_V levels: During positioner initialization, the values for K_p and T_V are optimally set. If the positioner tends to overshoot impermissibly due to other disturbances, the K_p and T_V levels can be adapted accordingly after initialization. Increment T_V level until desired behavior is reached or when the maximum value of 4 is reached, the K_p level can be decreased in increments. K_p level changes affect the set point deviation. |
| 18* | Derivative-action time T_V (level) 1, [2], 3, 4, No, ESC | Read or change T_V (see K_p level) A change of the T_V level has no effect on the system deviation. |
| 19* | Tolerance band 0.1 to 10.0 %, [5.0 %] of the operating range, ESC | Used for error monitoring. Determination of the tolerance band in relation to the operating range. Associated lag time (30 s) is a reset criterion. If a transit time is determined during initialization which is six times longer than 30 s, the six-fold transit time is accepted as the lag time. |

| Code no. | Parameter – Readings/values [default setting] | Description |
|----------|--|--|
| 20* | Characteristic [0] to 9, ESC | Select characteristic 0 Linear 1 Equal percentage 2 Reverse equal percentage 3 SAMSON butterfly valve, linear 4 SAMSON butterfly valve, equal percentage 5 VETEC rotary plug valve, linear 6 VETEC rotary plug valve, equal percentage 7 Segmented ball valve, linear 8 Segmented ball valve, equal percentage 9 User-defined (defined over operator software) i Note <i>The various characteristics are listed in the Appendix.</i> |
| 21* | Required transit time OPEN (w ramp open) [0] to 240 s, ESC | Time required to move through the operating range when the valve opens. Limitation of the transit time (Code 21 and 22): For some applications it is recommendable to limit the transit time of the actuator to prevent it from engaging too fast in the running process. Code 21 has priority over Code 15. NOTICE <i>The function is not activated when the fail-safe function or solenoid valve is triggered nor upon failure of the auxiliary power.</i> |
| 22* | Required transit time CLOSED (w ramp closed) [0] to 240 s, ESC | Time required to move through the operating range when the valve closes. Code 22 has priority over Code 14. NOTICE <i>The function is not activated when the fail-safe function or solenoid valve is triggered nor upon failure of the auxiliary power.</i> |
| 23* | Total valve travel [0] to 99 · 10 ⁷ , YES, ESC Exponential reading from 9999 travel cycles onwards | Totaled full valve travel cycle Can be reset to 0 by selecting ESC. i Note <i>The total valve travel is saved in a non-volatile memory after every 1000 full valve travel cycle.</i> |

| Code no. | Parameter – Readings/values [default setting] | Description |
|----------|---|---|
| 24* | LV total valve travel 1000 to $99 \cdot 10^7$ [1.000000], ESC Exponential reading from 9999 travel cycles onwards | Limit value of total valve travel. If the limit is exceeded, the error message and the  icon corresponding to the condensed state appear. |
| 34* | Closing direction CL, [CCL], ESC | CL: Clockwise CCL: Counterclockwise Direction of rotation to reach the valve's CLOSED position (view onto rotary switch with positioner cover open). Needs only be entered in SUB initialization mode (Code 6). |
| 35* | Blocking position [0.0] mm/° /%, ESC | Enter the blocking position (distance to CLOSED position) Only necessary with SUB initialization mode. |
| 36* | Reset [----], Std, diAG, ESC | Std: Resets all parameters and diagnosis data to their default settings. After a reset, the positioner must be re-initialized. diAG: Resets diagnosis data only. Plotted reference graphs and logs remain saved. The positioner does not need to be re-initialized. |
| 38* | Inductive alarm [No], YES, ESC | Indicates whether the inductive limit switch option is installed or not. |
| 39 | Set point deviation e info -99.9 to 99.9 % | Read only Indicates the deviation from the target position. |
| 40 | Transit time Open info [0] to 240 s | Read only Minimum opening time determined during initialization. |
| 41 | Transit time Closed info [0] to 240 s | Read only Minimum closing time determined during initialization. |
| 42 | Auto-w/manual-w info 0.0 to 100.0 % of the span | Read only Auto mode: Indicates the applied automatic set point. Man mode: Indicates the applied manual set point. |
| 43 | Firmware info control | Read only Indicates the positioner type and current firmware version in alternating sequence. |

| Code no. | Parameter – Readings/values [default setting] | Description |
|------------|---|---|
| 44 | y info [0] to 100 %, OP, MAX, – – – | Read only Indicates the control signal y in % in relation to the travel range determined during initialization. MAX: The positioner builds up its maximum output pressure, see description in Code 14 and 15. OP: The positioner vents completely, see description in Code 14 and 15. – – –: The positioner is not initialized. |
| 45 | Solenoid valve info YES, HIGH/LOW, No | Read only Indicates whether a solenoid valve is installed or not. If a voltage supply is connected at the terminals of the installed solenoid valve, YES and HIGH appear on the display in alternating sequence. If a voltage supply is not connected (actuator vented, fail-safe position indicated on the display by the S icon), YES and LOW appear on the display in alternating sequence. |
| 46* | Bus address 16 to 251, ESC | Bus address 16 to 247: Positioners with fixed bus address 248 to 251: Positioners without fixed bus address (new or decommissioned positioners) |
| 47* | Write protection FF YES, [No], ESC | When write protection is active, device data can be read using FF communication but not overwritten. |
| 48* 49* | Diagnostic parameters ► EB 8389 | |

11.4 Error codes

Initialization errors

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|---|---|
| 50 | x > permissible range | Value of measuring signal too high or too low; the lever operates near its mechanical stops. <ul style="list-style-type: none"> • Pin not mounted properly • Bracket slipped in case of NAMUR attachment or positioner is off center. Follower plate not mounted properly. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check attachment and pin position, set operating mode from SAFE to MAN and re-initialize the positioner. |
| 51 | $\Delta x < permissible$ range | Insufficient measuring span of the lever. <ul style="list-style-type: none"> • Pin not mounted properly • Wrong lever An angle of rotation smaller than 16° at the positioner shaft only generates an alarm. An angle below 9° leads to the initialization being canceled. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check attachment and re-initialize the positioner. |
| 52 | Attachment | <ul style="list-style-type: none"> • Invalid positioner attachment • Rated travel/angle (Code 5) could not be achieved during NOM initialization (no tolerance downwards permissible). • Mechanical or pneumatic fault, e.g. wrong lever selected or supply pressure too low to move to the required position. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check attachment and supply pressure. Re-initialize the positioner. Under certain circumstances, it may be possible to check the maximum travel/angle by entering the actual pin position and then performing a MAX initialization. After initialization has been completed, the Code 5 indicates the maximum achieved travel or angle. |

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|--|--|
| 53 | Initialization time exceeded (Init time >) | Initialization takes too long. The positioner returns to the previous operating mode. <ul style="list-style-type: none"> • No pressure in supply line or pneumatic leakage • Supply air failure during initialization |
| | Status classification | [Maintenance required] |
| | Recommended action | Check attachment and supply air line. Re-initialize the positioner. |
| 54 | Initialization – solenoid valve | <ol style="list-style-type: none"> ¹⁾ A solenoid valve is installed (Code 45 = YES) and has not been connected or not properly. As a result, actuator pressure cannot build up. The alarm is generated when you attempt to initialize the positioner. ²⁾ If you attempt to initialize the positioner from the fail-safe position (SAFE). |
| | Status classification | [Maintenance required] |
| | Recommended action | <ol style="list-style-type: none"> ¹⁾ Check connection and supply voltage of the solenoid valve (Code 45 High/Low). ²⁾ Set the MAN mode in Code 0. Re-initialize the positioner. |
| 55 | Transit time too short (transit time <) | Actuator transit times detected during initialization are so short that optimal positioner tuning is impossible. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check the volume restriction setting. Re-initialize the positioner. |
| 56 | Pin position | Initialization canceled because selected NOM and SUB initialization modes require the pin position to be entered. |
| | Status classification | [Maintenance required] |
| | Recommended action | Enter pin position over Code 4 and rated travel/angle over Code 5. Re-initialize the positioner. |

Operational errors

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|------------------------|--|
| 57 | Control loop | Control loop error, the valve no longer follows the controlled variable within tolerable times (tolerance band alarm Code 19). <ul style="list-style-type: none"> • Actuator blocked • Positioner attachment shifted subsequently • Supply pressure no longer suffices. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check attachment. |
| 58 | Zero point | Zero point incorrect Error can occur when the positioner's attachment position is shifted or when the valve trim is worn, particularly with soft-sealed plugs. |
| | Status classification | [Maintenance required] |
| | Recommended action | Check valve and attachment of the positioner. If OK, perform a zero calibration over Code 6. We recommend to re-initialize the positioner if zero deviates by more than 5 %. |
| 59 | Auto-correction | Errors in the positioner's data section are detected detected by automatic monitoring and corrected automatically. |
| | Status classification | [No message] |
| | Recommended action | Automatic |
| 60 | Fatal error | Error in safety-relevant data that cannot be corrected automatically. Possible cause: EMC disturbances. The valve is moved to fail-safe position. |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Reset over Code 36. Re-initialize the positioner. |

Hardware errors

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|--------------------------|--|
| 62 | x signal | <p>Actuator's measured value recording failed. The conductive plastic element is defective. The device continues functioning in emergency mode but it must be replaced as quickly as possible. The emergency mode on the display is indicated by a blinking closed-loop operation icon and 4 dashes instead of the position reading.</p> <p>i Note <i>Note on the open-loop operation: If the measuring system has failed, the positioner is still in a reliable state. The positioner switches to emergency mode where the position cannot be accurately controlled anymore. However, the positioner continues operation according to its set point so that the process remains in a safe state.</i></p> |
| | Status classification | [Maintenance demanded] |
| | Recommended action | Return positioner to SAMSON AG for repair. |
| 64 | i/p converter (y) | Current circuit of i/p converter interrupted. |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Cannot be remedied. Return positioner to SAMSON AG for repair. |

Error appendix

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|-----------------------|--|
| 65 | Hardware | <p>Initialization key jammed (firmware version R 1.51 and higher) A hardware error has occurred. The positioner changes to the fail-safe position (SAFE).</p> |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Confirm error and return to automatic mode or perform a reset and re-initialize the positioner. If this is not successful, return positioner to SAMSON for repair. |
| 66 | Data memory | No more data can be written to the memory, e.g. because written data deviate from read data. The valve moves to the fail-safe position. |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Return positioner to SAMSON AG for repair. |

| | | |
|----|--------------------------|---|
| 67 | Check calculation | Hardware controller monitored by test calculation. |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Confirm error. If this is not possible, return positioner to SAMSON for repair. |

Data errors

| | | |
|---|---------------------------------|--|
| Error codes – Recommended action | | Condensed state message active, when prompted, <i>Err</i> appears. When fault alarms exist, they are displayed here. |
| 68 | Control parameters | Error in control parameters. |
| | Status classification | [Maintenance required] |
| | Recommended action | Confirm error, perform a reset and re-initialize the positioner. |
| 69 | Potentiometer parameters | Error in digital potentiometer parameters |
| | Status classification | [Maintenance required] |
| | Recommended action | Confirm error, perform a reset and re-initialize the positioner. |
| 70 | Calibration | Error in data from production calibration. The positioner continues operation with cold start values. |
| | Status classification | [Maintenance required] |
| | Recommended action | Return positioner to SAMSON AG for repair. |
| 71 | General parameters | Error in parameters not critical to control operation. |
| | Status classification | [Maintenance required] |
| | Recommended action | Confirm error. Check and, if necessary, change the settings of the required parameters. |
| 73 | Internal device error 1 | Internal device error |
| | Status classification | [Maintenance required] |
| | Recommended action | Return positioner to SAMSON AG for repair. |
| 74 | FF parameters | Error in parameters not critical to control operation. |
| | Status classification | [Maintenance required] |
| | Recommended action | Confirm error and perform a reset. |

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|-------------------------------|--|
| 76 | No emergency mode | The travel measuring system of the positioner has a self-monitoring function (see Code 62). An emergency mode (open-loop control) is not available for certain actuators, such as double-acting actuators. In case of a travel sensing error, the positioner vents the output (Output 38) or A1 in double-acting actuators. During the initialization, the positioner automatically checks whether the actuator has such a function or not. |
| | Status classification | [No message] |
| | Recommended action | Merely information, confirm, if necessary. No further action required. |
| 77 | Software loading error | When the positioner starts operation for the first time after the FF signal has been applied, it carries out a self-test (tESinG runs across the display). If the positioner loads the wrong software, the valve moves to the fail-safe position. It is not possible to make the valve leave this fail-safe position again. |
| | Status classification | Maintenance alarm (cannot be classified) |
| | Recommended action | Interrupt fieldbus signal and restart the positioner. If not successful, return positioner to SAMSON for repair. |
| 78 | Option parameters | Error in option parameters. |
| | Status classification | [Maintenance required] |
| | Recommended action | Return positioner to SAMSON AG for repair. |

Diagnosis errors

| Error codes – Recommended action | | Condensed state message active, when prompted, Err appears. When fault alarms exist, they are displayed here. |
|----------------------------------|------------------------------|--|
| 79 | Diagnostic messages | Messages generated by the extended diagnostics |
| | Status classification | Maintenance required (cannot be classified) |
| 80 | Diagnostic parameters | Error in parameters not critical to control operation. |
| | Status classification | Maintenance required (cannot be classified) |
| | Recommended action | Confirm error. Check and, if necessary, perform a new reference test. |

| | | |
|---|-------------------------|---|
| Error codes – Recommended action | | Condensed state message active, when prompted, <i>Err</i> appears. When fault alarms exist, they are displayed here. |
| 81 | Reference graphs | Error occurred during plotting the reference graphs for drive signal y steady-state or drive signal y hysteresis. <ul style="list-style-type: none"> • Reference test canceled • Reference line for drive signal y steady-state or drive signal y hysteresis was not adopted. |
| | Status classification | [No message] |
| | Recommended action | Check and, if necessary, perform a new reference test. |

11.5 Decimal values of the modes in the FOUNDATION™ fieldbus blocks (Code 48)

| Mode | Decimal value |
|-----------|---------------|
| AUTO | 8 |
| AUTO/CAS | 12 |
| AUTO/RCAS | 134 |
| O/S | 128 |
| MAN | 16 |

11.6 Decimal values of the states in the FOUNDATION™ fieldbus blocks (Code 48)

| Status | Decimal value |
|-----------------------------------|---------------|
| Good (NC) – Non-specific | 128 |
| Good (NC) – Active block alarm | 132 |
| Good (NC) – Active advisory alarm | 136 |
| Good (NC) – Active critical alarm | 140 |
| Good (NC) – Unack block alarm | 144 |
| Good (NC) – Unack advisory alarm | 148 |
| Good (NC) – Unack critical alarm | 152 |
| Uncertain – Non-specific | 64 |

Appendix




| Status | Decimal value |
|--|---------------|
| Uncertain – Last usable value | 68 |
| Uncertain – Substitute/manual entry | 72 |
| Uncertain – Initial value | 76 |
| Uncertain – Sensor conversion not accurate | 80 |
| Uncertain – Engineering unit range violation | 84 |
| Uncertain – Sub-normal | 88 |
| Good (C) – Non-specific | 192 |
| Good (C) – Initialization acknowledge | 196 |
| Good (C) – Initialization request | 200 |
| Good (C) – Not invited | 204 |
| Good (C) – Not selected | 208 |
| Good (C) – Local override | 216 |
| Good (C) – Fault state active | 220 |
| Bad – Non-specific | 0 |
| Bad – Configuration error | 4 |
| Bad – Not connected | 8 |
| Bad – Device failure | 12 |
| Bad – Sensor failure | 16 |
| Bad – No comm., with last usable value | 20 |
| Bad – No comm., no last usable value | 24 |
| Bad – Out of service | 28 |

11.8 Selecting the characteristic

The characteristics that can be selected in Code 20 are shown in the following in graph form.


i Note

A characteristic can only be defined (user-defined characteristic) using a workstation/operating software (e.g. TROVIS-VIEW).




SAMSON butterfly valve linear (select characteristic: 3)

Travel/angle [%]




SAMSON butterfly valve equal percentage (select characteristic: 4)

Travel/angle [%]




VETEC rotary plug valve linear (select characteristic: 5)

Travel/angle [%]




VETEC rotary plug valve equal percentage (select characteristic: 6)

Travel/angle [%]




Segmented valve ball linear (select characteristic: 7)

Travel/angle [%]



Segmented valve ball equal percentage (select characteristic: 8)

Travel/angle [%]



VDE Prüf- und Zertifizierungsinstitut • Messmerstraße 8 • 53509 Sittard

Samsom AG
Mess- und Regeltechnik
Weennullesrasse 3
63314 Frankfurt

Ihr Zeichen
Herr Opti

2005-11-08

Ihr Zeichen - Bitte angeben
475000-9010-000167235

FG533bht-wah

Offenbach, 2005-11-21

Ansprechpartner
Herr Bleih

(069) 83 05-340

Fax (069) 83 05-716

gerhard.bleih@vde.com

Prüfbericht
zur Information des Auftraggebers
Test Report for the Information of the Applicant

Schreibartikelform an Gehäusen für Stellungsregler Typ 3730, 3731
Dieser Prüfbericht enthält das Ergebnis einer einmaligen Untersuchung an dem zur Prüfung vorgelegten Erzeugnis. Ein Muster dieses Erzeugnisses wurde geprüft, um die Übereinstimmung mit den nachfolgend aufgeführten Normen bzw. Teilen von Normen festzustellen.
This test report contains the result of a single investigation carried out on the product submitted. A sample of this product was tested to find the accordance with the thereafter listed standards resp. parts of standards.

Der Prüfbericht berechtigt nicht zur Benutzung eines Prüfzeichens des VDE und des Zeichens "GS-geprüfte Sicherheit" und erstreckt sich nicht auf alle für das geprüfte Erzeugnis geltenden VDE-Bestimmungen.
This test report does not entitle to use a VDE Certification mark and the GS - approved, Sicherheit (tested safety) and does not refer to all VDE specifications applicable for the tested product.

Dieser Prüfbericht darf Dritten nur im vollen Wortlaut einschließlich dieser Vorbemerkung und unter Angabe des Ausstellungsdatums zur Kenntnis gegeben werden.
This test report may only be passed to a third party in its complete wording including this preamble and the date of issue.

Jede Veröffentlichung oder Vervielfältigung bedarf der vorherigen, schriftlichen Genehmigung des VDE Prüf- und Zertifizierungsinstituts.
Any publication or reproduction requires the prior written approval of the VDE Testing and Certification Institute.

**VDE VERBAND DER ELEKTROTECHNIK
ELEKTRONIK INFORMATIONSTECHNIK e.V.**

VDE Prüf- und Zertifizierungsinstitut
10000 Sittard
Tel. 069 83 05-0
Fax 069 83 05-400
www.vde.com
VDE ist ein eingetragenes
Markenzeichen
VDE ist ein eingetragenes
Markenzeichen

VDE ist ein eingetragenes
Markenzeichen
VDE ist ein eingetragenes
Markenzeichen
VDE ist ein eingetragenes
Markenzeichen
VDE ist ein eingetragenes
Markenzeichen

Selle 2 - 21.11.2005 Unser Zeichen: 475000-9010-000167235
FG533bht-wah



1 Aufgabe

An den unter Punkt 2 bezeichneten Prüfmustern wurde eine Prüfung auf Einhaltung der Schutzart IP50 durchgeführt.

2 Prüfmuster

2.1 Stellungsregler Typ 3730

2.2 Stellungsregler Typ 3731



3 Beurteilungsgrundlage

DIN EN 60529 (VDE 0470 Teil 1):2000-09
Schutzarten durch Gehäuse (IP-Code)
Deutsche Fassung EN 60529:1991 + A1:2000

4 Durchführung der Prüfung

Die Staubprüfung erfolgte bereits am Stellungsregler Typ 3730 unter Az.-Nr. 475000-9010-000167235
Kategorie 1 an den Anschlussgehäusen der Stellungsregler und der Magnetventile. Der Unterdruck betrug 2 kPa; die Prüfzeit 6 Stunden.

**VDE VERBAND DER ELEKTROTECHNIK
ELEKTRONIK INFORMATIONSTECHNIK e.V.**

VDE Prüf- und Zertifizierungsinstitut
10000 Sittard
Tel. 069 83 05-0
Fax 069 83 05-400
www.vde.com
VDE ist ein eingetragenes
Markenzeichen

2005 11 19 19 05



Nach dem Grad der VDE-Produktzertifizierung (IPSE) "Informationsblatt für Verbraucher"
VDE ist ein eingetragenes
Markenzeichen
VDE ist ein eingetragenes
Markenzeichen

Seite 3 - 21.11.2005 Unser Zeichen: 478000-9010-0001/67325
FG33/blh/wah

5 Prüfergebnis

Für die unter 2 beschriebenen Prüfmuster wurde folgendes Ergebnis erzielt:

- Schutz gegen den Zugang zu gefährlichen Teilen
nach DIN EN 60529 (VDE 0470 Teil 1):2000-09 **IP6X** **erfüllt**
- Schutz gegen das Eindringen von Wasser
nach DIN EN 60529 (VDE 0470 Teil 1):2000-09 **IPX6** **erfüllt**

Die Gehäuse der Stellungsregler erfüllen in den vorgestellten Ausführungen die Anforderungen an die Schutzart IP66.

In die Anschlussgehäuse dringt weiter Staub nach Wasser ein.

VDE Prüf- und Zertifizierungsinstitut
Fachgebiet FG33

i.A.  i.A. 



VDE VERBAND DER ELEKTROTECHNIK
ELEKTRONIKINFORMATIK e.V.

VDE ist ein eingetragenes Unternehmen
VDE-Prüf- und Zertifizierungsinstitut
Eckener Str. 3
42699 Solingen
VDE ist ein Unternehmen mit dem VDE-Prüf- und Zertifizierungsinstitut
Zertifiziert nach DIN EN ISO 9001:2008
DIN EN ISO 14001:2004
DIN EN ISO 45001:2018
DIN EN ISO 19011:2018
VDE ist ein Unternehmen mit dem VDE-Prüf- und Zertifizierungsinstitut
Zertifiziert nach DIN EN ISO 9001:2008
DIN EN ISO 14001:2004
DIN EN ISO 45001:2018
DIN EN ISO 19011:2018

2011-11-06/18/2018



(1) **EU-TYPE-EXAMINATION CERTIFICATE**
(Translation)

(2) Equipment or Protective Systems Intended for Use in
Potentially Explosive Atmospheres - **Directive 2014/34/EU**

(3) EU-Type Examination Certificate Number:

PTB 04 ATEX 2109

Issue: 1

(4) Product: Positioner, type 3730-41..., 3730-51..., 3730-45..., 3730-55...

(5) Manufacturer: **SAMSON AG Mess- und Regeltechnik**

(6) Address: **Weismüllerstraße 3, 60314 Frankfurt, Germany**

(7) This product and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.

(8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and of the Council, dated 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential Test Report PTB Ex 17-25139.

(9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:
EN 60079-0:2012/A11:2013 EN 60079-11:2012 EN 60079-31:2014

(10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate.

(11) This EU-Type Examination Certificate relates only to the design and construction of the specified product in accordance to the Directive 2014/34/EU. Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate.

(12) The marking of the product shall include the following:

**II 2 G Ex ia IIC T6...T4 Gb and II 2 D Ex ia IIIC T80 °C Db or
II 2 D Ex tb IIIC T80 °C Db**

Konformitätsbewertungsstelle, Sektor Explosionsschutz

Braunschweig, May 11, 2017

On behalf of PTB:

Dr.-Ing. F. Liesch
Regierungsdirektor



sheet 1/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

ZSEx001e c



(13) **SCHEDULE**

(14) **EU-Type Examination Certificate Number PTB 04 ATEX 2109, Issue: 1**

(15) Description of Product

The positioners of types 3730-41..., 3730-51..., 3730-45... and 3730-55... are communication-capable, bus-powered field devices which are used to assign a valve position to a control signal.

The bus interface connection (bus-coupling) can be performed according to the FISCO-concept for both specifications, Profibus PA and Foundation™ Fieldbus.

They are mounted onto levitation and slewing actuators. Non-flammable media are used as pneumatic auxiliary power. The equipment is intended for the application inside the hazardous area.

Thermal and electrical maximum values

Type 3730-41 and 3730-51:

For relationship between temperature class and permissible ranges of the ambient temperature, reference is made to the following table:

| Gas- or dust group | Temperature class | Permissible ambient temperature range |
|--------------------|-------------------|---------------------------------------|
| IIC | T6 | -55 °C ... 60 °C |
| | T5 | -55 °C ... 70 °C |
| | T4 | -55 °C ... 80 °C |
| IIIC | not applicable | -55 °C ... 80 °C |

For relationship between temperature class, permissible ranges of the ambient temperature, maximum short-circuit currents and maximum power for analyzing units with limit contacts (terminals 41/42), reference is made to the following table:

sheet 2/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

| Temperature class | Permissible ambient temperature range | I_0 / P_0 |
|-------------------|---------------------------------------|----------------|
| T6 | -55 °C ... 45 °C | 52 mA / 169 mW |
| T5 | -55 °C ... 60 °C | |
| T4 | -55 °C ... 75 °C | |
| T6 | -55 °C ... 60 °C | 25 mA / 64 mW |
| T5 | -55 °C ... 80 °C | |
| T4 | -55 °C ... 80 °C | |

BUS-connection-signal circuittype of protection Intrinsic Safety Ex ia IIC / IIB / IIIC
 (terminals 11/12) only for connection to a certified intrinsically safe circuit

For relationship between type of protection and electrical data, reference is made to the following table:

Maximum values:

| FISCO power supply | FIELDBUS power supply general | |
|---------------------------|-------------------------------|-------------------------|
| Ex ia IIC / IIB / IIIC | Ex ia IIC / IIIC | Ex ia IIB / IIIC |
| $U_i = 17,5 \text{ V DC}$ | $U_i = 24 \text{ V DC}$ | $U_i = 24 \text{ V DC}$ |
| $I_i = 380 \text{ mA}$ | $I_i = 360 \text{ mA}$ | $I_i = 380 \text{ mA}$ |
| $P_i = 5,32 \text{ W}$ | $P_i = 1,04 \text{ W}$ | $P_i = 2,58 \text{ W}$ |

$C_i = 5 \text{ nF}$
 $L_i = 10 \text{ } \mu\text{H}$

Limit contact, inductivetype of protection Intrinsic Safety Ex ia IIC / IIIC
 (terminals 41/42) only for connection to a certified intrinsically safe circuit

Maximum values:

$U_i = 16 \text{ V}$
 $I_i = 52 \text{ mA}$
 $P_i = 169 \text{ mW}$
 $C_i = 60 \text{ nF}$
 $L_i = 100 \text{ } \mu\text{H}$
 resp.

SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

$U_i = 16 \text{ V}$
 $I_i = 25 \text{ mA}$
 $P_i = 64 \text{ mW}$
 $C_i = 60 \text{ nF}$
 $L_i = 100 \text{ } \mu\text{H}$

Forced deaeration.....type of protection Intrinsic Safety Ex ia IIC / IIIC
 (terminals 81/82) only for connection to a certified intrinsically safe circuit

Maximum values:

$U_i = 28 \text{ V}$
 $I_i = 115 \text{ mA}$
 $C_i = 5.3 \text{ nF}$
 L_i negligibly low

Binary input 1.....type of protection Intrinsic Safety Ex ia IIC / IIIC
 (terminals 87/88) for connection to an active contact circuit

Maximum values:

$U_i = 30 \text{ V}$
 $I_i = 100 \text{ mA}$
 C_i negligibly low
 L_i negligibly low

Binary input 2.....type of protection Intrinsic Safety Ex ia IIC / IIB / IIIC
 (terminals 85/86) only for connection to a passive floating contact circuit

Maximum values:

$U_o = 5.88 \text{ V}$
 $I_o = 1 \text{ mA}$
 $P_o = 7.2 \text{ mW}$

For relationship between explosion group and permissible external capacitances and inductances, reference is made to the following table:

| Ex ia IIC / IIIC | Ex ia IIB / IIIC |
|--------------------------------|---------------------------------|
| $C_o = 2 \text{ } \mu\text{F}$ | $C_o = 16 \text{ } \mu\text{F}$ |
| $L_o = 10 \text{ mH}$ | $L_o = 1 \text{ H}$ |

sheet 4/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

C_i negligibly low
 L_i negligibly low

Serial Interfacetype of protection Intrinsic Safety Ex ia IIC / IIB / IIIC
 (programming socket BU)

Maximum values:

$U_o = 8.61$ V
 $I_o = 55$ mA
 $P_o = 250$ mW

For relationship between type of protection and permissible external capacitances and inductances, reference is made to the following table:

| Ex ia IIC / IIIC | Ex ia IIB / IIIC |
|----------------------|-------------------|
| $C_o = 0.61$ μ F | $C_o = 4$ μ F |
| $L_o = 9$ mH | $L_o = 9$ mH |

resp.

only for connection to a certified intrinsically safe circuit

Maximum values:

$U_i = 16$ V
 $I_i = 25$ mA
 $P_i = 64$ mW

C_i negligibly low
 L_i negligibly low

External position sensortype of protection Intrinsic Safety Ex ia IIC / IIIC
 (analog circuit board, pins p9, p10, p11)

Maximum values:

$U_o = 8.61$ V
 $I_o = 55$ mA
 $P_o = 250$ mW

For relationship between type of protection and permissible external capacitances and inductances, reference is made to the following table:

sheet 5/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

| | |
|--------------------------|-----------------------|
| Ex ia IIC / IIIC | Ex ia IIB / IIIC |
| C _o = 0.61 μF | C _o = 4 μF |
| L _o = 9 mH | L _o = 9 mH |

C_i = 730 nF
 L_i = 370 μH

Type 3730-45... und 3730-55...

The permissible range of the ambient temperature for dust groupe IIIC is -55 °C ... 80 °C.

| | | |
|---|--|-----------------------|
| BUS-connection signal circuit (Terminals 11/12)..... | Nominal signal: Rated voltage: | 24 V DC 28 V |
| Binary input 1..... (Terminals 87/88) | Nominal signal: Rated voltage: | 6 ... 30 V DC 30 V |
| Binary input 2..... (Terminals 85/86)..... | only for connection to a passive floating contact circuit | |
| Limit contact, inductive (Terminals 41/42) | Nominal signal: Rated voltage: | 8 V DC, 8 mA 16 V |
| Forced deaeration..... (Terminals 81/82) | Nominal signal: Rated voltage: | 6 ... 24 V DC 28 V |

Changes against previous issue:

The changes concern the update of the applied standards, the electrical data, the adding of another type notation for dust ignition protection by enclosure, the implementation of dust ignition protection by Intrinsic Safety, the application of alternative gasket material of the enclosure and alternative construction of the enclosure.

- (16) Test Report PTB Ex17-25139
- (17) Specific conditions of use
none

sheet 6/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 04 ATEX 2109, Issue: 1

(18) Essential health and safety requirements

Met by compliance with the aforementioned standards.

According to Article 41 of Directive 2014/34/EU, EC-type examination certificates which have been issued according to Directive 94/9/EC prior to the date of coming into force of Directive 2014/34/EU (April 20, 2016) may be considered as if they were issued already in compliance with Directive 2014/34/EU. By permission of the European Commission supplements to such EC-type examination certificates and new issues of such certificates may continue to hold the original certificate number issued before April 20, 2016.

Konformitätsbewertungsstelle, Sektor Explosionsschutz
On behalf of PTB:

Braunschweig, May 11, 2017


Dr.-Ing. F. Lienesch
Regierungsdirektor



sheet 7/7

EU-Type Examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY



CONFORMITY STATEMENT (Translation)


- (1)
- (2) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres - **Directive 2014/34/EU**
- (3) Test Certificate Number: **PTB 05 ATEX 2010 X** **Issue: 1**
- (4) Product: Positioner type 3730-48... and 3730-58...
- (5) Manufacturer: SAMSON AG Mess- und Regeltechnik
- (6) Address: Weismüllerstraße 3, 60314 Frankfurt, Germany
- (7) This product and any acceptable variation thereto are specified in the schedule to this certificate and the documents therein referred to.
- (8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and of the Council, dated 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.
- The examination and test results are recorded in the confidential test report PTB Ex 17-25140.
- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:
EN 60079-0:2012/A11:2013 EN 60079-15:2010 EN 60079-31:2014
- (10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) This Conformity Statement relates only to the design and construction of the specified product in accordance with Directive 2014/34/EU. Further requirements of this Directive apply to the manufacture and supply of this product.
- (12) The marking of the product shall include the following:



II 3 G Ex nA IIC T6 Gc bzw. II 3 D Ex tc IIIC T80 °C Dc

Konformitätsbewertungsstelle, Sektor Explosionsschutz
On behalf of PTB:

Braunschweig, June 22, 2017


Dr.-Ing. F. Lienschn
Regierungsdirektor



Sheet 1/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

(13)

SCHEDULE

(14) **CONFORMITY STATEMENT PTB 05 ATEX 2010 X, Ausgabe: 1**

(15) Description of the product

The positioners of types 3730-48... and 3730-58... are communication-capable, bus-powered field devices which are used to assign a valve position to a control signal.

They are mounted onto levitation and slewing actuators. Non-flammable media are used as pneumatic auxiliary power. The equipment is intended for the application inside the hazardous area.

Thermal and electrical maximum values:

The permissible ambient temperature range for dust group IIIC is between -55 °C ... 80 °C.

For the relationship between temperature class and permissible ranges of the ambient temperature for gas group IIC reference is made to the following table:

| Temperature class | permissible ambient temperature range |
|-------------------|---------------------------------------|
| T6 | -55 °C ... 60 °C |
| T5 | -55 °C ... 70 °C |
| T4 | -55 °C ... 80 °C |

BUS-connection signal circuit Nominal signal: 24 V DC
 (Terminals 11/12) Rated voltage: 28 V

Binary input 1 Nominal signal: 6 ... 30 V DC
 (Terminals 87/88) Rated voltage: 30 V

Binary input 2 only for connection to a passive floating
 (Terminals 85/86) contact circuit

Limit contact, inductive Nominal signal: 8 V DC, 8 mA
 (Terminals 41/42) Rated voltage: 16 V

Forced deaeration Nominal signal: 6 ... 24 V DC
 (Terminals 81/82) Rated voltage: 28 V

Sheet 2/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

SCHEDULE TO EU-TYPE EXAMINATION CERTIFICATE PTB 05 ATEX 2010 X, Issue: 1

Changes against previous issue:

The changes concern the update of the applied standards, the electrical data, the cancelation of type of protection "nL", the adding of dust ignition protection by enclosure, the application of alternative gasket material of the enclosure and alternative construction of the enclosure.

(16) Test report PTB Ex 17-25139

(17) Specific conditions of use

The program-interface intended for connection to the positioners of types 3730-48... and 3730-58... shall be installed outside of the hazardous area.

For type of protection "nA" applies:

If the program-interface adaptor is connected to a circuit of type of protection "nA" a fuse according to IEC 60127-2/II, 250 V F or according to IEC 60127-2/VI, 250 V T with a nominal fuse current of max. $I_n \leq 40$ mA shall be connected in series to the Vcc-circuit. The fuse shall be arranged outside of the hazardous area.

(18) Essential health and safety requirements

Met by compliance with the aforementioned harmonized standards.

According to Article 41 of Directive 2014/34/EU, Conformity Statements which have been issued according to Directive 94/9/EC prior to the date of coming into force of Directive 2014/34/EU (April 20, 2016) may be considered as if they were issued already in compliance with Directive 2014/34/EU. By permission of the European Commission supplements to such Conformity Statements and new issues of such certificates may continue to hold the original certificate number issued before April 20, 2016.

Konformitätsbewertungsstelle, Sektor Explosionsschutz
On behalf of PTB

Braunschweig, June 22, 2017


Dr.-Ing. F. Lienesch
Regierungsdirektor



Sheet 3/3

Conformity Statements without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

CERTIFICATE OF COMPLIANCE

HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT

This certificate is issued for the following equipment:

3730-43-abcdef. Profibus PA Positioner

3730-53-abcdef. Foundation FF Positioner

IS / I,II,III / 1 / ABCDEFG / T6 Ta = 60°C - Addendum to EB Addendum to EB 8384-5 EN, pages 7 to 12;

Entity/FISCO; Type 4X

I / 0 / AEx ia IIC / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 7 to 12; Type 4X

NI / 1 / 2 / ABCD / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 10 to 12; Nonincendive Field

Wiring/FNINCO; Type 4X; S / II,III / 2 / FG / T6 Ta = 60°C; Type 4X

I / 2 / Ex nA / nL IIC / T6 Ta = 60°C - Addendum to EB 8384-5 EN, pages 10 to 12; Nonincendive Field
Wiring/FNINCO; Type 4X

Entity/FISCO Parameters:

Foundation-Fieldbus Signal Terminals Group A/B (IIC)

Vmax (Ui) = 24V, Imax (Ii) = 360mA, Pmax (Pi) = 1.04W, Ci = 5nF, Li = 10µH

Profibus-Fieldbus Signal Terminals Group C, D (IIB)

Vmax (Ui) = 24V, Imax (Ii) = 380mA, Pmax (Pi) = 2.58W, Ci = 5nF, Li = 10µH

Profibus-Fieldbus Signal Circuit Terminals Group A/B (IIC)

Vmax (Ui) = 17.5Vdc, Imax (Ii) = 380mA, Pmax (Pi) = 5.32W, Ci = 5nF, Li = 10µH

Nonincendive Field Wiring/FNINCO Parameters:

Foundation-Fieldbus Signal Terminals Group A/B (IIC)

Vmax (Ui) = 30V or 32V, Imax (Ii) = 152mA or 130mA, Pmax (Pi) = 1.14W, Ci = 5nF, Li = 10µH

Profibus-Fieldbus Signal Terminals Group C, D (IIB)

Vmax (Ui) = 30V or 32V, Imax (Ii) = 379mA or 324mA, Pmax (Pi) = 3.85W or 2.77W, Ci = 5nF, Li = 10µH

Inputs & Outputs:

Limit Switches Terminals (Entity/FISCO):

Vmax (Ui) = 16V, Imax (Ii) = 25mA, Pmax (Pi) = 64mW, Ci = 30nF, Li = 100µH

Vmax (Ui) = 16V, Imax (Ii) = 52mA, Pmax (Pi) = 169mW, Ci = 30nF, Li = 100µH

Limit Switches Terminals (Nonincendive Field Wiring/ FNINCO):

Vmax (Ui) = 20V, Imax (Ii) = 25mA, Pmax (Pi) = 64mW, Ci = 60nF, Li = 100µH

Force Venting Function Terminals 81/82 (Entity/FISCO):

Vmax (Ui) = 28V, Imax (Ii) = 115mA, Pmax (Pi) = 0.5W, Ci = 5.3nF, Li = 0

Force Venting Function Terminals 81/82 (Nonincendive Field Wiring/FNINCO):
Vmax (Ui) = 30V, Imax (Ii) = 100mA, Pmax (Pi) = 0.75W, Ci = 5.3nF, Li = 0

Binary Inputs 1 & 2 Terminals (Entity/FISCO/Nonincendive Field Wiring/FNINCO):
Vmax (Ui) = 30V, Imax (Ii) = 100mA, Pmax (Pi) = 0.75W, Ci = 0, Li = 0
Voc (Ui) = 5.88V, Imax (Ii) = 1mA, Pmax (Pi) = 7.2mW, Ca = 2µF, La = 10mH

Serial Interface Active & Passive Plugs (Entity/FISCO/Nonincendive Field Wiring/FNINCO):
Voc (Ui) = 8.61V, Isc (Ii) = 55mA, Pmax (Pi) = 250mW, Ca = 0.61µF, La = 9mH
Vmax (Ui) = 16V, Isc (Ii) = 25mA, Pmax (Pi) = 64mW, Ci = 0, Li = 0

a = Inductive proximity switches: 0 (without proximity switch) or 1 (with proximity switch).
b = Force venting function (solenoid Valve): 0 (not provided) or 4 (provided).
c = Vibration Sensor: 0 (not provided) or 2 (provided).
d = Binary input: 0 (not provided) or 3 (provided).
e = External position sensor: 0 (not provided) or 1 (provided).
f = Connections: Pneumatic connections, electrical connections, 1+2 m 20 x 1.5 (plastic) or 1 + 5 = M 20 x 1.5 (metal).

Equipment Ratings:

evaluated as Intrinsically Safe electrical apparatus with Entity/FISCO parameters for use in Class I, II, III, Division 1, Groups A, B, C, D, E, F and G; alternatively for Class I, Zone 0, AEx ia Group IIC; Temperature Class T6 Ta = 60°C in accordance with control drawing Addendum to EB 8384-5 EN, pages 7 to 12; Nonincendive electrical apparatus with nonincendive field wiring/FNINCO for use in Class I, Division 2, Groups A, B, C and D; Suitable for Class II, III, Division 2, Groups F and G Temperature Class T6 Ta = 60°C; alternatively for Class I, Zone 2, Ex nA / nL Group IIC; Temperature Class T6 Ta = 60°C in accordance with control drawing Addendum to EB 8384-5 EN, pages 10 to 12; indoor/outdoor Type 4X hazardous (classified) Locations.

Approved for:

Samson AG
Postfach 101901 D-60314 Frankfurt, Germany



This certifies that the equipment described has been found to comply with the following FM Approval Standards and other documents:

| | |
|---------------|------|
| Class 3600 | 1998 |
| Class 3610 | 1999 |
| Class 3611 | 2004 |
| Class 3810 | 2005 |
| ANSI/NEMA 250 | 1991 |

Original Project ID: 3023605

FM Approval Granted: September 5, 2005

Subsequent Revision Reports / Date FM Approval Amended

| Report Number | Date | Report Number | Date |
|---------------|------------------|---------------|------|
| 3025274 | October 26, 2005 | | |

FM Global Technologies LLC

Timothy Adam
Technical Team Manager
FM Approvals

31st October, 2005
Date



Certificate of Compliance

Certificate: 1675804

Master Contract: 173246 (LR 54227)

Project: 70136714

Date Issued: 2017-05-23

Issued to: Samson AG
Mess- Und Regeltechnik
Weismuellerstrasse 3
Frankfurt, 60314
GERMANY

Attention: Tomislav Varga

The products listed below are eligible to bear the CSA Mark shown



Issued by:


R Papiah

PRODUCTS

CLASS 2258 04 - PROCESS CONTROL EQUIPMENT - Intrinsicly Safe Entity - For Hazardous Locations

Ex ia IIC T6

Class I, Division 1, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Type 4 Enclosure

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C; Intrinsicly safe when installed per Samson AG installation drawing EB8384-5 EN.

CLASS 2258 03 - PROCESS CONTROL EQUIPMENT - Intrinsicly Safe and Non-Incendive Systems - For Hazardous Locations

Ex nL IIC T6

Class I, Division 2, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Class III; Type 4 Enclosure

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C; Energy-limited (Non-incendive) when installed per Samson AG installation drawing EB8384-5 EN.



Certificate: 1675804 (LR 54227)
Project: 70136714

Master Contract: 173246
Date Issued: 2017-05-24

CLASS 2258 02 - PROCESS CONTROL EQUIPMENT - For Hazardous Locations

Ex nA II T6

Class I, Division 2, Groups A, B, C and D; Class II, Division 1, Groups E, F and G; Class III; Type 4 Enclosure

Model 3730-53 FOUNDATION Fieldbus Positioner, Temperature Code T6 at ambient of -40°C to +60°C, T5 at -40°C to +70°C, T4 at -40°C to +80°C. Refer to installation EB 8384-5 EN for electrical ratings.

Condition of acceptability

The Model 3730-53 must be installed per SAMSON AG installation drawing EB8384-5 EN.

APPLICABLE REQUIREMENTS

- | | | |
|-----------------------------|---|---|
| CSA Std C22.2 No. 25-1966 | - | Enclosures for Use in Class II, Groups E, F and G Hazardous Locations |
| CAN/CSA-C22.2 No. 94-M91 | - | Special Purpose Enclosures |
| CSA Std C22.2 No. 142-M1987 | - | Process Control Equipment |
| CAN/CSA-C22.2 No. 157-92 | - | Intrinsically Safe and Non-Incendive Equipment for Use in Hazardous Locations |
| CSA Std C22.2 No. 213-M1987 | - | Non-Incendive Electrical Equipment for Use in Class I, Division 2 Hazardous Locations |
| CAN/CSA-E60079-0:02 | - | Electrical Apparatus for Explosive Atmospheres, Part 0 - General Requirements |
| CAN/CSA-E60079-11:02 | - | Electrical Apparatus for Explosive Atmospheres, Part 11 - Intrinsic Safety "I" |
| CAN/CSA-E60079-15:02 | - | Electrical Apparatus for Explosive Atmospheres, Part 15 - Type of Protection "n" |



Certificate: 1675804 (LR 54227)
Project: 70136714

Master Contract: 173246
Date Issued: 2017-05-24

MARKINGS

Marking nameplate shall bear the following information:

- CSA Monogram;
- Submitter Identification;
- Model number;
- Serial number or date code;
- Electrical Rating/Entity Parameters
- Hazardous Location Designation;
- Reference to installation drawing number.
- The caution: "Warning - Substitution of Components May Impair Intrinsic Safety";
- Temperature Code Rating
- Maximum ambient
- Year and Certificate Number followed by an indicator 'X'



Supplement to Certificate of Compliance

Certificate: 1675804

Master Contract: 173246 (LR 54227)

*The products listed, including the latest revision described below,
are eligible to be marked in accordance with the referenced Certificate.*

Product Certification History

| Project | Date | Description |
|----------------|-------------|---|
| 70136714 | 2017-05-24 | Addition of a new window construction |
| 1675804 | 2006-06-01 | Correction – originally issued January 30, 2006 |
| 1675804 | 2006-01-30 | Original Certification. |

Installation Manual for apparatus certified by CSA for use in hazardous locations.

Communication is optionally either according to the FOUNDATIONTM Fieldbus Specification or according to PROFIBUS PA in compliance FISCO-Concept

The **FISCO Concept** allows interconnection of intrinsically safe apparatus to associated apparatus not specifically examined in such combination. The criteria for interconnection is that the voltage (**V_{max}**) the current (**I_{max}**) and the power (**P_{max}**) which intrinsically safe apparatus can receive and remain intrinsically safe, considering faults, must be equal or greater than the voltage (**V_{0C}**) the current (**I_{SC}**) and the power (**P₀**) levels which can be delivered by the associated apparatus, considering faults and applicable factors. In addition, the maximum unprotected capacitance (**C_i**) and inductance (**L_i**) of each apparatus (other than the termination) connected to the fieldbus must be less than or equal to **5 nF** and **10 μH** respectively.

In each segment only one active device, normally the associated apparatus, is allowed to provide the necessary energy for the fieldbus system The allowed voltage (**V_{0C}**) of the associated apparatus is limited to the range of **14V DC. to 24V DC.** All other equipment connected to the bus cable has to be passive, meaning that they are not allowed to provide energy to the system, except to a leakage current of 50mA for each connected device. Separately powered equipment needs a galvanic isolation to assure that the intrinsically safe fieldbus circuit remains passive.

The cable used to interconnect the devices need to have the parameters in the following range:

| | |
|--|-------------------|
| Loop resistance R': | 15 ... 150 Ohm/km |
| Inductance per unit length L': | 0,4 ... 1 mH/km |
| Capacitance per unit length C': | 80 ... 200 nF/km |
| C' = C' line/line + 0,5 C' line/screen, if both lines are floating or, C' = C' line/line + C'line/screen, if the screen is connected to one line | |
| Length of spur cable: | ≤ 30 m |
| Length of trunk cable: | ≤ 1 km |

At each end of the trunk cable an approved infallible line termination with the following parameters is suitable:

| | |
|--------------------|------------------|
| R = 90 ... 100 Ohm | C = 0 ... 2,2 μF |
|--------------------|------------------|

One of the allowed terminations might already be integrated in the associated apparatus.

The number of passive devices connected to the bus segment is not limited due to I.S. reasons. If the above rules are respected, the inductance and capacitance of the cable will not impair the intrinsic safety of the installation.

Notes:

1. Approved associated apparatus must be installed in accordance with manufacturer instructions
2. Approved associated apparatus must meet the following requirements:
V_{0c} ≤ V_{max}, I_{sc} ≤ I_{max}, P₀ ≤ P_{max}
3. The maximum non-hazardous area voltage must not exceed 250 V.
4. The installation must be in accordance with the Canadian Electrical code Part 1.
5. Each set of wires must be provided with grounded shield. The shield must extend as close to the terminal(s) as possible and it must be grounded shield at I. S. Barrier ground.
6. Caution: Use only supply wires suitable for 5 °C above surrounding.
7. Warning: Substitution of components may impair intrinsic safety. PE = I. S. Ground
8. The polarity for connecting 11 and 12 is of no importance due to an internal rectifier.
9. FISCO concept applies to fieldbus / circuit only.
10. Entity parameters apply to circuit 2, 3 and 4 and further required to meet the following conditions:
C₀ ≥ C_i + C_{able}; L₀ ≥ L_i + L_{able}

Intrinsically safe if installed as specified in manufacturer's installation manual.


CSA- certified for hazardous locations

Ex ia IIC; Class I, Zone 0

Class I; Groups A, B, C, D

Class II, Groups E, F + G; Class III.

Type 4 Enclosure



Revisions Control No. 0: March.2005

Revisions Control No. 1: Nov. 2012

Addendum to EB 8384-4 EN

and EB 8384-5 EN

Table 1: Maximum values

| | Fieldbus | | | Limit-switches inductive | Forced venting-function | Binary-input | | Serial-Interface | |
|-------------------------|------------|----------|----------------------|--------------------------|-------------------------|--------------|----------------------|----------------------|---------------------|
| | Foundation | | Profibus | | | 1 | 2 | active | passive |
| Circuit No. | 1 | | 1 | 2 | 3 | 4 | 5 | 6 | 6 |
| Terminal No. | 11 / 12 | | 11 / 12 | 41 / 42 | 81 / 82 | 87 and 88 | 85 and 86 | plug | |
| Groups | A, B IIC | C, D IIB | A, B, C, D IIC / IIB | ### | ### | ### | ### | ### | ### |
| V _{max} [V] | 24 | | 17,5 | 16 | 28 | 30 | V _{0C} 5,88 | V _{0C} 8,61 | V _{max} 16 |
| I _{max} [mA] | 360 | 380 | 380 | 25 | 115 | 100 | I _{SC} 1 | I _{SC} 55 | I _{max} 25 |
| P _{max} [W] | 1,04 | 2,58 | 5,32 | 64 mW | ## | ## | 7,2 mW | 250 mW | 64 mW |
| C _i [nF] | 5 | | | 60 | 5,3 | 0 | 2µF | 0,61µF | 0 |
| L _i [µH] | 10 | | | 100 | 0 | 0 | 10mH | 9mH | 0 |

Binary- input 1: For connection of an active signal circuit

Binary- input 2: For connection of an passive contact circuit directly on the control valve, e.g. passive pressure switch for leakage monitoring

Notes:

- Entity parameters must meet the following requirements:
 $V_{0C} \leq V_{max}$, $I_{SC} \leq I_{max}$, $P_0 \leq P_{max}$
 C_0 or $C_a \geq C_i + C_{cable}$ and L_0 or $L_a \geq L_i + L_{cable}$
- Install in accordance with the Canadian Electrical Code Part I
- Cable entry M 20 x1,5 or metal conduit acc. to dwg. No. 1050-0540

Table 2: CSA – certified barrier parameters of circuit 4

| Barrier | Supply barrier | | Evaluation barrier | |
|-----------|-----------------|------------------|--------------------|------------------|
| | V _{0C} | R _{min} | V _{0C} | R _{min} |
| circuit 3 | ≤28V | ≥245Ω | ≤28V | Diode |
| circuit 4 | ≤30V | ≥300Ω | ≤30V | Diode |

The correlation between temperature classification and permissible ambient temperature ranges is shown in the table 3 below:

Table 3:

| Temperature class | Permissible ambient temperature range |
|-------------------|---------------------------------------|
| T6 | +60°C |
| T5 | -40°C ≤ T _a ≤ +70°C |
| T4 | +80°C |


Table 4:

| | Foundation Fieldbus or Profibus PA (see PTB Certificate PTB 05 ATEX 2010 X) | | | | | | Limit-switches (inductive) | Forced venting function | Binary- Input 1 | Maximum values for serial-interface and binary input 2 see table 1 |
|------------------|--|-----------|-----------|--------------|-----------|-----------|-------------------------------|----------------------------|--------------------|---|
| Terminal | 11 / 12 | | | | | | 41 / 42 | 81 / 82 | 87 / 88 | |
| Groups | A, B and IIC | | | C, D and IIB | | | ### | ### | ### | |
| V _{max} | 20V DC | 24V DC | 30V DC | 20V DC | 24V DC | 30V DC | 20V | 30V | 30V | |
| I _{max} | 464 mA | 261 mA | 152 mA | 1,17 A | 650 mA | 379 mA | 25mA | 100mA | 100mA | |
| P _{max} | 2,32 | 1,56 | 1,14 | 5,88 | 3,89 | 3,85 | 64mW | ## | ## | |
| C _i | 5nF | | | | | | 60 | 5,3 | 0 | |
| L _i | 10µH | | | | | | 100 | 0 | 0 | |

CSA certified for hazardous locations:

Ex nA II; Ex nL IIC; Zone 2
 Class II, Div. 2; Groups A, B, C, D
 Class II, Div. 2 Groups E, F + G; Class III


Type 4 Enclosure



Revisions Control No. 0: March.2005
 Revisions Control No. 1: Nov. 2012

Addendum to EB 8384-4 EN
 and EB 8384-5 EN

Installation drawing Control Relay KHA5-OTI/Ex2, KHA6-OTI/Ex1 or KHA6-OTI/Ex2 with Model SJ-b-N Proximity Sensors



Model designation code Type KHab - cExde
 a= Supply Voltage type A or D
 a=AC, d=DC
 b= Supply Level
 2=24V DC±15%; 5=120V AC+10%-15%;
 6=230V AC+10%-15%;
 c= Output type RTA; RW1; SS1; SS2; RS1;
 SR; ST-or SOT
 d= Number of channels 1 or 2
 e= Power rail designation, P, 2S,P or GS.P
 (includes Model KHD2-EB-PB Power Feed Module) or Blank

The total series inductance and shunt capacitance of shield wiring shall be restricted to the following maximum values

maximum capacitance of each inductive sensor 30nF
 maximum inductance of each inductive sensor 100µH

System parameters

| Control Relay Terminal No. | Groups | L [mH] | C [µF] | V _{0C} [V] | I _{SC} [mA] | V _{max} [V] | R _{min} [Ω] |
|----------------------------|---------|--------|--------|---------------------|----------------------|----------------------|----------------------|
| 1-3; 2-3 4-6; 5-6 | A + B | 192 | 2,66 | ↑ | ↑ | ↑ | ↑ |
| | C + E | 671 | 7,9 | 10,5 | 13 | 10,5 | 811 |
| | D, F, G | 1000 | 21,3 | ↓ | ↓ | ↓ | ↓ |

Division 2 wiring method shall be in accordance to the Canadian Electrical Code Part 1.

Revisions Control No. 0: March.2005
 Revisions Control No. 1: Nov. 2012

Addendum to EB 8384-4 EN
 and EB 8384-5 EN

Installation Manual for apparatus approved by FM for use in hazardous locations.

Communication is optionally either according to the FOUNDATION™ Fieldbus Specification or according to PROFIBUS PA in compliance FISCO-Concept

The **FISCO Concept** allows interconnection of intrinsically safe apparatus to associated apparatus not specifically examined in such combination. The criteria for interconnection is that the voltage (V_{max}/U_i) the current (I_{max}/I_i) and the power (P_i) which intrinsically safe apparatus can receive and remain intrinsically safe, considering faults, must be equal or greater than the voltage (V_{oc}/U_o) the current (I_{sc}/I_o) and the power (P_o) levels which can be delivered by the associated apparatus, considering faults and applicable factors. In addition, the maximum unprotected capacitance (C_i) and inductance (L_i) of each apparatus (other than the termination) connected to the fieldbus must be less than or equal to 5 nF and 10 μ H respectively.

In each segment only one active device, normally the associated apparatus is allowed to provide the necessary energy for the fieldbus system. The allowed voltage (V_{oc}/U_o) of the associated apparatus is limited to the range of 14V DC. to 24V DC. All other equipment connected to the bus cable has to be passive, meaning that they are not allowed to provide energy to the system, except to a leakage current of 50mA for each connected device. Separately powered equipment needs a galvanic isolation to assure that the intrinsically safe fieldbus circuit remains passive.

The cable used to interconnect the devices need to have the parameters in the following range:

| | |
|---|-------------------|
| Loop resistance R': | 15 ... 150 Ohm/km |
| Inductance per unit length L': | 0,4 ... 1 mH/km |
| Capacitance per unit length C': | 80 ... 200 nF/km |
| C' = C' line/line + 0,5 C' line/screen, if both lines are floating or, C' = C' line/line + C' line/screen, if the screen is connected to one line | |
| Length of spur cable: | \leq 30 m |
| Length of trunk cable: | \leq 1 km |

At each end of the trunk cable an approved infallible line termination with the following parameters is suitable:

$$R = 90 \dots 100 \text{ Ohm} \qquad C = 0 \dots 2,2 \text{ } \mu\text{F}$$

One of the allowed terminations might already be integrated in the associated apparatus.

The number of passive devices connected to the bus segment is not limited due to I.S. reasons. If the above rules are respected, the inductance and capacitance of the cable will not impair the intrinsic safety of the installation.

Notes:

- Approved associated apparatus must be installed in accordance with manufacturer instructions
- Approved associated apparatus must meet the following requirements:
 $U_o \text{ or } V_{oc} \leq U_i \text{ or } V_{max}$, $I_o \text{ or } I_{sc} \leq I_i \text{ or } I_{max}$, $P_o \leq P_i \text{ or } P_{max}$
- The maximum non-hazardous area voltage must not exceed 250 V.
- The installation must be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.06.01
- Each set of wires must be provided with grounded shield. The shield must extend as close to the terminal(s) as possible and it must be grounded shield at I. S. Barrier ground.
- Caution: Use only supply wires suitable for 5 °C above surrounding.
- Warning: Substitution of components may impair intrinsic safety. PE = I. S. Ground
- The polarity for connecting 11 and 12 is of no importance due to an internal rectifier.
- FISCO concept applies to fieldbus / circuit only.
- Entity parameters apply to circuit 2, 3 and 4 and further required to meet the following conditions:
 $C_o \geq C_i + C_{cable}$; $L_o \geq L_i + L_{cable}$


Intrinsically safe if installed as specified in manufacturer's installation manual.

FM- approved for hazardous locations

Class I, Zone 0 AEx ia IIC T6:

Class I, II, III Div. 1, Groups A, B, C, D, E, F + G.

Field enclosure NEMA 4X



Revisions Control No. 0: March.2005

Addendum to EB 8384-5 EN

Table 1: Maximum values

| | Fieldbus | | | Limit-switches inductive | Forced venting-function | Binary- input | | Serial-Interface | |
|---|------------|----------|----------------------|--------------------------|-------------------------|---------------|----------------------|----------------------|---------------------|
| | Foundation | | Profibus | | | 1 | 2 | active | passive |
| Circuit No. | 1 | | 1 | 2 | 3 | 4 | 5 | 6 | 6 |
| Terminal No. | 11 / 12 | | 11 / 12 | 41 / 42 | 81 / 82 | 87 / 88 | 85 / 86 | plug | |
| Groups | A, B IIC | C, D IIB | A, B, C, D IIC / IIB | ## | ## | ## | ## | ## | ## |
| U _i or V _{max} [V] | 24 | | 17,5 | 16 | 28 | 30 | V _{0C} 5,88 | V _{0C} 8,61 | V _{max} 16 |
| I _i or I _{max} [mA] | 360 | 380 | 380 | 25 | 115 | 100 | I _{SC} 1 | I _{SC} 55 | I _{max} 25 |
| P _i or P _{max} [W] | 1,04 | 2,58 | 5,32 | 64 mW | ## | ## | 7,2 mW | 250 mW | 64 mW |
| C _i [nF] | 5 | | | 60 | 5,3 | 0 | 2μF | 0,61μF | 0 |
| L _i [μH] | 10 | | | 100 | 0 | 0 | 10mH | 9mH | 0 |

Binary- input 1: For connection of an active signal circuit

Binary- input 2: For connection of an passive contact circuit directly on the control valve, e.g. passive pressure switch for leakage monitoring

Notes:

- Entity parameters must meet the following requirements:
 $U_0 \leq U_i$ or V_{max} , $I_0 \leq I_i$ or I_{max} , $P_0 \leq P_i$ or P_{max} ; C_0 or $C_a \geq C_i + C_{cable}$ and L_0 or $L_a \geq L_i + L_{cable}$
- The installation must be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.06.01
- Cable entry M 20 x1,5 or metal conduit acc. to dwg. No. 1050-0540

Table 2: FM – approved barrier parameters of circuit 4

| Barrier | Supply barrier | | | | Evaluation barrier | |
|-----------|-----------------|------------------|-----------------|------------------|--------------------|------------------|
| | V _{0C} | R _{min} | I _{0C} | P _{max} | V _{0C} | R _{min} |
| circuit 3 | ≤28V | ≥245Ω | ≤115mA | ## | ≤28V | Diode |
| circuit 4 | ≤30V | ≥300Ω | ≤100mA | ## | ≤30V | Diode |

The correlation between temperature classification and permissible ambient temperature ranges is shown in the table 3 below:


Table 3:

| Temperature class | Permissible ambient temperature range |
|-------------------|---------------------------------------|
| T6 | +60°C |
| T5 | -40°C ≤ T _a ≤ +70°C |
| T4 | +80°C |

Table 4:

| | Foundation Fieldbus or Profibus PA (Non incensive Field wiring) | | | | | | | | Limit- switches (inductive) | Forced venting function | Binary- Input 1 | Maximum values for serial-interface and binary input 2 see table 1 |
|---|--|------|------|------|--------------|------|------|------|-----------------------------------|-------------------------------|--------------------|---|
| Terminal | 11 / 12 | | | | | | | | 41 / 42 | 81 / 82 | 87 / 88 | |
| Groups | A, B and IIC | | | | C, D and IIB | | | | ## | ## | ## | |
| U _i or V _{max} [VDC] | 20V | 24V | 30V | 32V | 20V | 24V | 30V | 32V | 20V | 30V | 30V | |
| I _i or I _{max} [mA] | 464 | 261 | 152 | 130 | 1,117 A | 650 | 379 | 324 | 25mA | 100mA | 100mA | |
| P _i or P _{max} [W] | 2,32 | 1,56 | 1,14 | 1,14 | 5,88 | 3,89 | 3,85 | 2,77 | 64mW | ## | ## | |
| C _i | 5nF | | | | | | | | 60 | 5,3 | 0 | |
| L _i | 10µH | | | | | | | | 100 | 0 | 0 | |


Ex nA II T6; Ex nL IIC T6 Zone 2.
Class I, II, Div. 2 Groups A, B, C, D, E+F.



Revisions Control No. 0: March.2005

Addendum to EB 8384-5 EN

Installation drawing Control Relay KHA5-OTI/Ex2, KHA6-OTI/Ex1 or KHA6-OTI/Ex2 with Model SJ-b-N Proximity Sensors



maximum capacitance of each inductive sensor 30nF
 maximum inductance of each inductive sensor 100µH

Model designation code Type KHab - cExde

- a= Supply Voltage type A or D
- a=AC, d=DC
- b= Supply Level
- 2=24V DC±15%; 5=120V AC+10%-15%;
- 6=230V AC+10%-15%;
- c= Output type RTA; RW1; SS1; SS2; RS1; SR; ST-or SOT
- d= Number of channels 1 or 2
- e= Power rail designation, P, 2S.P or GS.P (includes Model KHD2-EB-PB Power Feed Module) or Blank

Each pair of I.S. wires must be protected by a shield that is grounded at the I.S. Ground. The shield must extend as close to the terminals as possible installation shall be in accordance with the National Electrical Code ANSI/NFPA 70 and ANSI/ISA RP 12.06.01.

The total series inductance and shunt capacitance of shield wiring shall be restricted to the following maximum values

System parameters

| Control Relay Terminal No. | Groups | L [mH] | C [µF] | V _{0C} [V] | I _{SC} [mA] | V _{max} [V] | R _{min} [Ω] |
|----------------------------|---------|--------|--------|---------------------|----------------------|----------------------|----------------------|
| 1-3; 2-3 4-6; 5-6 | A + B | 192 | 2,66 | ↑ | ↑ | ↑ | ↑ |
| | C + E | 671 | 7,9 | 10,5 | 13 | 10,5 | 811 |
| | D, F, G | 1000 | 21,3 | ↓ | ↓ | ↓ | ↓ |

Revisions Control No. 0: March.2005

Addendum to EB 8384-5 EN



**EU Konformitätserklärung / EU Declaration of Conformity /
Déclaration UE de conformité**

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/
This declaration of conformity is issued under the sole responsibility of the manufacturer/
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.
Für das folgende Produkt / For the following product / Nous certifions que le produit

**Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation /
Electropneumatic Positioner with FOUNDATION FIELDBUS communication /
Positionneur électropneumatique avec communication FOUNDATION FIELDBUS
Typ/Type/Type 3730-5...**

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /
the conformity with the relevant Union harmonisation legislation is declared with /
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

| | |
|-----------------|---|
| EMC 2014/30/EU | EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013 |
| RoHS 2011/65/EU | EN 50581:2012 |

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3
D-60314 Frankfurt am Main
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

Hanno Zager
Leiter Qualitätssicherung/Head of Quality Management/
Responsable de l'assurance de la qualité

Dirk Hoffmann
Zentralabteilungsleiter/Head of Department/Chef du département
Entwicklungsorganisation/Development Organization



EU Konformitätserklärung / EU Declaration of Conformity / Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/
This declaration of conformity is issued under the sole responsibility of the manufacturer/
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.
Für das folgende Produkt / For the following product / Nous certifions que le produit

Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation / Electropneumatic Positioner with FOUNDATION FIELDBUS communication / Positionneur électropneumatique avec communication FOUNDATION FIELDBUS Typ/Type/Type 3730-51..

entsprechend der EU-Baumusterprüfbescheinigung PTB 04 ATEX 2109 ausgestellt von der/
according to the EU Type Examination PTB 04 ATEX 2109 issued by/
établi selon le certificat CE d'essais sur échantillons PTB 04 ATEX 2109 émis par:

Physikalisch Technische Bundesanstalt
Bundesallee 100
D-38116 Braunschweig
Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /
the conformity with the relevant Union harmonisation legislation is declared with/
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:


| | |
|--|---|
| EMC 2014/30/EU | EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013 |
| Explosion Protection 94/9/EC (bis/to 2016-04-19) | EN 60079-0:2012/A11:2013, |
| Explosion Protection 2014/34/EU (ab/from 2016-04-20) | EN 60079-11:2012, EN 60079-31:2014 |
| RoHS 2011/65/EU | EN 50581:2012 |

Hersteller / Manufacturer / Fabricant:


SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3
D-60314 Frankfurt am Main
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.



Hanno Zager
Leiter Qualitätssicherung/Head of Quality Management/
Responsable de l'assurance de la qualité



Dirk Hoffmann
Zentralabteilungsleiter/Head of Department/Chef du département
Entwicklungsorganisation/Development Organization



EU Konformitätserklärung / EU Declaration of Conformity / Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/
This declaration of conformity is issued under the sole responsibility of the manufacturer/
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.
Für das folgende Produkt / For the following product / Nous certifions que le produit

Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation / Electropneumatic Positioner with FOUNDATION FIELDBUS communication / Positionneur électropneumatique avec communication FOUNDATION FIELDBUS Typ/Type/Type 3730-55..

entsprechend der EU-Baumusterprüfbescheinigung PTB 04 ATEX 2109 ausgestellt von der/
according to the EU Type Examination PTB 04 ATEX 2109 issued by/
établi selon le certificat CE d'essais sur échantillons PTB 04 ATEX 2109 émis par:

Physikalisch Technische Bundesanstalt
Bundesallee 100
D-38116 Braunschweig
Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /
the conformity with the relevant Union harmonisation legislation is declared with/
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:

| | |
|--|---|
| EMC 2014/30/EU | EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013 |
| Explosion Protection 94/9/EC (bis/to 2016-04-19) | EN 60079-0:2012/A11:2013, |
| Explosion Protection 2014/34/EU (ab/from 2016-04-20) | EN 60079-11:2012, EN 60079-31:2014 |
| RoHS 2011/65/EU | EN 50581:2012 |

Hersteller / Manufacturer / Fabricant:

SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3
D-60314 Frankfurt am Main
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.

H. Zager

Hanno Zager
Leiter Qualitätssicherung/Head of Quality Management/
Responsable de l'assurance de la qualité

D. Hoffmann

Dirk Hoffmann
Zentralabteilungsleiter/Head of Department/Chef du département
Entwicklungsorganisation/Development Organization



EU Konformitätserklärung / EU Declaration of Conformity / Déclaration UE de conformité

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller/
This declaration of conformity is issued under the sole responsibility of the manufacturer/
La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.
Für das folgende Produkt / For the following product / Nous certifions que le produit

Elektropneumatischer Stellungsregler mit FOUNDATION FIELDBUS Kommunikation / Electropneumatic Positioner with FOUNDATION FIELDBUS communication / Positionneur électropneumatique avec communication FOUNDATION FIELDBUS Typ/Type/Type 3730-58..

entsprechend der EU-Baumusterprüfbescheinigung PTB 05 ATEX 2010 X ausgestellt von der/
according to the EU Type Examination PTB 05 ATEX 2010 X issued by/
établi selon le certificat CE d'essais sur échantillons PTB 05 ATEX 2010 X émis par:

Physikalisch Technische Bundesanstalt
Bundesallee 100
D-38116 Braunschweig
Benannte Stelle/Notified Body/Organisme notifié 0102

wird die Konformität mit den einschlägigen Harmonisierungsrechtsvorschriften der Union bestätigt /
the conformity with the relevant Union harmonisation legislation is declared with/
est conforme à la législation d'harmonisation de l'Union applicable selon les normes:


| | |
|--|---|
| EMC 2014/30/EU | EN 61000-6-2:2005, EN 61000-6-3:2007 +A1:2011, EN 61326-1:2013 |
| Explosion Protection 94/9/EC (bis/to 2016-04-19) | EN 60079-15:2010, EN 60079-31:2009 |
| Explosion Protection 2014/34/EU (ab/from 2016-04-20) | |
| RoHS 2011/65/EU | EN 50581:2012 |

Hersteller / Manufacturer / Fabricant:


SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3
D-60314 Frankfurt am Main
Deutschland/Germany/Allemagne

Frankfurt / Francfort, 2017-07-29

Im Namen des Herstellers/ On behalf of the Manufacturer/ Au nom du fabricant.



Hanno Zager
Leiter Qualitätssicherung/Head of Quality Management/
Responsable de l'assurance de la qualité



Dirk Hoffmann
Zentralabteilungsleiter/Head of Department/Chef du département
Entwicklungsorganisation/Development Organization

EB 8384-5 EN



SAMSON AKTIENGESELLSCHAFT
Weismüllerstraße 3 · 60314 Frankfurt am Main, Germany
Phone: +49 69 4009-0 · Fax: +49 69 4009-1507
samson@samsongroup.com · www.samsongroup.com